


## HEADLIGHT RELAY CIRCUIT

### CIRCUIT DESCRIPTION

The multiplex network body ECU controls the HEAD relay when signals are received from the headlamp dimmer switch assy.

WIRING DIAGRAM



C

I39984

## INSPECTION PROCEDURE

### 1 PERFORM ACTIVE TEST USING HAND-HELD TESTER

- (a) Connect the hand-held tester to the DLC3.
- (b) Push the power switch ON (IG) and turn the hand-held tester main switch on.
- (c) Select the item below in the ACTIVE TEST and then check that the head relay operates.

#### B No.1/GW (Multiplex Network Body ECU):

Item	Test Details	Diagnostic Note
HEAD LIGHT	Turn headlamp relay ON/OFF	-
HEAD LIGHT (HI)	Turn headlamp dimmer relay (headlamp dimmer switch in HI position) ON/OFF	-

**OK: Headlamp is comes on.**

**NG**

**Go to step 2**


**OK**

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE  
(SEE PAGE 05-1677)**

**2 INSPECT INSTRUMENT PANEL JUNCTION BLOCK ASSY**

- (a) Disconnect the B7 connector from the instrument panel junction block assy.
- (b) Using a service wire, connect B7-20 of the wire harness side and body ground.

**OK: Headlamp (Low beam) comes on**




**NG** Go to step 4

**OK**

**3 INSPECT INSTRUMENT PANEL JUNCTION BLOCK ASSY**

- (a) Using a service wire, connect B7-20 of the wire harness side and body ground.
- (b) Using a service wire, connect B7-2 of the wire harness side and body ground.

**OK: Headlamp (High beam) comes on**



**NG** Go to step 5

**OK**


**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE (SEE PAGE 05-1677)**

**4 CHECK HARNESS AND CONNECTOR(HEAD SIGNAL CIRCUIT)**

(a) Measure the voltage according to the value(s) in the table below.

**Standard:**

Tester connection	Condition	Specified condition
B7-20 - Body ground	Always	10 to 14 V



**NG** REPAIR OR REPLACE HARNESS OR CONNECTOR (INSTRUMENT PANEL JUNCTION BLOCK ASSY - BATTERY)

**OK**


**REPAIR OR REPLACE HARNESS OR CONNECTOR (EACH OF HEADLIGHT (LOW BEAM) CIRCUIT)**

**5 CHECK HARNESS AND CONNECTOR(DRL/DIM SIGNAL CIRCUIT)**

(a) Measure the voltage according to the value(s) in the table below.

**Standard:**

Tester connection	Condition	Specified condition
B7-2 - Body ground	Connect B5-20 and Body ground	10 to 14 V



**NG** REPAIR OR REPLACE HARNESS OR CONNECTOR (INSTRUMENT PANEL JUNCTION BLOCK ASSY - ENGINE ROOM R/B AND J/B)

**OK**

**REPAIR OR REPLACE HARNESS OR CONNECTOR (EACH OF HEADLIGHT (HIGH BEAM) CIRCUIT)**