

# Recalibrating fuel gauge

[https://www.youtube.com/watch?v=\\_es6nB8OEzc](https://www.youtube.com/watch?v=_es6nB8OEzc)

## *Second Generation Toyota Prius*

After replacement of the combination meter, reset the standard horizontal angle of the inclination sensor.

1. Start with a full tank of gas, with the vehicle on level ground
  - a. The accuracy of this procedure depends on this step
  - b. Ideally the level should be within  $\pm 3^\circ$
2. Start the car and press ODO until Trip A is showing
3. Turn off engine
4. Keep your foot off the brake, press and HOLD the ODO/TRIP button
  - a. *(Do not put your foot on the brake)*
5. Press the POWER button twice
6. Release and press the ODO/TRIP button THREE times, HOLD
  - a. Press the ODO/TRIP button (switch?) within 5 seconds and hold it at least 5 seconds
  - b. Release-Press-Release-Press-Release-Press and Hold
7. Wait until the odometer displays a series of SIX digits.
8. Release the ODO/TRIP button then press it again
9. The odometer will change to five digits, the third digit will quickly change to 1
  - a. HINT:  
If "0", "2", or "3" is displayed, perform the procedure again from the beginning
- 10 Release the ODO/TRIP button  
(Once the reset is complete, the odometer will return to normal)