



|   |                     |                                      |
|---|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000TBX1       |
| <b>Model Year Start:</b> 2016   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING AMPLIFIER: COMPONENTS; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

## COMPONENTS

## ILLUSTRATION



|    |   |    |                                |
|----|---|----|--------------------------------|
| *1 | AIR CONDITIONING AMPLIFIER ASSEMBLY                       | *2 | FRONT NO. 1 CONSOLE BOX INSERT |
| *3 | LOWER CENTER INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY | -  | -                              |




|  |              |                               |
|--|--------------|-------------------------------|
| Last Modified: 01-14-2019  | 6.8:8.0.48   | Doc ID: RM100000000TBX3       |
| Model Year Start: 2016   | Model: Prius | Prod Date Range: [11/2015 - ] |
| Title: HEATING / AIR CONDITIONING: AIR CONDITIONING AMPLIFIER: INSTALLATION; 2016 - 2019 MY Prius [11/2015 - ] |              |                               |

## INSTALLATION


### PROCEDURE

#### 1. INSTALL AIR CONDITIONING AMPLIFIER ASSEMBLY


- (a) Connect each connector.
- (b) Align the rib of the air conditioning amplifier assembly with the rib of the air conditioner unit assembly and engage the guide as shown in the illustration.



P

|  |  |
|--|--|
| *a   | Rib of Air Conditioning Amplifier Assembly |
| *b   | Rib of Air Conditioner Unit Assembly       |
| *c   | Align                                      |
|  | Install in this Direction                  |

(c) Move the air conditioning amplifier assembly in each direction shown in the illustration to check that the guide is securely engaged.



(d) Install the air conditioning amplifier assembly with the screw.

## 2. INSTALL FRONT NO. 1 CONSOLE BOX INSERT

Click here [INFO](#) [INFO](#) [INFO](#)

## 3. INSTALL LOWER CENTER INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY

Click here [INFO](#) [INFO](#)

## 4. INSTALL ACCELERATOR PEDAL SENSOR ASSEMBLY

Click here [INFO](#) [INFO](#)

## 5. INSTALL REAR CONSOLE BOX ASSEMBLY

Click here [INFO](#) [INFO](#)

## 6. INITIALIZATION SERVO MOTOR

Click here [INFO](#)



|  |                     |                                      |
|--|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000TBX2       |
| <b>Model Year Start:</b> 2016  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING AMPLIFIER: REMOVAL; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

## REMOVAL

### CAUTION / NOTICE / HINT

The necessary procedures (adjustment, calibration, initialization or registration) that must be performed after parts are removed and installed, or replaced during air conditioning amplifier assembly removal/installation are shown below.

#### **Necessary Procedure After Parts Removed/Installed/Replaced**

| REPLACED PART OR PERFORMED PROCEDURE | NECESSARY PROCEDURE                              | EFFECT/INOPERATIVE FUNCTION WHEN NECESSARY PROCEDURE NOT PERFORMED | LINK                 |
|--------------------------------------|--|--|----------------------|
| Air conditioning amplifier assembly  | Initialize servo motor (Air conditioning system) | DTCs are stored  | <a href="#">INFO</a> |

## PROCEDURE

### **1. REMOVE REAR CONSOLE BOX ASSEMBLY**

Click here [INFO](#) [INFO](#)

### **2. REMOVE ACCELERATOR PEDAL SENSOR ASSEMBLY**

Click here [INFO](#) [INFO](#)

### **3. REMOVE LOWER CENTER INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY**


Click here [INFO](#) [INFO](#) [INFO](#)

### **4. REMOVE FRONT NO. 1 CONSOLE BOX INSERT**



Click here [INFO](#) [INFO](#) [INFO](#)

### **5. REMOVE AIR CONDITIONING AMPLIFIER ASSEMBLY**


(a) Remove the screw.



(b) Disengage the guide to remove the air conditioning amplifier assembly as shown in the illustration.




(c) Disconnect each connector.




|   |              |                               |
|---|--------------|-------------------------------|
| Last Modified: 01-14-2019   | 6.8:8.0.48   | Doc ID: RM100000000TBWU       |
| Model Year Start: 2016  | Model: Prius | Prod Date Range: [11/2015 - ] |
| Title: HEATING / AIR CONDITIONING: AIR CONDITIONING FILTER: COMPONENTS; 2016 - 2019 MY Prius [11/2015 - ] |              |                               |

## COMPONENTS

## ILLUSTRATION



|    |                                 |    |                    |
|----|---------------------------------|----|--------------------|
| *1 | AIR FILTER COVER PLATE          | *2 | CLEAN AIR FILTER   |
| *3 | GLOVE COMPARTMENT DOOR ASSEMBLY | *4 | COOLING UNIT PARTS |
| *5 | AIR FILTER SUB-ASSEMBLY         | -  | -                  |




|   |              |                               |
|---|--------------|-------------------------------|
| Last Modified: 01-14-2019   | 6.8:8.0.48   | Doc ID: RM100000000TBWW       |
| Model Year Start: 2016  | Model: Prius | Prod Date Range: [11/2015 - ] |
| Title: HEATING / AIR CONDITIONING: AIR CONDITIONING FILTER: INSTALLATION; 2016 - 2019 MY Prius [11/2015 - ] |              |                               |

## INSTALLATION

### PROCEDURE

#### 1. INSTALL CLEAN AIR FILTER

(a) Engage the 2 guides on the cutout side of the cooling unit parts and then engage the 2 guides as shown in the illustration to install the clean air filter.





| *a | Cutout                        | *b | Rib                           |
|----|-------------------------------|----|-------------------------------|
|    | Install in this Direction (1) |    | Install in this Direction (2) |

#### NOTICE:

- Make sure that the "UP" marks are facing the correct direction before installing the clean air filter.
- Make sure that there is no clearance between the clean air filter and cooling unit parts and that the clean air filter is not deformed.

(b) Install the air filter sub-assembly as shown in the illustration.





**NOTICE:**

Make sure that the "UP" mark is facing the correct direction before installing the air filter sub-assembly.


**2. INSTALL AIR FILTER COVER PLATE**

(a) Engage the 2 guides and claw as indicated by the arrows, in the order shown in the illustration to install the air filter cover plate.



**3. INSTALL GLOVE COMPARTMENT DOOR ASSEMBLY**

Click here [INFO](#) [INFO](#)





|  |              |                               |
|--|--------------|-------------------------------|
| Last Modified: 01-14-2019  | 6.8:8.0.48   | Doc ID: RM100000000TBWV       |
| Model Year Start: 2016   | Model: Prius | Prod Date Range: [11/2015 - ] |
| Title: HEATING / AIR CONDITIONING: AIR CONDITIONING FILTER: REMOVAL; 2016 - 2019 MY Prius [11/2015 - ] |              |                               |

## REMOVAL


### PROCEDURE

#### 1. REMOVE GLOVE COMPARTMENT DOOR ASSEMBLY

Click here [INFO](#) [INFO](#) [INFO](#)

#### 2. REMOVE AIR FILTER COVER PLATE


(a) Disengage the claw and 2 guides as indicated by the arrows, in the order shown in the illustration to remove the air filter cover plate.



|  |                              |
|--|------------------------------|
|  | Remove in this Direction (1) |
|  | Remove in this Direction (2) |

#### 3. REMOVE CLEAN AIR FILTER

(a) Remove the air filter sub-assembly as shown in the illustration.




|  |  |
|--|--|
|  |  |
|--|--|



Remove in this Direction


(b) Disengage the 4 guides to remove the clean air filter from the cooling unit parts.



|  |              |                               |
|--|--------------|-------------------------------|
| Last Modified: 01-14-2019  | 6.8:8.0.48   | Doc ID: RM1000000018JEW       |
| Model Year Start: 2018   | Model: Prius | Prod Date Range: [11/2017 - ] |
| Title: HEATING / AIR CONDITIONING: AIR CONDITIONING PANEL: COMPONENTS; 2018 - 2019 MY Prius [11/2017 - ] |              |                               |

## COMPONENTS


## ILLUSTRATION



|    |                                      |    |   |
|----|--------------------------------------|----|---|
| *A | except 11.6 Inch Display             | -  | -   |
| *1 | AIR CONDITIONING CONTROL ASSEMBLY    | *2 | CENTER INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY |
| *3 | INSTRUMENT PANEL FINISH PANEL END RH | -  | -   |

## ILLUSTRATION

\*A




P

|    |   |    |  |
|----|---|----|--|
| *A | for 11.6 Inch Display   | -  | -  |
| *1 | CENTER INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY WITH NAVIGATION RECEIVER ASSEMBLY | *2 | CENTER INSTRUMENT CLUSTER FINISH PANEL UPPER |
| *3 | INSTRUMENT PANEL FINISH PANEL END RH  | -  | -  |

## ILLUSTRATION

\*A



P


|    |   |    |                                       |
|----|---|----|---------------------------------------|
| *A | for 11.6 Inch Display                               | *B | w/ Satellite Radio                    |
| *1 | CENTER INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY | *2 | HAZARD WARNING SIGNAL SWITCH ASSEMBLY |
| *3 | INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY        | *4 | NAVIGATION RECEIVER ASSEMBLY          |
| *5 | NO. 1 RADIO BRACKET                                 | *6 | NO. 2 RADIO BRACKET                   |

\*7

STEREO COMPONENT TUNER  
ASSEMBLY WITH WIRE

-

-



|   |                     |                                      |
|---|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM1000000018JHL       |
| <b>Model Year Start:</b> 2018   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2017 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING PANEL: INSTALLATION; 2018 - 2019 MY Prius [11/2017 - ] |                     |                                      |

## [INSTALLATION](#)

### [PROCEDURE](#)

**1. INSTALL STEREO COMPONENT TUNER ASSEMBLY WITH WIRE (for 11.6 Inch Display with Satellite Radio)**

**2. INSTALL NAVIGATION RECEIVER ASSEMBLY (for 11.6 Inch Display)**

**3. INSTALL NO. 2 RADIO BRACKET (for 11.6 Inch Display)**

Click here [INFO](#)

**4. INSTALL NO. 1 RADIO BRACKET (for 11.6 Inch Display)**

Click here [INFO](#)

**5. INSTALL HAZARD WARNING SIGNAL SWITCH ASSEMBLY (for 11.6 Inch Display)**

Click here [INFO](#)

**6. CONNECT STEREO COMPONENT TUNER ASSEMBLY WITH WIRE (for 11.6 Inch Display with Satellite Radio)**

Click here [INFO](#)

**7. INSTALL CENTER INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY (for 11.6 Inch Display)**

Click here [INFO](#)

**8. INSTALL INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY (for 11.6 Inch Display)**

Click here [INFO](#)

**9. INSTALL AIR CONDITIONING CONTROL ASSEMBLY (except 11.6 Inch Display)**

(a) Engage the 4 guides and claw.

(b) Install the air conditioning control assembly with the 2 screws.

**10. INSTALL CENTER INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY (except 11.6 Inch Display)**

Click here [INFO](#)

**11. INSTALL CENTER INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY WITH NAVIGATION RECEIVER ASSEMBLY (for 11.6 Inch Display)**

Click here [INFO](#)

**12. INSTALL CENTER INSTRUMENT CLUSTER FINISH PANEL UPPER (for 11.6 Inch Display)**


Click here [INFO](#)

**13. INSTALL INSTRUMENT PANEL FINISH PANEL END RH**

Click here [INFO](#)

#### 14. CONNECT CABLE TO NEGATIVE AUXILIARY BATTERY TERMINAL (for 11.6 Inch Display)

Click here [INFO](#) [INFO](#)





|   |                     |                                      |
|---|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000001GLC7       |
| <b>Model Year Start:</b> 2019   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [12/2018 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING PANEL: REMOVAL; 2019 MY Prius [12/2018 - ] |                     |                                      |

## REMOVAL

### CAUTION / NOTICE / HINT

The necessary procedures (adjustment, calibration, initialization, or registration) that must be performed after parts are removed and installed, or replaced during air conditioning panel removal/installation are shown below.

#### Necessary Procedures After Parts Removed/Installed/Replaced

| REPLACED PART OR PERFORMED PROCEDURE                      | NECESSARY PROCEDURE                   | EFFECT/INOPERATIVE FUNCTION WHEN NECESSARY PROCEDURE NOT PERFORMED | LINK                 |
|---|---------------------------------------|--|----------------------|
| Disconnect cable from negative auxiliary battery terminal | Memorize steering angle neutral point | Lane departure alert system (w/ Steering Control)                  | <a href="#">INFO</a> |
|   |                                       | Intelligent clearance sonar system*1                               |                      |
|   |                                       | Simple advanced parking guidance system*1                          |                      |
|   |                                       | Pre-collision system   |                      |
|   | AFS (Adaptive Front-lighting System)  |  |                      |
|   | Initialize back door lock             | Power door lock control system                                     | <a href="#">INFO</a> |
| *1: When performing learning using the Techstream.        |                                       |  |                      |
| Click here <a href="#">INFO</a>                           |                                       |  |                      |

## PROCEDURE

### 1. PRECAUTION (for 11.6 Inch Display)

#### NOTICE:

After turning the power switch off, waiting time may be required before disconnecting the cable from the negative (-) auxiliary battery terminal. Therefore, make sure to read the disconnecting the cable from the negative (-) auxiliary battery terminal notices before proceeding with work.

Click here [INFO](#)

Click here [INFO](#)

### 2. DISCONNECT CABLE FROM NEGATIVE AUXILIARY BATTERY TERMINAL (for 11.6 Inch Display)

Click here [INFO](#)

### 3. REMOVE INSTRUMENT PANEL FINISH PANEL END RH


Click here [INFO](#)

### 4. REMOVE CENTER INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY (except 11.6 Inch Display)

Click here [INFO](#)

### 5. REMOVE AIR CONDITIONING CONTROL ASSEMBLY (except 11.6 Inch Display)

(a) Remove the 2 screws.



(b) Disengage the claw and 4 guides to remove the air conditioning control assembly.

**6. REMOVE CENTER INSTRUMENT CLUSTER FINISH PANEL UPPER (for 11.6 Inch Display)**

Click here [INFO](#)

**7. REMOVE CENTER INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY WITH NAVIGATION RECEIVER ASSEMBLY (for 11.6 Inch Display)**

Click here [INFO](#)

**8. REMOVE INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY (for 11.6 Inch Display)**

Click here [INFO](#)

**9. REMOVE CENTER INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY (for 11.6 Inch Display)**

Click here [INFO](#)

**10. DISCONNECT STEREO COMPONENT TUNER ASSEMBLY WITH WIRE (for 11.6 Inch Display with Satellite Radio)**

Click here [INFO](#)

**11. REMOVE HAZARD WARNING SIGNAL SWITCH ASSEMBLY (for 11.6 Inch Display)**

Click here [INFO](#)

**12. REMOVE NO. 1 RADIO BRACKET (for 11.6 Inch Display)**

Click here [INFO](#)

**13. REMOVE NO. 2 RADIO BRACKET (for 11.6 Inch Display)**

Click here [INFO](#)

**14. REMOVE NAVIGATION RECEIVER ASSEMBLY (for 11.6 Inch Display)**


**15. REMOVE STEREO COMPONENT TUNER ASSEMBLY WITH WIRE (for 11.6 Inch Display with Satellite Radio)**




|  |              |                               |
|--|--------------|-------------------------------|
| Last Modified: 01-14-2019  | 6.8:8.0.48   | Doc ID: RM100000000T88J       |
| Model Year Start: 2016   | Model: Prius | Prod Date Range: [11/2015 - ] |
| Title: HEATING / AIR CONDITIONING: AIR CONDITIONING PRESSURE SENSOR: COMPONENTS; 2016 - 2019 MY Prius [11/2015 - ] |              |                               |

## COMPONENTS

## ILLUSTRATION



|    |   |   |                   |
|----|---|---|-------------------|
| *1 | AIR CONDITIONER PRESSURE SENSOR         | - | -                 |
|    | N*m (kgf*cm, ft.*lbf): Specified torque | • | Non-reusable part |
|    | Compressor oil ND-OIL 11 or equivalent  | - | -                 |



|   |                     |                                      |
|---|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000T88L       |
| <b>Model Year Start:</b> 2016   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING PRESSURE SENSOR: INSTALLATION; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

## INSTALLATION

### PROCEDURE

#### 1. INSTALL AIR CONDITIONER PRESSURE SENSOR

- (a) Remove the vinyl tape from the air conditioner tube and accessory assembly.
- (b) Sufficiently apply compressor oil to a new air conditioner pressure sensor and the fitting surface of the air conditioner pressure sensor.


Compressor Oil:

ND-OIL 11 or equivalent

- (c) Using a 27 mm deep socket wrench, install the air conditioner pressure sensor as shown in the illustration.

**Torque:**

**10.8 N·m { 110 kgf·cm, 8 ft·lbf }**



|    |      |
|----|------|
| *a | Turn |
| *b | Hold |

- (d) Connect the connector.

#### 2. CHARGE AIR CONDITIONING SYSTEM WITH REFRIGERANT


Click here [INFO](#)

#### 3. WARM UP COMPRESSOR

Click here [INFO](#)

#### 4. INSPECT FOR REFRIGERANT LEAK

Click here [INFO](#)



|  |                     |  |
|--|---------------------|--|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000T88M           |
| <b>Model Year Start:</b> 2016  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 -     ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING PRESSURE SENSOR: ON-VEHICLE INSPECTION; 2016 - 2019 MY Prius [11/2015 -     ] |                     |  |

## ON-VEHICLE INSPECTION

### PROCEDURE

#### 1. INSPECT AIR CONDITIONER PRESSURE SENSOR

(a) Check the wire harness.

- (1) Disconnect the A29 air conditioner pressure sensor connector.
- (2) Disconnect the F57 air conditioning amplifier assembly connector.
- (3) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A29\)](#)

[Click Location & Routing\(F57\)](#)

[Click Connector\(A29\)](#)

[Click Connector\(F57\)](#)

| TESTER CONNECTION                        | CONDITION | SPECIFIED CONDITION     |
|--|-----------|-------------------------|
| A29-1 (-) - F57-2 (SG-2)                 | Always    | Below 1 $\Omega$        |
| A29-2 (PR) - F57-24 (PRE)                | Always    | Below 1 $\Omega$        |
| A29-3 (+) - F57-6 (S5 -3)                | Always    | Below 1 $\Omega$        |
| A29-1 (-) or F57-2 (SG-2) - Body ground  | Always    | 10 k $\Omega$ or higher |
| A29-2 (PR) or F57-24 (PRE) - Body ground | Always    | 10 k $\Omega$ or higher |
| A29-3 (+) or F57-6 (S5 -3) - Body ground | Always    | 10 k $\Omega$ or higher |

If the resistance is not as specified, repair the wire harness.

- (4) Reconnect the F57 air conditioning amplifier assembly connector.
- (5) Turn the power switch on (IG).
- (6) Measure the voltage according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(A29\)](#)

[Click Connector\(A29\)](#)

| TESTER CONNECTION       | CONDITION            | SPECIFIED CONDITION |
|-------------------------|----------------------|---------------------|
| A29-3 (+) - Body ground | Power switch on (IG) | 4.75 to 5.25 V      |

If the voltage is not as specified, repair the wire harness or replace air conditioning amplifier assembly.

(b) Check the air conditioner pressure sensor.

- (1) Connect the connector to the air conditioner pressure sensor.
- (2) Install a manifold gauge set.
- (3) Turn the A/C switch on.

(4) Measure the voltage according to the value(s) in the table below.

**HINT:**

Check from the rear of the connector while it is connected to the air conditioning amplifier assembly.

Standard Voltage:




[Click Location & Routing\(F57\)](#)


[Click Connector\(F57\)](#)

| TESTER CONNECTION              | CONDITION  | SPECIFIED CONDITION |
|--------------------------------|--|---------------------|
| F57-24 (PRE)<br>- F57-2 (SG-2) | Refrigerant pressure: Normal pressure (less than 3025 kPa (30.8 kgf/cm <sup>2</sup> , 439 psi) and more than 176 kPa (1.8 kgf/cm <sup>2</sup> , 26 psi)) | 0.74 to 4.61 V      |

If the voltage is not as specified, replace the air conditioner pressure sensor.



|    |  |
|----|--|
| *a | Component with harness connected (Air Conditioning Amplifier Assembly) |
|----|--|



|  |                     |                                      |
|--|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000T88K       |
| <b>Model Year Start:</b> 2016  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING PRESSURE SENSOR: REMOVAL; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

## REMOVAL

### PROCEDURE

#### 1. RECOVER REFRIGERANT FROM REFRIGERATION SYSTEM

Click here [INFO](#)


#### 2. REMOVE AIR CONDITIONER PRESSURE SENSOR

(a) Disconnect the connector.


(b) Using a 27 mm deep socket wrench, remove the air conditioner pressure sensor as shown in the illustration.

**NOTICE:**

Seal the openings of the disconnected parts using vinyl tape to prevent entry of moisture and foreign matter.



|    |      |
|----|------|
| *a | Turn |
| *b | Hold |




|  |                     |  |
|--|---------------------|--|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM1000000018K1Z           |
| <b>Model Year Start:</b> 2018  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2017 -     ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: Air Conditioning Control Panel Circuit; 2018 - 2019 MY Prius [11/2017 -     ] |                     |  |

**Air Conditioning Control Panel Circuit**

## DESCRIPTION

The navigation receiver assembly switch signals are sent to the air conditioning amplifier assembly via CAN communication.

## WIRING DIAGRAM



## PROCEDURE

|           |                                       |
|-----------|---------------------------------------|
| <b>1.</b> | <b>CHECK CAN COMMUNICATION SYSTEM</b> |
|-----------|---------------------------------------|

(a) Using the Techstream, check for CAN communication system DTCs.

Click here [INFO](#) [INFO](#)

| RESULT                  | PROCEED TO |
|-------------------------|------------|
| CAN DTCs are not output | A          |
| CAN DTCs are output     | B          |

**B** [▶](#) **GO TO CAN COMMUNICATION SYSTEM** [INFO](#) [INFO](#)



**A**  
▼


|           |   |
|-----------|---|
| <b>2.</b> | <b>CHECK NAVIGATION RECEIVER ASSEMBLY</b> |
|-----------|---|

(a) Check the operation of the navigation system and then operate the air conditioning system using the navigation receiver assembly.

| RESULT  | PROCEED TO |
|---|------------|
| Only the air conditioning function does not operate | A          |
| The navigation receiver assembly does not operate   | B          |

**A** ► **REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY**


**B** ► **GO TO NAVIGATION SYSTEM**



|   |                     |                                      |
|---|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000RW4W       |
| <b>Model Year Start:</b> 2016   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B14A2; Driver Side Solar Sensor Short Circuit; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

|            |              |   |
|------------|--------------|---|
| <b>DTC</b> | <b>B14A2</b> | <b>Driver Side Solar Sensor Short Circuit</b> |
|------------|--------------|---|

## DESCRIPTION




The cooler (solar sensor) thermistor is installed on the upper side of the instrument panel. It detects sunlight to control air conditioning control in AUTO mode. The output voltage from the cooler (solar sensor) thermistor varies in accordance with the amount of sunlight. When the sunlight increases, the output voltage increases. As the sunlight decreases, the output voltage decreases. The air conditioning amplifier assembly detects changes in the output voltage from the cooler (solar sensor) thermistor.

| DTC NO. | DETECTION ITEM                         | DTC DETECTION CONDITION                           | TROUBLE AREA  | MEMORY                         |
|---------|--|---|---|--------------------------------|
| B14A2   | Driver Side Solar Sensor Short Circuit | Short in cooler (solar sensor) thermistor circuit | <ul style="list-style-type: none"> <li>Cooler (solar sensor) thermistor</li> <li>Harness or connector</li> <li>Air conditioning amplifier assembly</li> </ul> | Memorized<br>(4 sec. or more)* |

\*: The air conditioning amplifier assembly stores this DTC if the malfunction has occurred for the period of time indicated in the brackets.

## WIRING DIAGRAM



## PROCEDURE

### 1. READ VALUE USING TECHSTREAM

- Connect the Techstream to the DLC3.
- Turn the power switch on (IG).
- Turn the Techstream on.
- Enter the following menus: Body Electrical / Air Conditioner / Data List.
- Read the Data List according to the display on the Techstream.

#### Body Electrical > Air Conditioner > Data List

| TESTER DISPLAY        | MEASUREMENT ITEM | RANGE                | NORMAL CONDITION                                    | DIAGNOSTIC NOTE |
|-----------------------|------------------|----------------------|---|-----------------|
| Solar Sensor (D Side) | Solar sensor     | Min.: 0<br>Max.: 255 | Solar sensor value increase as brightness increases | -               |

#### Body Electrical > Air Conditioner > Data List

| TESTER DISPLAY        |
|-----------------------|
| Solar Sensor (D Side) |

OK:

The display is as specified in the normal condition column.

| RESULT  | PROCEED TO |
|---|------------|
| OK (When troubleshooting according to Problem Symptoms Table) | A          |

|  |   |
|--|---|
| OK (When troubleshooting according to the DTC) | B |
| NG   | C |

**A** ▶ PROCEED TO NEXT SUSPECTED AREA SHOWN IN PROBLEM SYMPTOMS TABLE [INFO](#) [INFO](#) [INFO](#) [INFO](#)

**B** ▶ REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY

**C**



**2. CHECK HARNESS AND CONNECTOR (POWER SOURCE CIRCUIT)**

(a) Disconnect the G2 cooler (solar sensor) thermistor connector.

(b) Measure the voltage according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(G2\)](#)

[Click Connector\(G2\)](#)


| TESTER CONNECTION       | CONDITION            | SPECIFIED CONDITION |
|-------------------------|----------------------|---------------------|
| G2-1 (SS+) - G2-2 (SS-) | Power switch off     | Below 1 V           |
| G2-1 (SS+) - G2-2 (SS-) | Power switch on (IG) | 4.5 to 5.5 V        |

**NG** ▶ GO TO STEP 4

**OK**



**3. INSPECT COOLER (SOLAR SENSOR) THERMISTOR**



|    |  |
|----|--|
| *a | Component with harness connected<br>(Cooler (Solar Sensor) Thermistor) |
|----|--|

(a) Remove the cooler (solar sensor) thermistor.

**HINT:**

[Click here](#)

(b) Connect the cooler (solar sensor) thermistor connector.

(c) Turn the power switch on (IG).

(d) Measure the voltage according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(G2\)](#)

[Click Connector\(G2\)](#)

| TESTER CONNECTION       | CONDITION                          | SPECIFIED CONDITION |
|-------------------------|------------------------------------|---------------------|
| G2-1 (SS+) - G2-2 (SS-) | Sensor subjected to electric light | 0.8 to 4.3 V        |
| G2-1 (SS+) - G2-2 (SS-) | Sensor covered with cloth          | Below 0.8 V         |

**NOTICE:**

- The connection procedure for using a digital tester such as a TOYOTA electrical tester is shown above. When using an analog tester, connect the negative (-) lead to terminal 1 and the positive (+) lead to terminal 2 of the cooler (solar sensor) thermistor.
- Do not bring the positive and negative tester probes too close to each other as a short circuit may occur.

**HINT:**

- Use an incandescent light for inspection. Bring it within about 30 cm (11.8 in.) of the cooler (solar sensor) thermistor.
- As the inspection light is moved away from the sensor, the voltage will decrease.

**OK** REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY

**NG** REPLACE COOLER (SOLAR SENSOR) THERMISTOR

|    |  |
|----|--|
| 4. | CHECK HARNESS AND CONNECTOR (AIR CONDITIONING AMPLIFIER ASSEMBLY - COOLER (SOLAR SENSOR) THERMISTOR) |
|----|--|

- (a) Disconnect the F57 air conditioning amplifier assembly connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(F57\)](#)

[Click Location & Routing\(G2\)](#)


[Click Connector\(F57\)](#)

[Click Connector\(G2\)](#)

| TESTER CONNECTION                         | CONDITION | SPECIFIED CONDITION     |
|---|-----------|-------------------------|
| F57-4 (S5 -1) - G2-1 (SS+)                | Always    | Below 1 $\Omega$        |
| F57-22 (TS) - G2-2 (SS-)                  | Always    | Below 1 $\Omega$        |
| F57-4 (S5 -1) or G2-1 (SS+) - Body ground | Always    | 10 k $\Omega$ or higher |
| F57-22 (TS) or G2-2 (SS-) - Body ground   | Always    | 10 k $\Omega$ or higher |

**OK** ► REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY

**NG** ► REPAIR OR REPLACE HARNESS OR CONNECTOR



|   |                     |                                      |
|---|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000RW4X       |
| <b>Model Year Start:</b> 2016   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B14A8,B14A9,B14AA; Glass Temperature Sensor Circuit; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

|            |              |   |
|------------|--------------|---|
| <b>DTC</b> | <b>B14A8</b> | <b>Glass Temperature Sensor Circuit</b> |
|------------|--------------|---|

|            |              |  |
|------------|--------------|--|
| <b>DTC</b> | <b>B14A9</b> | <b>Glass Surroundings Temperature Sensor Circuit</b> |
|------------|--------------|--|

|            |              |                                      |
|------------|--------------|--------------------------------------|
| <b>DTC</b> | <b>B14AA</b> | <b>Glass Humidity Sensor Circuit</b> |
|------------|--------------|--------------------------------------|

## DESCRIPTION


- B14A8: The air conditioning amplifier assembly detects the windshield glass surface temperature from this circuit. The air conditioning amplifier assembly applies voltage to the air conditioning thermistor assembly (glass temperature sensor). As the windshield glass surface temperature rises, the resistance decreases. The air conditioning amplifier assembly detects the change in resistance as the windshield glass surface temperature changes.
  - B14A9: The air conditioning amplifier assembly detects the temperature of the area near the windshield glass using this circuit. The air conditioning amplifier assembly applies voltage to the air conditioning thermistor assembly (glass surroundings temperature sensor). As the temperature of the area near the windshield glass rises, the resistance decreases. The air conditioning amplifier assembly detects the change in resistance as the windshield glass surroundings temperature changes.
  - B14AA: The air conditioning thermistor assembly (glass humidity sensor) detects cabin humidity. The voltage of the air conditioning thermistor assembly (glass humidity sensor) changes in accordance with cabin humidity. The air conditioning amplifier assembly reads the changes in output voltage of the air conditioning thermistor assembly (glass humidity sensor).
- The glass temperature sensor is integrated with the air conditioning thermistor assembly.

| DTC NO. | DETECTION ITEM                                | DTC DETECTION CONDITION  | TROUBLE AREA   | MEMORY                        |
|---------|---|--|--|-------------------------------|
| B14A8   | Glass Temperature Sensor Circuit              | Open or short in glass temperature sensor circuit              | Air conditioning thermistor assembly (glass temperature sensor)              | Memorized<br>(4 sec. or more) |
| B14A9   | Glass Surroundings Temperature Sensor Circuit | Open or short in glass surroundings temperature sensor circuit | Air conditioning thermistor assembly (glass surroundings temperature sensor) | Memorized<br>(4 sec. or more) |
| B14AA   | Glass Humidity Sensor Circuit                 | Open or short in glass humidity sensor circuit                 | Air conditioning thermistor assembly (glass humidity sensor)                 | Memorized<br>(4 sec. or more) |

\*: The air conditioning amplifier assembly stores this DTC if the malfunction has occurred for the period of time

indicated in the brackets.

## WIRING DIAGRAM



## CAUTION / NOTICE / HINT

### NOTICE:

Inspect the fuses for circuits related to this system before performing the following procedure.

### HINT:

The air conditioning thermistor assembly must be replaced if the glass temperature sensor is malfunctioning.

## PROCEDURE

|           |                      |
|-----------|----------------------|
| <b>1.</b> | <b>CHECK FOR DTC</b> |
|-----------|----------------------|

(a) Check for DTCs.

Click here [INFO](#)

**Body Electrical > Air Conditioner > Trouble Codes**


| RESULT              | PROCEED TO |
|---------------------|------------|
| DTC B1279 is output | A          |
| DTC B1373 is output | B          |
| DTC B14A8 is output | C          |
| DTC B14A9 is output |            |



**A** ► GO TO DTC B1279

**B** ► GO TO DTC B1373

**C** ► REPLACE AIR CONDITIONING THERMISTOR ASSEMBLY



|  |                     |                                      |
|--|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000RW51       |
| <b>Model Year Start:</b> 2016  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B14B2; Lost Communication with Front Panel LIN; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

|            |              |  |
|------------|--------------|--|
| <b>DTC</b> | <b>B14B2</b> | <b>Lost Communication with Front Panel LIN</b> |
|------------|--------------|--|

## DESCRIPTION


The air conditioning control assembly communicates with the air conditioning amplifier assembly via LIN communication.

If the LIN communication system malfunctions, the air conditioning amplifier assembly does not operate even if the air conditioning control assembly is operated.

| DTC NO. | DETECTION ITEM                          | DTC DETECTION CONDITION                                   | TROUBLE AREA   | MEMORY                          |
|---------|---|---|--|---------------------------------|
| B14B2   | Lost Communication with Front Panel LIN | Lost communication with air conditioning control assembly | <ul style="list-style-type: none"> <li>• Harness or connector between air conditioning control assembly and IG power source</li> <li>• Harness or connector between air conditioning control assembly and body ground</li> <li>• LIN communication system</li> <li>• Air conditioning control assembly</li> <li>• Air conditioning amplifier assembly</li> </ul> | Memorized<br>(10 sec. or more)* |

\*: The air conditioning amplifier assembly stores this DTC if the malfunction has occurred for the period of time indicated in the brackets.

## WIRING DIAGRAM



## CAUTION / NOTICE / HINT

### NOTICE:

Inspect the fuses for circuits related to this system before performing the following procedure.

## PROCEDURE

|           |  |
|-----------|--|
| <b>1.</b> | <b>CHECK HARNESS AND CONNECTOR (AIR CONDITIONING CONTROL ASSEMBLY - IG POWER SOURCE)</b> |
|-----------|--|

- (a) Disconnect the F52 air conditioning control assembly connector.
- (b) Measure the voltage according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(F52\)](#)

[Click Connector\(F52\)](#)

| TESTER CONNECTION         | CONDITION            | SPECIFIED CONDITION |
|---------------------------|----------------------|---------------------|
| F52-8 (IG+) - Body ground | Power switch on (IG) | 11 to 14 V          |
| F52-8 (IG+) - Body ground | Power switch off     | Below 1 V           |

**NG** **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK



|    |  |
|----|--|
| 2. | <b>CHECK HARNESS AND CONNECTOR (AIR CONDITIONING CONTROL ASSEMBLY - BODY GROUND)</b> |
|----|--|

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(F52\)](#)

[Click Connector\(F52\)](#)

| TESTER CONNECTION         | CONDITION | SPECIFIED CONDITION |
|---------------------------|-----------|---------------------|
| F52-1 (GND) - Body ground | Always    | Below 1 $\Omega$    |

**NG** REPAIR OR REPLACE HARNESS OR CONNECTOR

OK



|    |  |
|----|--|
| 3. | <b>CHECK HARNESS AND CONNECTOR (AIR CONDITIONING AMPLIFIER ASSEMBLY - AIR CONDITIONING CONTROL ASSEMBLY)</b> |
|----|--|

(a) Disconnect the F58 air conditioning amplifier assembly connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(F52,F58\)](#)

[Click Connector\(F52\)](#)

[Click Connector\(F58\)](#)

| TESTER CONNECTION                           | CONDITION | SPECIFIED CONDITION     |
|---|-----------|-------------------------|
| F52-6 (LIN1) - F58-14 (LIN1)                | Always    | Below 1 $\Omega$        |
| F52-6 (LIN1) or F58-14 (LIN1) - Body ground | Always    | 10 k $\Omega$ or higher |

**NG** REPAIR OR REPLACE HARNESS OR CONNECTOR

OK




**4. INSPECT AIR CONDITIONING AMPLIFIER ASSEMBLY**

- (a) Reconnect the F58 air conditioning amplifier assembly connector.
- (b) Turn the power switch on (IG).

(c) Connect an oscilloscope to terminals F58-14 (LIN1) and F58-4 (GND) of the air conditioning amplifier assembly and check the waveform.

OK:  
Waveform is similar to that shown in the illustration.

| ITEM              | CONTENT               |
|-------------------|-----------------------|
| Tool Setting      | 2 V/DIV., 20 ms./DIV. |
| Vehicle Condition | Power switch on (IG)  |



**NG** **REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY**

**OK**



**5. INSPECT AIR CONDITIONING CONTROL ASSEMBLY**

- (a) Reconnect the F52 air conditioning control assembly connector.
- (b) Turn the power switch on (IG).


(c) Connect an oscilloscope to terminals F52-6 (LIN1) and F52-1 (GND) of the air conditioning control assembly and

check the waveform.

OK:

Waveform is similar to that shown in the illustration.

| ITEM              | CONTENT               |
|-------------------|-----------------------|
| Tool Setting      | 2 V/DIV., 20 ms./DIV. |
| Vehicle Condition | Power switch on (IG)  |



|    |   |
|----|---|
| *a | Component with harness connected<br>(Air Conditioning Control Assembly) |
|----|---|

**OK** ► REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY

**NG** ► REPLACE AIR CONDITIONING CONTROL ASSEMBLY INFO

INFO INFO INFO



|   |                     |                                      |
|---|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000RW3U       |
| <b>Model Year Start:</b> 2016   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B14B8; Refrigerant Shortage; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

|            |              |                             |
|------------|--------------|-----------------------------|
| <b>DTC</b> | <b>B14B8</b> | <b>Refrigerant Shortage</b> |
|------------|--------------|-----------------------------|

## DESCRIPTION

This DTC is stored if the amount of refrigerant in the air conditioning system is insufficient.

The air conditioning amplifier assembly receives the ambient temperature signal, refrigerant pressure signal, etc. from various sensors.


Based on these signals, the air conditioning amplifier assembly detects the amount of refrigerant.

The A/C switch indicator is turned off and the air conditioning system is stopped if the amount of refrigerant is insufficient.

| DTC NO. | DETECTION ITEM       | DTC DETECTION CONDITION  | TROUBLE AREA   | MEMORY                              |
|---------|----------------------|--|--|-------------------------------------|
| B14B8   | Refrigerant Shortage | When following condition is detected in refrigerant shortage check in normal operation:<br><br>Amount of refrigerant is insufficient | <ul style="list-style-type: none"> <li>Refrigerant pipe line</li> <li>Cooler expansion valve</li> <li>Air conditioning amplifier assembly</li> </ul> | Memorized<br><br>(15 min. or more)* |

\*: The air conditioning amplifier assembly stores this DTC if the malfunction has occurred for the period of time indicated in the brackets.

## WIRING DIAGRAM



## PROCEDURE

## 1. CHECK REFRIGERANT PRESSURE

- (a) Connect the Techstream to the DLC3.
- (b) Turn the power switch on (IG).
- (c) Turn the Techstream on.
- (d) Enter the following menus: Body Electrical / Air Conditioner / Data List.
- (e) Read the Data List according to the display on the Techstream.

### Body Electrical > Air Conditioner > Data List

| TESTER DISPLAY            | MEASUREMENT ITEM                | RANGE  | NORMAL CONDITION                      | DIAGNOSTIC NOTE |
|---------------------------|---------------------------------|--|---------------------------------------|-----------------|
| Regulator Pressure Sensor | Air conditioner pressure sensor | Min.: -456.6<br>kPaG<br>Max.: 3294.3<br>kPaG | Actual refrigerant pressure displayed | -               |

### Body Electrical > Air Conditioner > Data List

| TESTER DISPLAY            |
|---------------------------|
| Regulator Pressure Sensor |

- (f) Install a manifold gauge set.


Click here [INFO](#)

- (g) Read the manifold gauge pressure when the following conditions are met.

(1) Prepare the vehicle according to the table below.

#### Measurement Condition:

| ITEM                       | CONDITION               |
|----------------------------|-------------------------|
| Vehicle doors              | Fully open              |
| Temperature setting        | MAX COLD                |
| Blower speed               | HI                      |
| A/C switch                 | On                      |
| Recirculation/fresh switch | RECIRCULATION           |
| Interior temperature       | 25 to 35°C (77 to 95°F) |



Standard Pressure:



*Low pressure side*

150 to 250 kPa (1.5 to 2.5 kgf/cm<sup>2</sup>, 22 to 36 psi)

*High pressure side*

1370 to 1570 kPa (14 to 16 kgf/cm<sup>2</sup>, 199 to 228 psi)

(h) Compare the values displayed in the Data List and on the manifold gauge.

OK:

The values displayed in the Data List and on the manifold gauge match.

**OK**  **CHECK REFRIGERANT PRESSURE**

**NG**



**2. CHECK HARNESS AND CONNECTOR (POWER SOURCE CIRCUIT)**

(a) Disconnect the A29 air conditioner pressure sensor connector.

(b) Measure the voltage according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(A29\)](#)

[Click Connector\(A29\)](#)

| TESTER CONNECTION     | CONDITION            | SPECIFIED CONDITION |
|-----------------------|----------------------|---------------------|
| A29-3 (+) - A29-1 (-) | Power switch on (IG) | 4.75 to 5.25 V      |

**NG**  **GO TO STEP 7**

**OK**



**3. CHECK HARNESS AND CONNECTOR (AIR CONDITIONER PRESSURE SENSOR - BODY GROUND)**

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A29\)](#)

[Click Connector\(A29\)](#)

| TESTER CONNECTION       | CONDITION | SPECIFIED CONDITION |
|-------------------------|-----------|---------------------|
| A29-1 (-) - Body ground | Always    | Below 1 $\Omega$    |

**NG**  **GO TO STEP 6**

**OK**



|           |  |
|-----------|--|
| <b>4.</b> | <b>CHECK HARNESS AND CONNECTOR (AIR CONDITIONING AMPLIFIER ASSEMBLY - AIR CONDITIONER PRESSURE SENSOR)</b> |
|-----------|--|

- (a) Disconnect the F57 air conditioning amplifier assembly connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A29\)](#)

[Click Location & Routing\(F57\)](#)

[Click Connector\(A29\)](#)

[Click Connector\(F57\)](#)

| TESTER CONNECTION                        | CONDITION | SPECIFIED CONDITION     |
|--|-----------|-------------------------|
| A29-2 (PR) - F57-24 (PRE)                | Always    | Below 1 $\Omega$        |
| A29-2 (PR) or F57-24 (PRE) - Body ground | Always    | 10 k $\Omega$ or higher |

**NG**  **REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**



|           |  |
|-----------|--|
| <b>5.</b> | <b>INSPECT AIR CONDITIONER PRESSURE SENSOR (SENSOR SIGNAL CIRCUIT)</b> |
|-----------|--|

- (a) Measure the voltage when the following conditions are met.

**Measurement Condition:**

| ITEM                | CONDITION  |
|---------------------|------------|
| Vehicle doors       | Fully open |
| Temperature setting | MAX COLD   |

|                            |                         |
|----------------------------|-------------------------|
| Blower speed               | HI                      |
| A/C switch                 | On                      |
| Recirculation/fresh switch | RECIRCULATION           |
| Interior temperature       | 25 to 35°C (77 to 95°F) |

**NOTICE:**

- If refrigerant pressure on the high pressure side becomes extremely high during the inspection (if the voltage exceeds 4.61 V), the fail-safe function stops compressor operation. Therefore, measure the voltage before the fail-safe operation.
- It is necessary to measure the voltage for a certain amount of time (approximately 10 minutes) because the malfunction may recur after a while.

**HINT:**

When the outside air temperature is low (below -1.5°C (29.3°F)), the compressor stops due to operation of the thermistor assembly and the No. 1 cooler thermistor to prevent the evaporator from freezing. In this case, perform the inspection in a warm indoor environment.

(1) Measure the voltage according to the value(s) in the table below.


Standard Voltage:



[Click Location & Routing\(F57\)](#)

[Click Connector\(F57\)](#)

| TESTER CONNECTION          | CONDITION                                | SPECIFIED CONDITION |
|----------------------------|--|---------------------|
| F57-24 (PRE) - Body ground | Power switch on (IG)<br>(A/C switch: On) | 0.74 to 4.61 V      |



|    |   |
|----|---|
| *a | Component with harness connected<br>(Air Conditioning Amplifier Assembly) |
|----|---|

- (b) Connect the Techstream to the DLC3.
- (c) Turn the power switch on (IG).
- (d) Turn the Techstream on.
- (e) Enter the following menus: Body Electrical / Air Conditioner / Data List.
- (f) Read the Data List according to the display on the Techstream.

**Body Electrical > Air Conditioner > Data List**

| TESTER DISPLAY            | MEASUREMENT ITEM                | RANGE                                  | NORMAL CONDITION                      | DIAGNOSTIC NOTE |
|---------------------------|---------------------------------|--|---------------------------------------|-----------------|
| Regulator Pressure Sensor | Air conditioner pressure sensor | Min.: -456.6 kPaG<br>Max.: 3294.3 kPaG | Actual refrigerant pressure displayed | -               |

Body Electrical > Air Conditioner > Data List

|                           |
|---------------------------|
| TESTER DISPLAY            |
| Regulator Pressure Sensor |

OK:  
The voltage and value displayed in the Data List change.

| RESULT   | PROCEED TO |
|--|------------|
| OK   | A          |
| NG (The voltage changes but the value displayed in the Data List does not change.) |            |
| NG (The voltage does not change.)  | B          |

**A** ► REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY

**B** ► REPLACE AIR CONDITIONER PRESSURE SENSOR

|    |  |
|----|--|
| 6. | <b>CHECK HARNESS AND CONNECTOR (AIR CONDITIONING AMPLIFIER ASSEMBLY - AIR CONDITIONER PRESSURE SENSOR)</b> |
|----|--|

- (a) Disconnect the F57 air conditioning amplifier assembly connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A29\)](#)

[Click Location & Routing\(F57\)](#)

[Click Connector\(A29\)](#)

[Click Connector\(F57\)](#)

| TESTER CONNECTION                       | CONDITION | SPECIFIED CONDITION |
|---|-----------|---------------------|
| A29-1 (-) - F57-2 (SG-2)                | Always    | Below 1 Ω           |
| A29-1 (-) or F57-2 (SG-2) - Body ground | Always    | 10 kΩ or higher     |

**OK** ► REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY

**NG** ► REPAIR OR REPLACE HARNESS OR CONNECTOR

|   |
|---|
| <b>CHECK HARNESS AND CONNECTOR (AIR CONDITIONING AMPLIFIER ASSEMBLY - AIR</b> |
|---|

7.

**CONDITIONER PRESSURE SENSOR)**

- (a) Disconnect the F57 air conditioning amplifier assembly connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A29\)](#)

[Click Location & Routing\(F57\)](#)


[Click Connector\(A29\)](#)

[Click Connector\(F57\)](#)

| TESTER CONNECTION                        | CONDITION | SPECIFIED CONDITION     |
|--|-----------|-------------------------|
| A29-3 (+) - F57-6 (S5 -3)                | Always    | Below 1 $\Omega$        |
| A29-3 (+) or F57-6 (S5 -3) - Body ground | Always    | 10 k $\Omega$ or higher |

**OK** ► REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY

**NG** ► REPAIR OR REPLACE HARNESS OR CONNECTOR



|   |                     |  |
|---|---------------------|--|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000T6LT           |
| <b>Model Year Start:</b> 2016   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 -     ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B1245; Lost Communication with Wiper ECU LIN;<br>2016 - 2019 MY Prius [11/2015 -     ] |                     |  |

|            |              |  |
|------------|--------------|--|
| <b>DTC</b> | <b>B1245</b> | <b>Lost Communication with Wiper ECU LIN</b> |
|------------|--------------|--|

## DESCRIPTION


The air conditioning amplifier assembly and windshield wiper relay assembly communicate via LIN communication.

The air conditioning amplifier assembly stores this DTC if communication becomes abnormal.

| DTC NO. | DETECTION ITEM                        | DTC DETECTION CONDITION                                 | TROUBLE AREA  | MEMORY                              |
|---------|---------------------------------------|---|---|-------------------------------------|
| B1245   | Lost Communication with Wiper ECU LIN | Lost communication with windshield wiper relay assembly | <ul style="list-style-type: none"> <li>• Harness or connector between windshield wiper relay assembly and IG power source</li> <li>• Harness or connector between windshield wiper relay assembly and body ground</li> <li>• LIN communication system</li> <li>• Windshield wiper relay assembly</li> </ul> | Memorized<br><br>(10 sec. or more)* |

\*: The air conditioning amplifier assembly stores this DTC if the malfunction has occurred for the period of time indicated in the brackets.

## WIRING DIAGRAM



## CAUTION / NOTICE / HINT

### NOTICE:

Inspect the fuses for circuits related to this system before performing the following procedure.

## PROCEDURE

### 1. CHECK FOR DTC

(a) Check for DTCs.

Click here [INFO](#)

**Body Electrical > Air Conditioner > Trouble Codes**

| RESULT                  | PROCEED TO |
|-------------------------|------------|
| DTC B1373 is output     | A          |
| DTC B1373 is not output | B          |

**A**  **GO TO DTC B1373**

**B**



### 2. CHECK HARNESS AND CONNECTOR (WINDSHIELD WIPER RELAY ASSEMBLY - IG POWER SOURCE)

(a) Disconnect the F43 windshield wiper relay assembly connector.

(b) Measure the voltage according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(F43\)](#)

[Click Connector\(F43\)](#)

| TESTER CONNECTION          | CONDITION            | SPECIFIED CONDITION |
|----------------------------|----------------------|---------------------|
| F43-16 (WIG) - Body ground | Power switch on (IG) | 11 to 14 V          |
| F43-16 (WIG) - Body ground | Power switch off     | Below 1 V           |

OK



|    |  |
|----|--|
| 3. | <b>CHECK HARNESS AND CONNECTOR (WINDSHIELD WIPER RELAY ASSEMBLY - BODY GROUND)</b> |
|----|--|

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(F43\)](#)

[Click Connector\(F43\)](#)

| TESTER CONNECTION        | CONDITION | SPECIFIED CONDITION |
|--------------------------|-----------|---------------------|
| F43-12 (E) - Body ground | Always    | Below 1 $\Omega$    |

OK



|    |  |
|----|--|
| 4. | <b>CHECK HARNESS AND CONNECTOR (AIR CONDITIONING AMPLIFIER ASSEMBLY - WINDSHIELD WIPER RELAY ASSEMBLY)</b> |
|----|--|

(a) Disconnect the F58 air conditioning amplifier assembly connector.

(b) Disconnect the O1 air conditioning thermistor assembly connector.

(c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(F43,F58\)](#)

[Click Connector\(F43\)](#)

[Click Connector\(F58\)](#)

| TESTER CONNECTION                            | CONDITION | SPECIFIED CONDITION     |
|--|-----------|-------------------------|
| F43-14 (MPX1) - F58-15 (SCLI)                | Always    | Below 1 $\Omega$        |
| F43-14 (MPX1) or F58-15 (SCLI) - Body ground | Always    | 10 k $\Omega$ or higher |




**OK** ▶ REPLACE WINDSHIELD WIPER RELAY ASSEMBLY

INFO

INFO

**NG** ▶ REPAIR OR REPLACE HARNESS OR CONNECTOR



|   |                     |                                      |
|---|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000T6MY       |
| <b>Model Year Start:</b> 2016   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B1279; Lost Communication with Humidity/Rain Sensor LIN; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

|            |              |   |
|------------|--------------|---|
| <b>DTC</b> | <b>B1279</b> | <b>Lost Communication with Humidity/Rain Sensor LIN</b> |
|------------|--------------|---|

## **DESCRIPTION**


The air conditioning amplifier assembly and air conditioning thermistor assembly communicate via LIN communication.

The air conditioning amplifier assembly stores this DTC if communication becomes abnormal.

| DTC NO. | DETECTION ITEM                                   | DTC DETECTION CONDITION                                      | TROUBLE AREA  | MEMORY                              |
|---------|--|--|---|-------------------------------------|
| B1279   | Lost Communication with Humidity/Rain Sensor LIN | Lost communication with air conditioning thermistor assembly | <ul style="list-style-type: none"> <li>● Harness or connector between air conditioning thermistor assembly and IG power source</li> <li>● Harness or connector between air conditioning thermistor assembly and body ground</li> <li>● LIN communication system</li> <li>● Air conditioning amplifier assembly</li> <li>● Air conditioning thermistor assembly</li> </ul> | Memorized<br><br>(10 sec. or more)* |

\*: The air conditioning amplifier assembly stores this DTC if the malfunction has occurred for the period of time indicated in the brackets.

## **WIRING DIAGRAM**



## CAUTION / NOTICE / HINT

### NOTICE:

Inspect the fuses for circuits related to this system before performing the following procedure.

### HINT:

The air conditioning thermistor assembly must be replaced if the glass temperature sensor is malfunctioning.

## PROCEDURE

|           |                      |
|-----------|----------------------|
| <b>1.</b> | <b>CHECK FOR DTC</b> |
|-----------|----------------------|

(a) Check for DTCs.

**Body Electrical > Air Conditioner > Trouble Codes**

| RESULT              | PROCEED TO |
|---------------------|------------|
| B1373 is not output | A          |
| B1373 is output     | B          |

**B** GO TO DTC B1373

**A**



2.

**CHECK HARNESS AND CONNECTOR (AIR CONDITIONING THERMISTOR ASSEMBLY - IG POWER SOURCE)**

(a) Disconnect the O1 air conditioning thermistor assembly connector.

(b) Measure the voltage according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(O1\)](#)

[Click Connector\(O1\)](#)

| TESTER CONNECTION        | CONDITION            | SPECIFIED CONDITION |
|--------------------------|----------------------|---------------------|
| O1-4 (SIG) - Body ground | Power switch on (IG) | 11 to 14 V          |
| O1-4 (SIG) - Body ground | Power switch off     | Below 1 V           |

**NG** **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK



3.

**CHECK HARNESS AND CONNECTOR (AIR CONDITIONING THERMISTOR ASSEMBLY - BODY GROUND)**

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(O1\)](#)

[Click Connector\(O1\)](#)

| TESTER CONNECTION       | CONDITION | SPECIFIED CONDITION |
|-------------------------|-----------|---------------------|
| O1-2 (ES) - Body ground | Always    | Below 1 Ω           |

**NG** **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK



4.

**CHECK HARNESS AND CONNECTOR (AIR CONDITIONING AMPLIFIER ASSEMBLY - AIR CONDITIONING THERMISTOR ASSEMBLY)**

- (a) Disconnect the F58 air conditioning amplifier assembly connector.
- (b) Disconnect the F43 windshield wiper relay assembly connector.
- (c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(O1\)](#)

[Click Location & Routing\(F58\)](#)


[Click Connector\(O1\)](#)

[Click Connector\(F58\)](#)

| TESTER CONNECTION                         | CONDITION | SPECIFIED CONDITION     |
|---|-----------|-------------------------|
| O1-3 (MPX) - F58-15 (SCLI)                | Always    | Below 1 $\Omega$        |
| O1-3 (MPX) or F58-15 (SCLI) - Body ground | Always    | 10 k $\Omega$ or higher |

**OK** ► REPLACE AIR CONDITIONING THERMISTOR ASSEMBLY

**NG** ► REPAIR OR REPLACE HARNESS OR CONNECTOR



|   |                     |                                      |
|---|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000T6N1       |
| <b>Model Year Start:</b> 2016   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B1373; Lost Communication with Wiper System LIN BUS; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

|            |              |   |
|------------|--------------|---|
| <b>DTC</b> | <b>B1373</b> | <b>Lost Communication with Wiper System LIN BUS</b> |
|------------|--------------|---|

## DESCRIPTION


The air conditioning amplifier assembly communicates with the windshield wiper relay assembly, windshield wiper relay assembly and air conditioning thermistor assembly via LIN communication.

If a malfunction occurs in the LIN communication line and a communication error occurs, this DTC is stored.

| DTC NO. | DETECTION ITEM                               | DTC DETECTION CONDITION                                     | TROUBLE AREA   | MEMORY                             |
|---------|--|---|--|------------------------------------|
| B1373   | Lost Communication with Wiper System LIN BUS | Lost communication with wiper system LIN communication line | <ul style="list-style-type: none"> <li>• LIN communication system</li> <li>• Air conditioning amplifier assembly</li> <li>• Windshield wiper relay assembly</li> <li>• Air conditioning thermistor assembly</li> </ul> | Memorized<br><br>(7 sec. or more)* |

\*: The air conditioning amplifier assembly stores this DTC if the malfunction has occurred for the period of time indicated in the brackets.

## WIRING DIAGRAM



## CAUTION / NOTICE / HINT

### HINT:

The air conditioning thermistor assembly must be replaced if the glass temperature sensor is malfunctioning.

## PROCEDURE

1.

**CHECK HARNESS AND CONNECTOR (AIR CONDITIONING AMPLIFIER ASSEMBLY - AIR CONDITIONING THERMISTOR ASSEMBLY, WINDSHIELD WIPER RELAY ASSEMBLY)**

- Disconnect the F58 air conditioning amplifier assembly connector.
- Disconnect the O1 air conditioning thermistor assembly connector.
- Disconnect the F43 windshield wiper relay assembly connector.
- Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(F58\)](#)

[Click Location & Routing\(O1\)](#)

[Click Connector\(F58\)](#)

[Click Connector\(O1\)](#)

| TESTER CONNECTION                         | CONDITION | SPECIFIED CONDITION     |
|---|-----------|-------------------------|
| F58-15 (SCLI) - O1-3 (MPX)                | Always    | Below 1 $\Omega$        |
| F58-15 (SCLI) or O1-3 (MPX) - Body ground | Always    | 10 k $\Omega$ or higher |

**OK**



|           |                      |
|-----------|----------------------|
| <b>2.</b> | <b>CHECK FOR DTC</b> |
|-----------|----------------------|

- (a) Connect the F58 air conditioning amplifier assembly connector.
- (b) Connect the O1 air conditioning thermistor assembly connector.
- (c) Check for DTCs.

**Body Electrical > Air Conditioner > Trouble Codes**

| RESULT              | PROCEED TO |
|---------------------|------------|
| B1373 is not output | A          |
| B1373 is output     | B          |

**B**



|           |                      |
|-----------|----------------------|
| <b>3.</b> | <b>CHECK FOR DTC</b> |
|-----------|----------------------|

- (a) Connect the F43 windshield wiper relay assembly connector.
- (b) Disconnect the O1 air conditioning thermistor assembly connector.
- (c) Check for DTCs.

**Body Electrical > Air Conditioner > Trouble Codes**

| RESULT              | PROCEED TO |
|---------------------|------------|
| B1373 is not output | A          |
| B1373 is output     | B          |



**A** ▶ REPLACE AIR CONDITIONING THERMISTOR ASSEMBLY

**B** ▶ REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY



|   |                     |                                      |
|---|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000RW3Y       |
| <b>Model Year Start:</b> 2016   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B1411/11; Room Temperature Sensor Circuit; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

|            |                 |  |
|------------|-----------------|--|
| <b>DTC</b> | <b>B1411/11</b> | <b>Room Temperature Sensor Circuit</b> |
|------------|-----------------|--|

## DESCRIPTION

The cooler (room temp. sensor) thermistor is installed in the instrument panel to detect the cabin temperature, which is used to control the air conditioning system. The resistance of the cooler (room temp. sensor) thermistor changes in accordance with the cabin temperature. As the temperature decreases, the resistance increases. As the temperature increases, the resistance decreases.

The air conditioning amplifier assembly applies voltage (5 V) to the cooler (room temp. sensor) thermistor and reads voltage changes due to changes in the resistance of the cooler (room temp. sensor) thermistor.


| DTC NO.  | DETECTION ITEM                  | DTC DETECTION CONDITION                          | TROUBLE AREA   | MEMORY                      |
|----------|---------------------------------|--|--|-----------------------------|
| B1411/11 | Room Temperature Sensor Circuit | Open or short in room temperature sensor circuit | <ul style="list-style-type: none"> <li>Cooler (room temp. sensor) thermistor</li> <li>Harness or connector between cooler (room temp. sensor) thermistor and air conditioning amplifier assembly</li> <li>Air conditioning amplifier assembly</li> </ul> | Memorized (4 sec. or more)* |

\*: The air conditioning amplifier assembly stores this DTC if the malfunction has occurred for the period of time indicated in the brackets.

### HINT:

If the cabin temperature is approximately  $-18.6^{\circ}\text{C}$  ( $-1.48^{\circ}\text{F}$ ) or lower, DTC B1411/11 may be output even though the system is normal.

## WIRING DIAGRAM



# PROCEDURE

|           |                                    |
|-----------|------------------------------------|
| <b>1.</b> | <b>READ VALUE USING TECHSTREAM</b> |
|-----------|------------------------------------|

- (a) Connect the Techstream to the DLC3.
- (b) Turn the power switch on (IG).
- (c) Turn the Techstream on.
- (d) Enter the following menus: Body Electrical / Air Conditioner / Data List.
- (e) Read the Data List according to the display on the Techstream.

**Body Electrical > Air Conditioner > Data List**

| TESTER DISPLAY          | MEASUREMENT ITEM                      | RANGE   | NORMAL CONDITION                   | DIAGNOSTIC NOTE |
|-------------------------|---------------------------------------|---|------------------------------------|-----------------|
| Room Temperature Sensor | Cooler (room temp. sensor) thermistor | Min.: -6.50°C<br>(20.30°F)<br><br>Max.: 57.25°C<br>(135.05°F) | Actual cabin temperature displayed | -               |

**Body Electrical > Air Conditioner > Data List**

| TESTER DISPLAY          |
|-------------------------|
| Room Temperature Sensor |

OK:  
The display is as specified in the normal condition column.

| Result  | PROCEED TO |
|---|------------|
| NG  | A          |
| OK (When troubleshooting according to Problem Symptoms Table) | B          |
| OK (When troubleshooting according to the DTC)                | C          |


**B** ▶ **PROCEED TO NEXT SUSPECTED AREA SHOWN IN PROBLEM SYMPTOMS TABLE** INFO INFO INFO INFO

**C** ▶ **REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY**

2. INSPECT COOLER (ROOM TEMP. SENSOR) THERMISTOR

(a) Remove the cooler (room temp. sensor) thermistor.

Click here [NFC](#) [NFC](#)



|    |   |
|----|---|
| *a | Component without harness connected (Cooler (Room Temp. Sensor) Thermistor) |
| *b | Sensing Portion   |
| *c | Resistance (kΩ)   |
| *d | Temperature (°C (°F))   |
| *e | Allowable Range   |

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

| TESTER CONNECTION | CONDITION   | SPECIFIED CONDITION |
|-------------------|-------------|---------------------|
|                   | 10°C (50°F) | 3.00 to 3.73 kΩ     |
|                   | 15°C (59°F) | 2.45 to 2.88 kΩ     |

|       |              |                 |
|-------|--------------|-----------------|
| 1 - 2 | 20°C (68°F)  | 1.95 to 2.30 kΩ |
|       | 25°C (77°F)  | 1.60 to 1.80 kΩ |
|       | 30°C (86°F)  | 1.28 to 1.47 kΩ |
|       | 35°C (95°F)  | 1.00 to 1.22 kΩ |
|       | 40°C (104°F) | 0.80 to 1.00 kΩ |
|       | 45°C (113°F) | 0.65 to 0.85 kΩ |
|       | 50°C (122°F) | 0.50 to 0.70 kΩ |
|       | 55°C (131°F) | 0.44 to 0.60 kΩ |
|       | 60°C (140°F) | 0.36 to 0.50 kΩ |

**NOTICE:**

- Hold the sensor only by its connector. Touching the sensing portion may change the resistance value.
- When measuring, the sensor temperature must be the same as the ambient temperature.

**HINT:**

As the temperature increases, the resistance decreases (see the graph).

**NG**  **REPLACE COOLER (ROOM TEMP. SENSOR) THERMISTOR**  
 

**OK**  


|           |  |
|-----------|--|
| <b>3.</b> | <b>CHECK HARNESS AND CONNECTOR (COOLER (ROOM TEMP. SENSOR) THERMISTOR - AIR CONDITIONING AMPLIFIER ASSEMBLY)</b> |
|-----------|--|

(a) Disconnect the F57 air conditioning amplifier assembly connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(F57,F51\)](#)


[Click Connector\(F57\)](#)

[Click Connector\(F51\)](#)

| TESTER CONNECTION                   | CONDITION | SPECIFIED CONDITION |
|-------------------------------------|-----------|---------------------|
| F57-14 (TR) - F51-1                 | Always    | Below 1 Ω           |
| F57-1 (SG-1) - F51-2                | Always    | Below 1 Ω           |
| F57-14 (TR) or F51-1 - Body ground  | Always    | 10 kΩ or higher     |
| F57-1 (SG-1) or F51-2 - Body ground | Always    | 10 kΩ or higher     |

**OK** ▶ REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY

**NG** ▶ REPAIR OR REPLACE HARNESS OR CONNECTOR



|  |                     |                                      |
|--|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000RW3W       |
| <b>Model Year Start:</b> 2016  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B1412/12; Ambient Temperature Sensor Circuit; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

|            |                 |   |
|------------|-----------------|---|
| <b>DTC</b> | <b>B1412/12</b> | <b>Ambient Temperature Sensor Circuit</b> |
|------------|-----------------|---|

## DESCRIPTION

The thermistor assembly is installed in front of the cooler condenser assembly to detect the ambient temperature, which is used to control the air conditioning system. This sensor is connected to the air conditioning amplifier assembly and detects fluctuations in the ambient temperature. This data is used for controlling the cabin temperature. The sensor sends a signal to the air conditioning amplifier assembly. The resistance of the thermistor assembly changes in accordance with the ambient temperature. As the temperature decreases, the resistance increases. As the temperature increases, the resistance decreases.

The air conditioning amplifier assembly applies voltage (5 V) to the thermistor assembly and reads voltage changes due to changes in the resistance of the thermistor assembly.


| DTC NO.  | DETECTION ITEM                     | DTC DETECTION CONDITION                             | TROUBLE AREA   | MEMORY                      |
|----------|------------------------------------|---|--|-----------------------------|
| B1412/12 | Ambient Temperature Sensor Circuit | Open or short in ambient temperature sensor circuit | <ul style="list-style-type: none"> <li>• Thermistor assembly</li> <li>• Harness or connector between thermistor assembly and air conditioning amplifier assembly</li> <li>• Air conditioning amplifier assembly</li> </ul> | Memorized (4 sec. or more)* |

\*: The air conditioning amplifier assembly stores this DTC if the malfunction has occurred for the period of time indicated in the brackets.

### **HINT:**

If the ambient temperature is approximately -52.9°C (-63.22°F) or lower, DTC B1412/12 may be output even though the system is normal.

## WIRING DIAGRAM



## PROCEDURE

### 1. READ VALUE USING TECHSTREAM

- (a) Connect the Techstream to the DLC3.
- (b) Turn the power switch on (IG).
- (c) Turn the Techstream on.
- (d) Enter the following menus: Body Electrical / Air Conditioner / Data List.
- (e) Read the Data List according to the display on the Techstream.

#### Body Electrical > Air Conditioner > Data List

| TESTER DISPLAY      | MEASUREMENT ITEM    | RANGE  | NORMAL CONDITION                     | DIAGNOSTIC NOTE |
|---------------------|---------------------|--|--------------------------------------|-----------------|
| Ambient Temp Sensor | Thermistor assembly | Min.: -23.30°C<br>(-9.94°F)<br>Max.: 65.95°C<br>(150.71°F) | Actual ambient temperature displayed | -               |

#### Body Electrical > Air Conditioner > Data List

| TESTER DISPLAY      |
|---------------------|
| Ambient Temp Sensor |

OK:

The display is as specified in the normal condition column.

**OK** ▶ REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY






**2. INSPECT THERMISTOR ASSEMBLY**

(a) Remove the thermistor assembly.

Click here [NFC](#)



|    |   |
|----|---|
| *a | Component without harness connected (Thermistor Assembly) |
| *b | Sensing Portion   |
| *c | Resistance (kΩ)   |
| *d | Temperature (°C (°F))                                     |
| *e | Allowable Range   |

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

| TESTER CONNECTION | CONDITION   | SPECIFIED CONDITION |
|-------------------|-------------|---------------------|
|                   | 10°C (50°F) | 3.00 to 3.73 kΩ     |
|                   | 15°C (59°F) | 2.45 to 2.88 kΩ     |
|                   | 20°C (68°F) | 1.95 to 2.30 kΩ     |

|       |              |                 |
|-------|--------------|-----------------|
| 1 - 2 | 25°C (77°F)  | 1.60 to 1.80 kΩ |
|       | 30°C (86°F)  | 1.28 to 1.47 kΩ |
|       | 35°C (95°F)  | 1.00 to 1.22 kΩ |
|       | 40°C (104°F) | 0.80 to 1.00 kΩ |
|       | 45°C (113°F) | 0.65 to 0.85 kΩ |
|       | 50°C (122°F) | 0.50 to 0.70 kΩ |
|       | 55°C (131°F) | 0.44 to 0.60 kΩ |
|       | 60°C (140°F) | 0.36 to 0.50 kΩ |

**NOTICE:**

- Hold the sensor only by its connector. Touching the sensing portion may change the resistance value.
- When measuring, the sensor temperature must be the same as the ambient temperature.

**HINT:**

As the temperature increases, the resistance decreases (see the graph).

**NG**  **REPLACE THERMISTOR ASSEMBLY**

**OK**



|           |  |
|-----------|--|
| <b>3.</b> | <b>CHECK HARNESS AND CONNECTOR (THERMISTOR ASSEMBLY - AIR CONDITIONING AMPLIFIER ASSEMBLY)</b> |
|-----------|--|

(a) Disconnect the F57 air conditioning amplifier assembly connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(F57\)](#)

[Click Location & Routing\(A4\)](#)


[Click Connector\(F57\)](#)

[Click Connector\(A4\)](#)

| TESTER CONNECTION                  | CONDITION | SPECIFIED CONDITION |
|------------------------------------|-----------|---------------------|
| F57-13 (TAM) - A4-1                | Always    | Below 1 Ω           |
| F57-2 (SG-2) - A4-2                | Always    | Below 1 Ω           |
| F57-13 (TAM) or A4-1 - Body ground | Always    | 10 kΩ or higher     |
| F57-2 (SG-2) or A4-2 - Body ground | Always    | 10 kΩ or higher     |

**OK**  **REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY**

**NG**  **REPAIR OR REPLACE HARNESS OR CONNECTOR**



|  |                     |                                      |
|--|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM10000001FYIP        |
| <b>Model Year Start:</b> 2019  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [12/2018 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B1413/13; Evaporator Temperature Sensor Circuit; 2019 MY Prius [12/2018 - ] |                     |                                      |

|            |                 |  |
|------------|-----------------|--|
| <b>DTC</b> | <b>B1413/13</b> | <b>Evaporator Temperature Sensor Circuit</b> |
|------------|-----------------|--|

## DESCRIPTION


The No. 1 cooler thermistor is installed to the evaporator in the air conditioner unit to detect the temperature of the cooled air that has passed through the evaporator, which is used to control the air conditioning system. It sends signals to the air conditioning amplifier assembly. The resistance of the No. 1 cooler thermistor changes in accordance with the temperature of the cooled air that has passed through the evaporator. As the temperature decreases, the resistance increases. As the temperature increases, the resistance decreases.

The air conditioning amplifier assembly applies voltage (5 V) to the No. 1 cooler thermistor and reads voltage changes as the resistance of the No. 1 cooler thermistor changes. This sensor is used for frost prevention.

| DTC NO.  | DETECTION ITEM                        | DTC DETECTION CONDITION                                | TROUBLE AREA  | MEMORY                         |
|----------|---------------------------------------|--|---|--------------------------------|
| B1413/13 | Evaporator Temperature Sensor Circuit | Open or short in evaporator temperature sensor circuit | <ul style="list-style-type: none"> <li>No. 1 cooler thermistor</li> <li>Air conditioning harness assembly</li> <li>Air conditioning amplifier assembly</li> </ul> | Memorized<br>(4 sec. or more)* |

\*: The air conditioning amplifier assembly stores this DTC if the malfunction has occurred for the period of time indicated in the brackets.

## WIRING DIAGRAM



## PROCEDURE

**1. READ VALUE USING TECHSTREAM**

- (a) Connect the Techstream to the DLC3.
- (b) Turn the power switch on (IG).
- (c) Turn the Techstream on.
- (d) Enter the following menus: Body Electrical / Air Conditioner / Data List.
- (e) Read the Data List according to the display on the Techstream.

**Body Electrical > Air Conditioner > Data List**

| TESTER DISPLAY            | MEASUREMENT ITEM        | RANGE   | NORMAL CONDITION                        | DIAGNOSTIC NOTE |
|---------------------------|-------------------------|---|---|-----------------|
| Evaporator Fin Thermistor | No. 1 cooler thermistor | Min.: -29.70°C<br>(-21.46°F)<br><br>Max.: 59.55°C<br>(139.19°F) | Actual evaporator temperature displayed | -               |

**Body Electrical > Air Conditioner > Data List**

| TESTER DISPLAY            |
|---------------------------|
| Evaporator Fin Thermistor |

OK:  
The display is as specified in the normal condition column.

| RESULT  | PROCEED TO |
|---|------------|
| NG  | A          |
| OK (When troubleshooting according to Problem Symptoms Table) | B          |
| OK (When troubleshooting according to the DTC)                | C          |

**B** ▶ PROCEED TO NEXT SUSPECTED AREA SHOWN IN PROBLEM SYMPTOMS TABLE

**C** ▶ REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY




## 2. INSPECT NO. 1 COOLER THERMISTOR

(a) Remove the No. 1 cooler thermistor.

Click here [INFO](#)

(b) Measure the resistance according to the value(s) in the table below.



|    |  |    |                       |
|----|--|----|-----------------------|
| *a | Component without harness connected<br>(No. 1 Cooler Thermistor) | *b | Sensing Portion       |
| *c | Resistance (kΩ)  | *d | Temperature (°C (°F)) |
| *e | Allowable Range  | -  | -                     |

Standard Resistance:

| TESTER CONNECTION | CONDITION    | SPECIFIED CONDITION |
|-------------------|--------------|---------------------|
| 1 - 2             | -10°C (14°F) | 7.30 to 9.10 kΩ     |
|                   | -5°C (23°F)  | 5.65 to 6.95 kΩ     |
|                   | 0°C (32°F)   | 4.40 to 5.35 kΩ     |
|                   | 5°C (41°F)   | 3.40 to 4.15 kΩ     |
|                   | 10°C (50°F)  | 2.70 to 3.25 kΩ     |
|                   | 15°C (59°F)  | 2.14 to 2.58 kΩ     |
|                   | 20°C (68°F)  | 1.71 to 2.05 kΩ     |
|                   | 25°C (77°F)  | 1.38 to 1.64 kΩ     |
|                   | 30°C (86°F)  | 1.11 to 1.32 kΩ     |

### NOTICE:

- Hold the sensor only by its connector. Touching the sensing portion may change the resistance value.
- When measuring, the sensor temperature must be the same as the ambient temperature.

### HINT:

As the temperature increases, the resistance decreases (see the graph).

**NG**  **REPLACE NO. 1 COOLER THERMISTOR**

**OK**




**3. INSPECT AIR CONDITIONING HARNESS ASSEMBLY**

(a) Remove the air conditioning harness assembly.

Click here 

(b) Measure the resistance according to the value(s) in the table below.



|    |   |    |   |
|----|---|----|---|
| *a | Air Conditioning Harness Assembly                                 | *b | Front view of wire harness connector (to Air Conditioning Amplifier Assembly) |
| *c | Front view of wire harness connector (to No. 1 Cooler Thermistor) | -  | -   |

Standard Resistance:




[Click Location & Routing\(z23\)](#)

[Click Connector\(z23\)](#)

| TESTER CONNECTION | CONDITION | SPECIFIED CONDITION |
|-------------------|-----------|---------------------|
| z23-5 (SGA) - 2   | Always    | Below 1 Ω           |
| z23-6 (TEA) - 1   | Always    | Below 1 Ω           |

**OK**  **REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY**

**NG**  **REPLACE AIR CONDITIONING HARNESS ASSEMBLY**





|  |                     |                                      |
|--|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000RW3M       |
| <b>Model Year Start:</b> 2016  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B1423; Pressure Sensor Circuit; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |


|            |              |                                |
|------------|--------------|--------------------------------|
| <b>DTC</b> | <b>B1423</b> | <b>Pressure Sensor Circuit</b> |
|------------|--------------|--------------------------------|

## DESCRIPTION

This DTC is stored if refrigerant pressure on the high pressure side is extremely low (176 kPa (1.8 kgf/cm<sup>2</sup>, 26 psi) or less) or extremely high (3025 kPa (30.8 kgf/cm<sup>2</sup>, 439 psi) or more). The air conditioner pressure sensor, which is installed to the high pressure side pipe to detect refrigerant pressure, sends a refrigerant pressure signal to the air conditioning amplifier assembly. The air conditioning amplifier assembly converts this signal to a pressure value according to the sensor characteristics and uses it to control the compressor.

| DTC NO. | DETECTION ITEM          | DTC DETECTION CONDITION  | TROUBLE AREA   | MEMORY |
|---------|-------------------------|--|--|--------|
| B1423   | Pressure Sensor Circuit | <ul style="list-style-type: none"> <li>• Open or short in air conditioner pressure sensor circuit</li> <li>• Refrigerant pressure on high pressure side is extremely low (176 kPa (1.8 kgf/cm<sup>2</sup>, 26 psi) or less) or extremely high (3025 kPa (30.8 kgf/cm<sup>2</sup>, 439 psi) or more)</li> </ul> | <ul style="list-style-type: none"> <li>• Air conditioner pressure sensor</li> <li>• Harness or connector</li> <li>• Air conditioning amplifier assembly</li> <li>• Cooler expansion valve (blocked, stuck)</li> <li>• Cooler condenser assembly (blocked, deterioration of cooling capacity due to dirt)</li> <li>• Cooler dryer (moisture in the refrigerant cycle cannot be absorbed)</li> <li>• Cooling fan system (cooler condenser assembly cannot be cooled down)</li> <li>• Air conditioning system (leaks, blocked)</li> </ul> | -      |

## WIRING DIAGRAM



## CAUTION / NOTICE / HINT

### HINT:

If DTC B1423 and B14B8 are output at the same time, troubleshoot for DTC B14B8 first.

Click here [INFO](#)

## PROCEDURE

### 1. CHECK FOR DTC

(a) Check for DTCs.

Body Electrical > Air Conditioner > Trouble Codes

| RESULT              | PROCEED TO |
|---------------------|------------|
| B14B8 is not output | A          |
| B14B8 is output     | B          |

**B** GO TO DTC B14B8

**A**



### 2. CHECK REFRIGERANT SHORTAGE

(a) Prepare the vehicle according to the table below.

Measurement Condition:

| ITEM                 | CONDITION               |
|----------------------|-------------------------|
| A/C switch           | On                      |
| Ambient temperature* | 0 to 49°C (32 to 120°F) |
| Blower speed         | HI                      |

\*: If the ambient temperature is not within the range shown, do not perform this check.

(b) Connect the Techstream to the DLC3.

(c) Turn the power switch on (READY).

(d) Turn the Techstream on.

(e) Enter the following menus: Body Electrical / Air Conditioner / Utility / Refrigerant Gas Volume Check.

**Body Electrical > Air Conditioner > Utility**

| TESTER DISPLAY               |
|------------------------------|
| Refrigerant Gas Volume Check |

| RESULT               | AMOUNT OF REFRIGERANT   |
|----------------------|-------------------------|
| Refrigerant shortage | Insufficient or leakage |
| Refrigerant correct  | Correct                 |

| RESULT                  | PROCEED TO |
|-------------------------|------------|
| Insufficient or leakage | A          |
| Correct                 | B          |

**B**  **GO TO STEP 4**

**A**



|           |  |
|-----------|--|
| <b>3.</b> | <b>REPAIR AIR CONDITIONING SYSTEM LEAK</b> |
|-----------|--|

(a) Identify the area where refrigerant leaks from.

**HINT:**

[Click here](#) 

(b) Repair the identified area of the air conditioning system.

(c) Evacuate the air conditioning system.

**NEXT**  **CHARGE SYSTEM WITH REFRIGERANT**

|           |                                   |
|-----------|-----------------------------------|
| <b>4.</b> | <b>CHECK REFRIGERANT PRESSURE</b> |
|-----------|-----------------------------------|

- (a) Connect the Techstream to the DLC3.
- (b) Turn the power switch on (IG).
- (c) Turn the Techstream on.
- (d) Enter the following menus: Body Electrical / Air Conditioner / Data List.
- (e) Read the Data List according to the display on the Techstream.

**Body Electrical > Air Conditioner > Data List**

| TESTER DISPLAY            | MEASUREMENT ITEM                | RANGE                                  | NORMAL CONDITION                      | DIAGNOSTIC NOTE |
|---------------------------|---------------------------------|--|---------------------------------------|-----------------|
| Regulator Pressure Sensor | Air conditioner pressure sensor | Min.: -456.6 kPaG<br>Max.: 3294.3 kPaG | Actual refrigerant pressure displayed | -               |

**Body Electrical > Air Conditioner > Data List**

| TESTER DISPLAY            |
|---------------------------|
| Regulator Pressure Sensor |

(f) Install a manifold gauge set.

**HINT:**

[Click here](#) 


(g) Read the manifold gauge pressure when the following conditions are met.

(1) Prepare the vehicle according to the table below.

**Measurement Condition:**

| ITEM                | CONDITION  |
|---------------------|------------|
| Vehicle doors       | Fully open |
| Temperature setting | MAX COLD   |
| Blower speed        | HI         |
| A/C switch          | On         |

|                            |                         |
|----------------------------|-------------------------|
|                            |                         |
|                            |                         |
|                            |                         |
|                            |                         |
|                            |                         |
| Recirculation/fresh switch | RECIRCULATION           |
| Interior temperature       | 25 to 35°C (77 to 95°F) |



Standard Pressure:

*Low pressure side*

150 to 250 kPa (1.5 to 2.5 kgf/cm<sup>2</sup>, 22 to 36 psi)

*High pressure side*

1370 to 1570 kPa (14 to 16 kgf/cm<sup>2</sup>, 199 to 228 psi)

(h) Compare the values displayed in the Data List and on the manifold gauge.

OK:

The values displayed in the Data List and on the manifold gauge match.

**OK** ► CHECK REFRIGERANT PRESSURE

**NG**



|           |   |
|-----------|---|
| <b>5.</b> | <b>CHECK HARNESS AND CONNECTOR (POWER SOURCE CIRCUIT)</b> |
|-----------|---|

(a) Disconnect the A29 air conditioner pressure sensor connector.

(b) Measure the voltage according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(A29\)](#)

[Click Connector\(A29\)](#)

| TESTER CONNECTION     | CONDITION            | SPECIFIED CONDITION |
|-----------------------|----------------------|---------------------|
| A29-3 (+) - A29-1 (-) | Power switch on (IG) | 4.75 to 5.25 V      |

**NG** ► GO TO STEP 10

OK



**6. CHECK HARNESS AND CONNECTOR (AIR CONDITIONER PRESSURE SENSOR - BODY GROUND)**

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A29\)](#)

[Click Connector\(A29\)](#)

| TESTER CONNECTION       | CONDITION | SPECIFIED CONDITION |
|-------------------------|-----------|---------------------|
| A29-1 (-) - Body ground | Always    | Below 1 $\Omega$    |

**NG** **GO TO STEP 9**

OK



**7. CHECK HARNESS AND CONNECTOR (AIR CONDITIONING AMPLIFIER ASSEMBLY - AIR CONDITIONER PRESSURE SENSOR)**

(a) Disconnect the F57 air conditioning amplifier assembly connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A29\)](#)

[Click Location & Routing\(F57\)](#)

[Click Connector\(A29\)](#)

[Click Connector\(F57\)](#)

| TESTER CONNECTION                        | CONDITION | SPECIFIED CONDITION     |
|--|-----------|-------------------------|
| A29-2 (PR) - F57-24 (PRE)                | Always    | Below 1 $\Omega$        |
| A29-2 (PR) or F57-24 (PRE) - Body ground | Always    | 10 k $\Omega$ or higher |

**NG** **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK



**8. INSPECT AIR CONDITIONER PRESSURE SENSOR (SENSOR SIGNAL CIRCUIT)**

(a) Measure the voltage when the following conditions are met.

**Measurement Condition:**

| ITEM                       | CONDITION               |
|----------------------------|-------------------------|
| Vehicle doors              | Fully open              |
| Temperature setting        | MAX COLD                |
| Blower speed               | HI                      |
| A/C switch                 | On                      |
| Recirculation/fresh switch | RECIRCULATION           |
| Interior temperature       | 25 to 35°C (77 to 95°F) |

**NOTICE:**

- If refrigerant pressure on the high pressure side becomes extremely high during the inspection (if the voltage exceeds 4.61 V), the fail-safe function stops compressor operation. Therefore, measure the voltage before the fail-safe operation.
- It is necessary to measure the voltage for a certain amount of time (approximately 10 minutes) because the malfunction may recur after a while.

**HINT:**

When the outside air temperature is low (below -1.5°C (29.3°F)), the compressor stops due to operation of the thermistor assembly and the No. 1 cooler thermistor to prevent the evaporator from freezing. In this case, perform the inspection in a warm indoor environment.

(1) Measure the voltage according to the value(s) in the table below.


Standard Voltage:



[Click Location & Routing\(F57\)](#)

[Click Connector\(F57\)](#)

| TESTER CONNECTION   | CONDITION       | SPECIFIED CONDITION |
|---------------------|-----------------|---------------------|
| F57-24 (PRE) - Body | Power switch on |                     |



\*a Component with harness connected (Air Conditioning Amplifier Assembly)

|        |                          |                |
|--------|--------------------------|----------------|
| ground | (IG)<br>(A/C switch: On) | 0.74 to 4.61 V |
|--------|--------------------------|----------------|

- (b) Connect the Techstream to the DLC3.
- (c) Turn the power switch on (IG).
- (d) Turn the Techstream on.
- (e) Enter the following menus: Body Electrical / Air Conditioner / Data List.
- (f) Read the Data List according to the display on the Techstream.

**Body Electrical > Air Conditioner > Data List**

| TESTER DISPLAY            | MEASUREMENT ITEM                | RANGE                                  | NORMAL CONDITION                      | DIAGNOSTIC NOTE |
|---------------------------|---------------------------------|--|---------------------------------------|-----------------|
| Regulator Pressure Sensor | Air conditioner pressure sensor | Min.: -456.6 kPaG<br>Max.: 3294.3 kPaG | Actual refrigerant pressure displayed | -               |

**Body Electrical > Air Conditioner > Data List**

| TESTER DISPLAY            |
|---------------------------|
| Regulator Pressure Sensor |

OK:  
The voltage and value displayed in the Data List change.

| RESULT   | PROCEED TO |
|--|------------|
| OK   | A          |
| NG (The voltage changes but the value displayed in the Data List does not change.) |            |
| NG (The voltage does not change.)  | B          |

**A** ► REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY

**B** ► REPLACE AIR CONDITIONER PRESSURE SENSOR

|           |  |
|-----------|--|
| <b>9.</b> | <b>CHECK HARNESS AND CONNECTOR (AIR CONDITIONING AMPLIFIER ASSEMBLY - AIR CONDITIONER PRESSURE SENSOR)</b> |
|-----------|--|

- (a) Disconnect the F57 air conditioning amplifier assembly connector.



(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A29\)](#)

[Click Location & Routing\(F57\)](#)

[Click Connector\(A29\)](#)

[Click Connector\(F57\)](#)

| TESTER CONNECTION                       | CONDITION | SPECIFIED CONDITION     |
|---|-----------|-------------------------|
| A29-1 (-) - F57-2 (SG-2)                | Always    | Below 1 $\Omega$        |
| A29-1 (-) or F57-2 (SG-2) - Body ground | Always    | 10 k $\Omega$ or higher |

**OK** ► REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY

**NG** ► REPAIR OR REPLACE HARNESS OR CONNECTOR

|     |  |
|-----|--|
| 10. | <b>CHECK HARNESS AND CONNECTOR (AIR CONDITIONING AMPLIFIER ASSEMBLY - AIR CONDITIONER PRESSURE SENSOR)</b> |
|-----|--|

(a) Disconnect the F57 air conditioning amplifier assembly connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A29\)](#)

[Click Location & Routing\(F57\)](#)

[Click Connector\(A29\)](#)

[Click Connector\(F57\)](#)

| TESTER CONNECTION                        | CONDITION | SPECIFIED CONDITION     |
|--|-----------|-------------------------|
| A29-3 (+) - F57-6 (S5 -3)                | Always    | Below 1 $\Omega$        |
| A29-3 (+) or F57-6 (S5 -3) - Body ground | Always    | 10 k $\Omega$ or higher |

**OK** ► REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY

**NG** ► REPAIR OR REPLACE HARNESS OR CONNECTOR



|   |                     |                                      |
|---|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000001FYJT       |
| <b>Model Year Start:</b> 2019   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [12/2018 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B1441; Air Mix Damper Control Servo Motor Circuit (Passenger Side); 2019 MY Prius [12/2018 - ] |                     |                                      |

|            |              |  |
|------------|--------------|--|
| <b>DTC</b> | <b>B1441</b> | <b>Air Mix Damper Control Servo Motor Circuit (Passenger Side)</b> |
|------------|--------------|--|


## DESCRIPTION

The No. 2 air conditioning radiator damper servo sub-assembly sends pulse signals to inform the air conditioning amplifier assembly of the damper position. The air conditioning amplifier assembly activates the motor (normal or reverse) based on these signals to move the air mix damper to the appropriate position. This adjusts the amount of air passing through the heater core after passing the evaporator and controls the temperature of the output air. The air conditioning amplifier assembly communicates with the servo through a communication/driver IC and wiring assembly called the air conditioning harness assembly.

| DTC NO. | DETECTION ITEM  | DTC DETECTION CONDITION   | TROUBLE AREA  | MEMORY                          |
|---------|---|---|---|---------------------------------|
| B1441   | Air Mix Damper Control Servo Motor Circuit (Passenger Side) | Air mix damper position sensor value does not change even if air conditioning amplifier assembly operates No. 2 air conditioning radiator damper servo sub-assembly | <ul style="list-style-type: none"> <li>• No. 2 air conditioning radiator damper servo sub-assembly</li> <li>• Air conditioning harness assembly</li> <li>• Air conditioning amplifier assembly</li> <li>• Air conditioning radiator assembly</li> </ul> | Memorized<br>(30 sec. or more)* |

\*: The air conditioning amplifier assembly stores this DTC if the malfunction has occurred for the period of time indicated in the brackets.

## WIRING DIAGRAM



## CAUTION / NOTICE / HINT

### HINT:

- Confirm that no mechanical problem is present because this DTC can be output when either a damper link or damper is mechanically locked.
- When installing the damper servo motor, make sure to install it correctly.

Click here [INFO](#)

## PROCEDURE

**1. CHECK FOR DTC**

(a) Check for DTCs.

**Body Electrical > Air Conditioner > Trouble Codes**

| RESULT                            | PROCEED TO |
|-----------------------------------|------------|
| B1441, B1442 and B1448 are output | A          |
| B1497 is output                   | B          |
| B1441 is output                   | C          |

**A** ▶ REPLACE NO. 2 AIR CONDITIONING RADIATOR DAMPER SERVO SUB-ASSEMBLY

**B** ▶ GO TO DTC B1497

**C**



**2. INSPECT NO. 2 AIR CONDITIONING RADIATOR DAMPER SERVO SUB-ASSEMBLY (MOTOR, LINK, DAMPER)**

(a) Check for a wire harness caught between the links of the motors and dampers.

OK:

No wire harnesses are caught between the links of the motors and dampers.

**NG** ▶ REMOVE PINCHED WIRE HARNESS

**OK**



**3. INSPECT AIR CONDITIONING RADIATOR ASSEMBLY (DAMPER)**

(a) Remove the No. 2 air conditioning radiator damper servo sub-assembly.

**HINT:**

Click here


(b) Operate the dampers by hand.

OK:

The dampers are easily operated by hand.

**OK** ► REPLACE NO. 2 AIR CONDITIONING RADIATOR DAMPER  
SERVO SUB-ASSEMBLY

**NG** ► REPLACE AIR CONDITIONING RADIATOR ASSEMBLY



|  |                     |                                      |
|--|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM100000001FYJU       |
| <b>Model Year Start:</b> 2019  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [12/2018 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B1442; Air Inlet Damper Control Servo Motor Circuit; 2019 MY Prius [12/2018 - ] |                     |                                      |

|            |              |   |
|------------|--------------|---|
| <b>DTC</b> | <b>B1442</b> | <b>Air Inlet Damper Control Servo Motor Circuit</b> |
|------------|--------------|---|

## DESCRIPTION


The No. 1 blower damper servo sub-assembly sends pulse signals to inform the air conditioning amplifier assembly of the damper position. The air conditioning amplifier assembly activates the motor (normal or reverse) based on these signals to move the air inlet damper to the appropriate position to change the air inlet mode (fresh, recirculation/fresh, and recirculation).

The air conditioning amplifier assembly communicates with the servo through a communication/driver IC and wiring assembly called the air conditioning harness assembly.

| DTC NO. | DETECTION ITEM                               | DTC DETECTION CONDITION  | TROUBLE AREA   | MEMORY                              |
|---------|--|--|--|-------------------------------------|
| B1442   | Air Inlet Damper Control Servo Motor Circuit | Air inlet damper position sensor value does not change even if air conditioning amplifier assembly operates No. 1 blower damper servo sub-assembly | <ul style="list-style-type: none"> <li>• No. 1 blower damper servo sub-assembly</li> <li>• No. 2 air conditioning radiator damper servo sub-assembly</li> <li>• Air conditioning harness assembly</li> <li>• Air conditioning amplifier assembly</li> <li>• Blower assembly</li> </ul> | Memorized<br><br>(30 sec. or more)* |

\*: The air conditioning amplifier assembly stores this DTC if the malfunction has occurred for the period of time indicated in the brackets.

## WIRING DIAGRAM



## CAUTION / NOTICE / HINT

### HINT:

- Confirm that no mechanical problem is present because this DTC can be output when either a damper link or damper is mechanically locked.
- When installing the damper servo motor, make sure to install it correctly.

Click here [INFO](#)

## PROCEDURE

## 1. CHECK FOR DTC

(a) Check for DTCs.

**Body Electrical > Air Conditioner > Trouble Codes**

| RESULT                            | PROCEED TO |
|-----------------------------------|------------|
| B1441, B1442 and B1448 are output | A          |
| B1497 is output                   | B          |
| B1442 is output                   | C          |

**A** ▶ REPLACE NO. 2 AIR CONDITIONING RADIATOR DAMPER SERVO SUB-ASSEMBLY

**B** ▶ GO TO DTC B1497

**C**



## 2. INSPECT BLOWER ASSEMBLY

(a) Remove the No. 1 blower damper servo sub-assembly.

**HINT:**

[Click here](#) 

(b) Operate the air inlet control dampers by hand.

OK:

The air inlet control dampers are easily operated by hand.

**NG** ▶ REPLACE BLOWER ASSEMBLY

**OK**



## 3. INSPECT AIR CONDITIONING HARNESS ASSEMBLY

(a) Disconnect the No. 2 air conditioning radiator damper servo sub-assembly connector.



(b) Disconnect the No. 1 blower damper servo sub-assembly connector.

(c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

| TESTER CONNECTION                  | CONDITION | SPECIFIED CONDITION     |
|------------------------------------|-----------|-------------------------|
| 6 (STE2) - 3 (sigB)                | Always    | Below 1 $\Omega$        |
| 5 (STE1) - 2 (sigA)                | Always    | Below 1 $\Omega$        |
| 8 (M-) - 5 (M-)                    | Always    | Below 1 $\Omega$        |
| 7 (M+) - 4 (M+)                    | Always    | Below 1 $\Omega$        |
| 4 (GND) - 1 (GND)                  | Always    | Below 1 $\Omega$        |
| 6 (STE2) or 3 (sigB) - Body ground | Always    | 10 k $\Omega$ or higher |
| 5 (STE1) or 2 (sigA) - Body ground | Always    | 10 k $\Omega$ or higher |
| 8 (M-) or 5 (M-) - Body ground     | Always    | 10 k $\Omega$ or higher |
| 7 (M+) or 4 (M+) - Body ground     | Always    | 10 k $\Omega$ or higher |

**NG**  **REPLACE AIR CONDITIONING HARNESS ASSEMBLY**

**OK**



**4. PERFORM ACTIVE TEST USING TECHSTREAM**

(a) Connect the No. 2 air conditioning radiator damper servo sub-assembly connector.

(b) Remove the No. 3 air conditioning radiator damper servo sub-assembly.

**HINT:**

[Click here](#) 

(c) Connect the No. 1 blower damper servo sub-assembly connector to the No. 3 air conditioning radiator damper servo sub-assembly.

(d) Connect the Techstream to the DLC3.

(e) Turn the power switch on (IG).

(f) Turn the Techstream on.

(g) Enter the following menus: Body Electrical / Air Conditioner / Active Test.

(h) Perform the Active Test according to the display on the Techstream.

**Body Electrical > Air Conditioner > Active Test**

| TESTER DISPLAY | MEASUREMENT ITEM | CONTROL RANGE | DIAGNOSTIC NOTE |
|----------------|------------------|---------------|-----------------|
|----------------|------------------|---------------|-----------------|

|                             |   |                        |                                    |
|-----------------------------|---|------------------------|------------------------------------|
| Air Inlet Damper Targ Pulse | No. 1 blower damper servo sub-assembly pulse* | Min.: 128<br>Max.: 383 | Operates between 220 to 256 pulses |
|-----------------------------|---|------------------------|------------------------------------|

\*: Thus this Active Test is for the No. 1 blower damper servo sub-assembly, in this case it is used to check the operation of the No. 3 air conditioning radiator damper servo sub-assembly.

**Body Electrical > Air Conditioner > Active Test**


|                             |
|-----------------------------|
| TESTER DISPLAY              |
| Air Inlet Damper Targ Pulse |

OK:

The No. 3 air conditioning radiator damper servo sub-assembly operates.

**OK** ► REPLACE NO. 1 BLOWER DAMPER SERVO SUB-ASSEMBLY

**NG** ► REPLACE NO. 2 AIR CONDITIONING RADIATOR DAMPER SERVO SUB-ASSEMBLY



|   |                     |                                      |
|---|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000001FYJV       |
| <b>Model Year Start:</b> 2019   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [12/2018 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B1443; Air Outlet Damper Control Servo Motor Circuit; 2019 MY Prius [12/2018 - ] |                     |                                      |

|            |              |  |
|------------|--------------|--|
| <b>DTC</b> | <b>B1443</b> | <b>Air Outlet Damper Control Servo Motor Circuit</b> |
|------------|--------------|--|

## DESCRIPTION


The No. 1 air conditioning radiator damper servo sub-assembly sends pulse signals to inform the air conditioning amplifier assembly of the damper position. The air conditioning amplifier assembly activates the motor (normal or reverse) based on these signals to move the air outlet damper to the appropriate position, which controls the air outlet switching.

The air conditioning amplifier assembly communicates with the servo through a communication/driver IC and wiring assembly called the air conditioning harness assembly.

| DTC NO. | DETECTION ITEM                                | DTC DETECTION CONDITION  | TROUBLE AREA  | MEMORY                              |
|---------|---|--|---|-------------------------------------|
| B1443   | Air Outlet Damper Control Servo Motor Circuit | Air outlet damper position sensor value does not change even if air conditioning amplifier assembly operates No. 1 air conditioning radiator damper servo sub-assembly | <ul style="list-style-type: none"> <li>No. 1 air conditioning radiator damper servo sub-assembly</li> <li>Air conditioning harness assembly</li> <li>Air conditioning amplifier assembly</li> <li>Air conditioning radiator assembly</li> </ul> | Memorized<br><br>(30 sec. or more)* |

\*: The air conditioning amplifier assembly stores this DTC if the malfunction has occurred for the period of time indicated in the brackets.

## WIRING DIAGRAM



## CAUTION / NOTICE / HINT

### HINT:

- Confirm that no mechanical problem is present because this DTC can be output when either a damper link or damper is mechanically locked.
- When installing the damper servo motor, make sure to install it correctly.

[Click here](#) INFO

## PROCEDURE

|           |                      |
|-----------|----------------------|
| <b>1.</b> | <b>CHECK FOR DTC</b> |
|-----------|----------------------|

(a) Check for DTCs.

**Body Electrical > Air Conditioner > Trouble Codes**

| RESULT              | PROCEED TO |
|---------------------|------------|
| B1497 is not output | A          |
| B1497 is output     | B          |

**B** ▶ GO TO DTC B1497

**A**



2.

**INSPECT NO. 1 AIR CONDITIONING RADIATOR DAMPER SERVO SUB-ASSEMBLY  
(INSTALLATION CONDITION)**

(a) Check that the No. 1 air conditioning radiator damper servo sub-assembly is installed correctly.

**HINT:**

[Click here](#) 

OK:

The No. 1 air conditioning radiator damper servo sub-assembly is installed correctly.

**NG**  **INSTALL NO. 1 AIR CONDITIONING RADIATOR DAMPER  
SERVO SUB-ASSEMBLY CORRECTLY**

**OK**



3.

**INSPECT NO. 1 AIR CONDITIONING RADIATOR DAMPER SERVO SUB-ASSEMBLY (MOTOR, LINK,  
DAMPER)**

(a) Check for a wire harness caught between the links of the motors and dampers.

OK:

No wire harnesses are caught between the links of the motors and dampers.

**NG**  **REMOVE PINCHED WIRE HARNESS**

**OK**



4.

**INSPECT AIR CONDITIONING RADIATOR ASSEMBLY (DAMPER)**

(a) Remove the No. 1 air conditioning radiator damper servo sub-assembly.

**HINT:**

[Click here](#) 

(b) Operate the dampers by hand.

OK:

The dampers are easily operated by hand.

**NG**  **REPLACE AIR CONDITIONING RADIATOR ASSEMBLY**

**5. PERFORM ACTIVE TEST USING TECHSTREAM**

(a) Remove the No. 3 air conditioning radiator damper servo sub-assembly.

**HINT:**

Click here 

(b) Connect the No. 3 air conditioning radiator damper servo sub-assembly connector to the No. 1 air conditioning radiator damper servo sub-assembly.

(c) Connect the Techstream to the DLC3.

(d) Turn the power switch on (IG).

(e) Turn the Techstream on.

(f) Enter the following menus: Body Electrical / Air Conditioner / Active Test.

(g) Perform the Active Test according to the display on the Techstream.

**Body Electrical > Air Conditioner > Active Test**

| TESTER DISPLAY        | MEASUREMENT ITEM   | CONTROL RANGE          | DIAGNOSTIC NOTE                    |
|-----------------------|--|------------------------|------------------------------------|
| A/O Servo Pulse(Rr D) | No. 3 air conditioning radiator damper servo sub-assembly pulse* | Min.: 128<br>Max.: 383 | Operates between 250 to 297 pulses |

\*: Thus this Active Test is for the No. 3 air conditioning radiator damper servo sub-assembly, in this case it is used to check the operation of the No. 1 air conditioning radiator damper servo sub-assembly.

**Body Electrical > Air Conditioner > Active Test**

| TESTER DISPLAY        |
|-----------------------|
| A/O Servo Pulse(Rr D) |

OK:  
The No. 1 air conditioning radiator damper servo sub-assembly operates.

**OK** ► REPLACE AIR CONDITIONING HARNESS ASSEMBLY

**NG** ► REPLACE NO. 1 AIR CONDITIONING RADIATOR DAMPER SERVO SUB-ASSEMBLY



|   |                     |  |
|---|---------------------|--|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000001FYJW           |
| <b>Model Year Start:</b> 2019   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [12/2018 -     ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B1448; Passenger Side FACE Servo Motor Circuit; 2019 MY Prius [12/2018 -     ] |                     |  |

|            |              |  |
|------------|--------------|--|
| <b>DTC</b> | <b>B1448</b> | <b>Passenger Side FACE Servo Motor Circuit</b> |
|------------|--------------|--|

## DESCRIPTION


The No. 2 air conditioning radiator damper servo sub-assembly sends pulse signals to inform the air conditioning amplifier assembly of the damper position. The air conditioning amplifier assembly activates the motor (normal or reverse) based on these signals to move the air outlet damper to the appropriate position, which controls the air outlet switching.

The air conditioning amplifier assembly communicates with the servo through a communication/driver IC and wiring assembly called the air conditioning harness assembly.

| DTC NO. | DETECTION ITEM                          | DTC DETECTION CONDITION  | TROUBLE AREA  | MEMORY                       |
|---------|---|--|---|------------------------------|
| B1448   | Passenger Side FACE Servo Motor Circuit | Air outlet damper position sensor value does not change even if air conditioning amplifier assembly operates No. 2 air conditioning radiator damper servo sub-assembly | <ul style="list-style-type: none"> <li>No. 2 air conditioning radiator damper servo sub-assembly</li> <li>Air conditioning harness assembly</li> <li>Air conditioning amplifier assembly</li> <li>Air conditioning radiator assembly</li> </ul> | Memorized (30 sec. or more)* |

\*: The air conditioning amplifier assembly stores this DTC if the malfunction has occurred for the period of time indicated in the brackets.

## WIRING DIAGRAM



## CAUTION / NOTICE / HINT

### HINT:

- Confirm that no mechanical problem is present because this DTC can be output when either a damper link or damper is mechanically locked.
- When installing the damper servo motor, make sure to install it correctly.

Click here

## PROCEDURE



**1. CHECK FOR DTC**

(a) Check for DTCs.

**Body Electrical > Air Conditioner > Trouble Codes**

| RESULT                            | PROCEED TO |
|-----------------------------------|------------|
| B1441, B1442 and B1448 are output | A          |
| B1497 is output                   | B          |
| B1448 is output                   | C          |

**A** ▶ REPLACE NO. 2 AIR CONDITIONING RADIATOR DAMPER SERVO SUB-ASSEMBLY

**B** ▶ GO TO DTC B1497

**C**



**2. INSPECT NO. 2 AIR CONDITIONING RADIATOR DAMPER SERVO SUB-ASSEMBLY (MOTOR, LINK, DAMPER)**

(a) Check for a wire harness caught between the links of the motors and dampers.

OK:

No wire harnesses are caught between the links of the motors and dampers.

**NG** ▶ REMOVE PINCHED WIRE HARNESS

**OK**



**3. INSPECT AIR CONDITIONING RADIATOR ASSEMBLY (DAMPER)**

(a) Remove the No. 2 air conditioning radiator damper servo sub-assembly.

**HINT:**

Click here


(b) Operate the dampers by hand.

OK:

The dampers are easily operated by hand.

**OK** ► REPLACE NO. 2 AIR CONDITIONING RADIATOR DAMPER  
SERVO SUB-ASSEMBLY

**NG** ► REPLACE AIR CONDITIONING RADIATOR ASSEMBLY



|  |                     |  |
|--|---------------------|--|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM100000001FYJX           |
| <b>Model Year Start:</b> 2019  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [12/2018 -     ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B1449; Rear Air Outlet Damper Control Servo Motor Circuit; 2019 MY Prius [12/2018 -     ] |                     |  |

|            |              |   |
|------------|--------------|---|
| <b>DTC</b> | <b>B1449</b> | <b>Rear Air Outlet Damper Control Servo Motor Circuit</b> |
|------------|--------------|---|


## DESCRIPTION

The No. 3 air conditioning radiator damper servo sub-assembly sends pulse signals to inform the air conditioning amplifier assembly of the damper position. The air conditioning amplifier assembly activates the motor (normal or reverse) based on these signals to move the air mix damper to the appropriate position, which controls the rear air outlet switching. The air conditioning amplifier assembly communicates with the servo through a communication/driver IC and wiring assembly called the air conditioning harness assembly.

| DTC NO. | DETECTION ITEM                                     | DTC DETECTION CONDITION   | TROUBLE AREA  | MEMORY                              |
|---------|--|---|---|-------------------------------------|
| B1449   | Rear Air Outlet Damper Control Servo Motor Circuit | Air mix damper position sensor value does not change even if air conditioning amplifier assembly operates No. 3 air conditioning radiator damper servo sub-assembly | <ul style="list-style-type: none"> <li>• No. 3 air conditioning radiator damper servo sub-assembly</li> <li>• Air conditioning harness assembly</li> <li>• Air conditioning amplifier assembly</li> <li>• Air conditioning radiator assembly</li> </ul> | Memorized<br><br>(30 sec. or more)* |

\*: The air conditioning amplifier assembly stores this DTC if the malfunction has occurred for the period of time indicated in the brackets.

## WIRING DIAGRAM



## CAUTION / NOTICE / HINT

### HINT:

- Confirm that no mechanical problem is present because this DTC can be output when either a damper link or damper is mechanically locked.
- When installing the damper servo motor, make sure to install it correctly.

Click here [INFO](#)

## PROCEDURE

|    |                      |
|----|----------------------|
| 1. | <b>CHECK FOR DTC</b> |
|----|----------------------|

(a) Check for DTCs.

Body Electrical > Air Conditioner > Trouble Codes

| RESULT              | PROCEED TO |
|---------------------|------------|
| B1497 is not output | A          |
| B1497 is output     | B          |

**B** GO TO DTC B1497

**A**



2.

**INSPECT INSTALL NO. 3 AIR CONDITIONING RADIATOR DAMPER SERVO SUB-ASSEMBLY CORRECTLY**

(a) Check that the No. 3 air conditioning radiator damper servo sub-assembly is installed correctly.

**HINT:**

[Click here](#) 

OK:

The No. 3 air conditioning radiator damper servo sub-assembly is installed correctly.

**NG**  **INSTALL NO. 3 AIR CONDITIONING RADIATOR DAMPER SERVO SUB-ASSEMBLY CORRECTLY**

**OK**



3.

**INSPECT NO. 3 AIR CONDITIONING RADIATOR DAMPER SERVO SUB-ASSEMBLY (MOTOR, LINK, DAMPER)**

(a) Check for a wire harness caught between the links of the motors and dampers.

OK:

No wire harnesses are caught between the links of the motors and dampers.

**NG**  **REMOVE PINCHED WIRE HARNESS**

**OK**



4.

**INSPECT AIR CONDITIONING RADIATOR ASSEMBLY (DAMPER)**

(a) Remove the No. 3 air conditioning radiator damper servo sub-assembly.

**HINT:**

[Click here](#) 

(b) Operate the dampers by hand.

OK:

The dampers are easily operated by hand.

**NG**  **REPLACE AIR CONDITIONING RADIATOR ASSEMBLY**



**5. PERFORM ACTIVE TEST USING TECHSTREAM**

(a) Remove the No. 1 air conditioning radiator damper servo sub-assembly.

**HINT:**

Click here

(b) Connect the No. 1 air conditioning radiator damper servo sub-assembly connector to the No. 3 air conditioning radiator damper servo sub-assembly.

(c) Connect the Techstream to the DLC3.

(d) Turn the power switch on (IG).

(e) Turn the Techstream on.

(f) Enter the following menus: Body Electrical / Air Conditioner / Active Test.

(g) Perform the Active Test according to the display on the Techstream.

**Body Electrical > Air Conditioner > Active Test**

| TESTER DISPLAY             | MEASUREMENT ITEM   | CONTROL RANGE          | DIAGNOSTIC NOTE                    |
|----------------------------|--|------------------------|------------------------------------|
| Air Outlet Servo Pulse (P) | No. 1 air conditioning radiator damper servo sub-assembly pulse* | Min.: 128<br>Max.: 383 | Operates between 164 to 256 pulses |

\*: Thus this Active Test is for the No. 1 air conditioning radiator damper servo sub-assembly, in this case it is used to check the operation of the No. 3 air conditioning radiator damper servo sub-assembly.

**Body Electrical > Air Conditioner > Active Test**

| TESTER DISPLAY             |
|----------------------------|
| Air Outlet Servo Pulse (P) |

OK:  
The No. 3 air conditioning radiator damper servo sub-assembly operates.

**OK** REPLACE AIR CONDITIONING HARNESS ASSEMBLY

**NG** REPLACE NO. 3 AIR CONDITIONING RADIATOR DAMPER SERVO SUB-ASSEMBLY



|  |                     |                                      |
|--|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000RW4K       |
| <b>Model Year Start:</b> 2016  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B1471; A/C Inverter High Voltage Power Resource System Malfunction; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

|            |              |  |
|------------|--------------|--|
| <b>DTC</b> | <b>B1471</b> | <b>A/C Inverter High Voltage Power Resource System Malfunction</b> |
|------------|--------------|--|


## DESCRIPTION

The hybrid vehicle control ECU monitors the voltage of the HV battery. The hybrid vehicle control ECU stops compressor control and stores this DTC when the monitored voltage is outside the specified range.

This DTC will be stored as a history DTC. Compressor control may not resume unless the power switch is turned off.

| DTC NO. | DETECTION ITEM  | DTC DETECTION CONDITION   | TROUBLE AREA  | MEMORY    |
|---------|---|---|---|-----------|
| B1471   | A/C Inverter High Voltage Power Resource System Malfunction | <ul style="list-style-type: none"> <li>Open or short in A/C inverter high voltage power resource system</li> <li>Boost inverter malfunctioning</li> </ul> | <ul style="list-style-type: none"> <li>Air conditioning wire (harness or connector between compressor with motor assembly and inverter with converter assembly)</li> <li>Compressor with motor assembly</li> <li>Hybrid control system</li> <li>CAN communication system</li> </ul> | Memorized |

## WIRING DIAGRAM



## CAUTION / NOTICE / HINT

### CAUTION:

- Before inspecting the high-voltage system, take safety precautions such as wearing insulated gloves and removing the service plug grip to prevent electrical shocks. After removing the service plug grip, put it in your pocket to prevent other technicians from accidentally reconnecting it while you are working on the high-voltage system.
- Do not touch the high-voltage connectors or terminals for 10 minutes after the service plug grip is removed.

### NOTICE:

- Inspect the fuses for circuits related to this system before performing the following procedure.
- After turning the power switch off, waiting time may be required before disconnecting the cable from the negative (-)



auxiliary battery terminal. Therefore, make sure to read the disconnecting the cable from the negative (-) auxiliary battery terminal notices before proceeding with work.

Click here [INFO](#) [INFO](#) [INFO](#)

- The hybrid control system and air conditioning system output DTCs separately. Perform troubleshooting for the hybrid control system first if DTCs for both systems are output simultaneously.

## PROCEDURE

### 1. CHECK CAN COMMUNICATION SYSTEM

(a) Using the Techstream, check if the CAN communication system is functioning normally.

#### HINT:

Click here [INFO](#) [INFO](#)

| RESULT                                       | PROCEED TO |
|--|------------|
| CAN communication system DTCs are not output | A          |
| CAN communication system DTCs are output     | B          |

**B**  GO TO CAN COMMUNICATION SYSTEM [INFO](#) [INFO](#)

**A**



### 2. CONFIRM MODEL

(a) Choose the model to be inspected.

| RESULT                           | PROCEED TO |
|----------------------------------|------------|
| for Nickel Metal Hydride Battery | A          |
| for Lithium-ion Battery          | B          |

**B**  GO TO STEP 7

**A**



### 3. CHECK FOR DTC

(a) Check if hybrid control system DTCs are output.

**Powertrain > Hybrid Control > Trouble Codes**

| RESULT              | PROCEED TO |
|---------------------|------------|
| DTCs are not output | A          |
| DTCs are output     | B          |

**B**  **GO TO HYBRID CONTROL SYSTEM**

**A**



### 4. INSPECT AIR CONDITIONING WIRE

**CAUTION:**

Be sure to wear insulated gloves.

(a) Disconnect the T1 and T2 air conditioning wire connectors.

**HINT:**

Click here  

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(T1,T2\)](#)

[Click Connector\(T1\)](#)

[Click Connector\(T2\)](#)

| TESTER CONNECTION       | CONDITION | SPECIFIED CONDITION |
|-------------------------|-----------|---------------------|
| T1-2 (PB) - T2-1 (ACPB) | Always    | Below 1 $\Omega$    |

**NG**  **GO TO STEP 6**

**OK**



5. INSPECT AIR CONDITIONING WIRE

**CAUTION:**

Be sure to wear insulated gloves.

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(T1,T2\)](#)

[Click Connector\(T1\)](#)

[Click Connector\(T2\)](#)

| TESTER CONNECTION       | CONDITION | SPECIFIED CONDITION |
|-------------------------|-----------|---------------------|
| T1-1 (PE) - T2-2 (ACPE) | Always    | Below 1 $\Omega$    |

OK REPLACE COMPRESSOR WITH MOTOR ASSEMBLY

NG REPLACE AIR CONDITIONING WIRE

6. INSPECT AIR CONDITIONING WIRE

**CAUTION:**

Be sure to wear insulated gloves.

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(T1\)](#)

[Click Connector\(T1\)](#)

| TESTER CONNECTION       | CONDITION | SPECIFIED CONDITION     |
|-------------------------|-----------|-------------------------|
| T1-2 (PB) - Body ground | Always    | 10 k $\Omega$ or higher |

OK REPLACE COMPRESSOR WITH MOTOR ASSEMBLY

NG REPLACE AIR CONDITIONING WIRE

## 7. CHECK FOR DTC

(a) Check if hybrid control system DTCs are output.

**Powertrain > Hybrid Control > Trouble Codes**

| RESULT              | PROCEED TO |
|---------------------|------------|
| DTCs are not output | A          |
| DTCs are output     | B          |

**B**  **GO TO HYBRID CONTROL SYSTEM**

**A**  


## 8. INSPECT AIR CONDITIONING WIRE

**CAUTION:**

Be sure to wear insulated gloves.

(a) Disconnect the T1 and T2 air conditioning wire connectors.

**HINT:**

Click here  

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(T1,T2\)](#)

[Click Connector\(T1\)](#)

[Click Connector\(T2\)](#)

| TESTER CONNECTION       | CONDITION | SPECIFIED CONDITION |
|-------------------------|-----------|---------------------|
| T1-2 (PB) - T2-1 (ACPB) | Always    | Below 1 $\Omega$    |

**NG**  **GO TO STEP 10**

**OK**  


## 9. INSPECT AIR CONDITIONING WIRE

### CAUTION:

Be sure to wear insulated gloves.

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(T1,T2\)](#)

[Click Connector\(T1\)](#)

[Click Connector\(T2\)](#)

| TESTER CONNECTION       | CONDITION | SPECIFIED CONDITION |
|-------------------------|-----------|---------------------|
| T1-1 (PE) - T2-2 (ACPE) | Always    | Below 1 $\Omega$    |

OK REPLACE COMPRESSOR WITH MOTOR ASSEMBLY

NG REPLACE AIR CONDITIONING WIRE

## 10. INSPECT AIR CONDITIONING WIRE

### CAUTION:

Be sure to wear insulated gloves.

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(T1\)](#)

[Click Connector\(T1\)](#)

| TESTER CONNECTION       | CONDITION | SPECIFIED CONDITION     |
|-------------------------|-----------|-------------------------|
| T1-2 (PB) - Body ground | Always    | 10 k $\Omega$ or higher |

OK REPLACE COMPRESSOR WITH MOTOR ASSEMBLY

NG REPLACE AIR CONDITIONING WIRE



|   |                     |                                      |
|---|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000RW4L       |
| <b>Model Year Start:</b> 2016   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B1472/72; A/C Inverter High Voltage Output System Malfunction; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

|            |                 |  |
|------------|-----------------|--|
| <b>DTC</b> | <b>B1472/72</b> | <b>A/C Inverter High Voltage Output System Malfunction</b> |
|------------|-----------------|--|

## DESCRIPTION

The inverter in the compressor with motor assembly outputs high-voltage electricity to operate the motor. If there is an open or short in the output circuit, the hybrid vehicle control ECU will stop compressor operation and store this DTC. This DTC will be stored as a history DTC. The compressor operation remains stopped until both the history and current DTCs are cleared.

| DTC NO.  | DETECTION ITEM                                      | DTC DETECTION CONDITION                                   | TROUBLE AREA   | MEMORY    |
|----------|---|---|--|-----------|
| B1472/72 | A/C Inverter High Voltage Output System Malfunction | Open or short in A/C inverter high voltage output circuit | <ul style="list-style-type: none"> <li>Compressor with motor assembly</li> <li>CAN communication system</li> </ul> | Memorized |

## CAUTION / NOTICE / HINT

### CAUTION:

- Before inspecting the high-voltage system, take safety precautions such as wearing insulated gloves and removing the service plug grip to prevent electrical shocks. After removing the service plug grip, put it in your pocket to prevent other technicians from accidentally reconnecting it while you are working on the high-voltage system.
- Do not touch the high-voltage connectors or terminals for 10 minutes after the service plug grip is removed.

### NOTICE:

- After turning the power switch off, waiting time may be required before disconnecting the cable from the negative (-) auxiliary battery terminal. Therefore, make sure to read the disconnecting the cable from the negative (-) auxiliary battery terminal notices before proceeding with work.

Click here [INFO](#) [INFO](#) [INFO](#)

- The hybrid control system and air conditioning system output DTCs separately. Perform troubleshooting for the hybrid control system first if DTCs for both systems are output simultaneously.

## PROCEDURE

|           |                                       |
|-----------|---------------------------------------|
| <b>1.</b> | <b>CHECK CAN COMMUNICATION SYSTEM</b> |
|-----------|---------------------------------------|

(a) Using the Techstream, check if the CAN communication system is functioning normally.

Click here [INFO](#) [INFO](#)


| RESULT                                       | PROCEED TO |
|--|------------|
| CAN communication system DTCs are not output | A          |

CAN communication system DTCs are output

B

**A** ▶ REPLACE COMPRESSOR WITH MOTOR ASSEMBLY [INFO](#) [INFO](#)  
[INFO](#) [INFO](#)

**B** ▶ GO TO CAN COMMUNICATION SYSTEM [INFO](#) [INFO](#) [INFO](#) [INFO](#)



|  |                     |  |
|--|---------------------|--|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000RW4M           |
| <b>Model Year Start:</b> 2016  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 -     ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B1473; A/C Inverter Start-up Signal System Malfunction; 2016 - 2019 MY Prius [11/2015 -     ] |                     |  |

|            |              |  |
|------------|--------------|--|
| <b>DTC</b> | <b>B1473</b> | <b>A/C Inverter Start-up Signal System Malfunction</b> |
|------------|--------------|--|


## DESCRIPTION

The inverter activation signal is sent to the compressor with motor assembly from the hybrid vehicle control ECU. Compressor control is stopped and this DTC is stored if there is an open or short in the signal circuit.

| DTC NO. | DETECTION ITEM                                  | DTC DETECTION CONDITION                               | TROUBLE AREA  | MEMORY |
|---------|---|---|---|--------|
| B1473   | A/C Inverter Start-up Signal System Malfunction | Open or short in A/C inverter start-up signal circuit | <ul style="list-style-type: none"> <li>● Harness or connector</li> <li>● Compressor with motor assembly</li> <li>● Hybrid vehicle control ECU</li> <li>● Hybrid control system</li> <li>● CAN communication system</li> </ul> | -      |

## WIRING DIAGRAM





## CAUTION / NOTICE / HINT

### CAUTION:

- Before inspecting the high-voltage system, take safety precautions such as wearing insulated gloves and removing the service plug grip to prevent electrical shocks. After removing the service plug grip, put it in your pocket to prevent other technicians from accidentally reconnecting it while you are working on the high-voltage system.
- Do not touch the high-voltage connectors or terminals for 10 minutes after the service plug grip is removed.

### NOTICE:

- After turning the power switch off, waiting time may be required before disconnecting the cable from the negative (-) auxiliary battery terminal. Therefore, make sure to read the disconnecting the cable from the negative (-) auxiliary

battery terminal notices before proceeding with work.

Click here [INFO](#) [INFO](#) [INFO](#)

- The hybrid control system and air conditioning system output DTCs separately. Perform troubleshooting for the hybrid control system first if DTCs for both systems are output simultaneously.

## PROCEDURE

### 1. CHECK CAN COMMUNICATION SYSTEM

(a) Using the Techstream, check if the CAN communication system is functioning normally.

#### HINT:

Click here [INFO](#) [INFO](#)

| RESULT                                       | PROCEED TO |
|--|------------|
| CAN communication system DTCs are not output | A          |
| CAN communication system DTCs are output     | B          |

**B**  GO TO CAN COMMUNICATION SYSTEM [INFO](#) [INFO](#)

**A**  


### 2. CHECK FOR DTC

(a) Check if air conditioning system DTCs are output.

**Body Electrical > Air Conditioner > Trouble Codes**

| RESULT                                    | PROCEED TO |
|---|------------|
| B1473 and B1498 are output simultaneously | A          |
| Only B1473 is output                      | B          |

**A**  GO TO DTC B1498

**B**  


### 3. CONFIRM MODEL

(a) Choose the model to be inspected.

| RESULT                           | PROCEED TO |
|----------------------------------|------------|
| for Nickel Metal Hydride Battery | A          |
| for Lithium-ion Battery          | B          |

**B** ► GO TO STEP 6

**A**



### 4. CHECK FOR DTC

(a) Check if hybrid control system DTCs are output.

**Powertrain > Hybrid Control > Trouble Codes**

| RESULT              | PROCEED TO |
|---------------------|------------|
| DTCs are not output | A          |
| DTCs are output     | B          |

**B** ► GO TO HYBRID CONTROL SYSTEM

**A**



### 5. PERFORM ACTIVE TEST USING TECHSTREAM

(a) Connect the Techstream to the DLC3.

(b) Turn the power switch on (IG).

(c) Turn the Techstream on.

(d) Enter the following menus: Body Electrical / Air Conditioner / Active Test.

(e) Perform the Active Test according to the display on the Techstream.

**Body Electrical > Air Conditioner > Active Test**

| TESTER DISPLAY          | MEASUREMENT ITEM               | CONTROL RANGE       | DIAGNOSTIC NOTE |
|-------------------------|--------------------------------|---------------------|-----------------|
| Compressor Target Speed | Compressor with motor assembly | Min.: 0, Max.: 7500 | -               |

**Body Electrical > Air Conditioner > Active Test**

| TESTER DISPLAY          |
|-------------------------|
| Compressor Target Speed |

OK:

Compressor with motor assembly operates normally.

**OK** ► REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY

**NG** ► REPLACE COMPRESSOR WITH MOTOR ASSEMBLY INFO INFO

**6. CHECK FOR DTC**

(a) Check if hybrid control system DTCs are output.

**Powertrain > Hybrid Control > Trouble Codes**

| RESULT              | PROCEED TO |
|---------------------|------------|
| DTCs are not output | A          |
| DTCs are output     | B          |

**B** ► GO TO HYBRID CONTROL SYSTEM

**A**



**7. PERFORM ACTIVE TEST USING TECHSTREAM**

(a) Connect the Techstream to the DLC3.

- (b) Turn the power switch on (IG).
- (c) Turn the Techstream on.
- (d) Enter the following menus: Body Electrical / Air Conditioner / Active Test.
- (e) Perform the Active Test according to the display on the Techstream.

**Body Electrical > Air Conditioner > Active Test**

| TESTER DISPLAY          | MEASUREMENT ITEM               | CONTROL RANGE       | DIAGNOSTIC NOTE |
|-------------------------|--------------------------------|---------------------|-----------------|
| Compressor Target Speed | Compressor with motor assembly | Min.: 0, Max.: 7500 | -               |

**Body Electrical > Air Conditioner > Active Test**

| TESTER DISPLAY          |
|-------------------------|
| Compressor Target Speed |

OK:  
Compressor with motor assembly operates normally.

**OK** ► REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY

**NG** ► REPLACE COMPRESSOR WITH MOTOR ASSEMBLY INFO INFO



|  |                     |                                      |
|--|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000RW4N       |
| <b>Model Year Start:</b> 2016  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B1474/74; A/C Inverter Malfunction; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

|            |                 |                                 |
|------------|-----------------|---------------------------------|
| <b>DTC</b> | <b>B1474/74</b> | <b>A/C Inverter Malfunction</b> |
|------------|-----------------|---------------------------------|

## DESCRIPTION

| DTC NO.  | DETECTION ITEM           | DTC DETECTION CONDITION  | TROUBLE AREA   | MEMORY    |
|----------|--------------------------|--------------------------|--|-----------|
| B1474/74 | A/C Inverter Malfunction | A/C inverter malfunction | <ul style="list-style-type: none"> <li>Compressor with motor assembly</li> <li>CAN communication system</li> </ul> | Memorized |

## CAUTION / NOTICE / HINT

### CAUTION:

- Before inspecting the high-voltage system, take safety precautions such as wearing insulated gloves and removing the service plug grip to prevent electrical shocks. After removing the service plug grip, put it in your pocket to prevent other technicians from accidentally reconnecting it while you are working on the high-voltage system.
- Do not touch the high-voltage connectors or terminals for 10 minutes after the service plug grip is removed.

### NOTICE:

- After turning the power switch off, waiting time may be required before disconnecting the cable from the negative (-) auxiliary battery terminal. Therefore, make sure to read the disconnecting the cable from the negative (-) auxiliary battery terminal notices before proceeding with work.

Click here [INFO](#) [INFO](#) [INFO](#)

- The hybrid control system and air conditioning system output DTCs separately. Perform troubleshooting for the hybrid control system first if DTCs for both systems are output simultaneously.

## PROCEDURE

|           |                                       |
|-----------|---------------------------------------|
| <b>1.</b> | <b>CHECK CAN COMMUNICATION SYSTEM</b> |
|-----------|---------------------------------------|

(a) Using the Techstream, check if the CAN communication system is functioning normally.

Click here [INFO](#) [INFO](#)

| RESULT                                       | PROCEED TO |
|--|------------|
| CAN communication system DTCs are not output | A          |
| CAN communication system DTCs are output     | B          |

**A**  **REPLACE COMPRESSOR WITH MOTOR ASSEMBLY** [INFO](#) [INFO](#)



|  |                     |                                      |
|--|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000RW40       |
| <b>Model Year Start:</b> 2016  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B1475; A/C Inverter Cooling / Heating System Malfunction; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

|            |              |  |
|------------|--------------|--|
| <b>DTC</b> | <b>B1475</b> | <b>A/C Inverter Cooling / Heating System Malfunction</b> |
|------------|--------------|--|

## DESCRIPTION

The temperature sensor of the compressor with motor assembly detects the A/C inverter temperature.

If the temperature exceeds the maximum, operation of the compressor with motor assembly will be stopped, and this DTC will be stored.

| DTC NO. | DETECTION ITEM                                    | DTC DETECTION CONDITION  | TROUBLE AREA   | MEMORY    |
|---------|---|--|--|-----------|
| B1475   | A/C Inverter Cooling / Heating System Malfunction | A/C inverter temperature outside specified range (temperature too high) or open or short to ground in temperature sensor circuit | <ul style="list-style-type: none"> <li>Cooling fan system</li> <li>Refrigerant volume</li> <li>Compressor with motor assembly</li> <li>CAN communication system</li> </ul> | Memorized |

## CAUTION / NOTICE / HINT

### CAUTION:

- Before inspecting the high-voltage system, take safety precautions such as wearing insulated gloves and removing the service plug grip to prevent electrical shocks. After removing the service plug grip, put it in your pocket to prevent other technicians from accidentally reconnecting it while you are working on the high-voltage system.
- Do not touch the high-voltage connectors or terminals for 10 minutes after the service plug grip is removed.

### NOTICE:

- After turning the power switch off, waiting time may be required before disconnecting the cable from the negative (-) auxiliary battery terminal. Therefore, make sure to read the disconnecting the cable from the negative (-) auxiliary battery terminal notices before proceeding with work.

Click here [INFO](#) [INFO](#) [INFO](#)

- The hybrid control system and air conditioning system output DTCs separately. Perform troubleshooting for the hybrid control system first if DTCs for both systems are output simultaneously.

## PROCEDURE

|           |                                       |
|-----------|---------------------------------------|
| <b>1.</b> | <b>CHECK CAN COMMUNICATION SYSTEM</b> |
|-----------|---------------------------------------|

(a) Using the Techstream, check if the CAN communication system is functioning normally.



**HINT:**

Click here

INFO

INFO

| RESULT                                       | PROCEED TO |
|--|------------|
| CAN communication system DTCs are not output | A          |
| CAN communication system DTCs are output     | B          |

**B**  **GO TO CAN COMMUNICATION SYSTEM**

INFO

INFO

**A**

|           |   |
|-----------|---|
| <b>2.</b> | <b>PERFORM ACTIVE TEST USING TECHSTREAM</b> |
|-----------|---|

- (a) Connect the Techstream to the DLC3.
- (b) Turn the power switch on (IG).
- (c) Turn the Techstream on.
- (d) Enter the following menus: Powertrain / Engine / Active Test.
- (e) Perform the Active Test according to the display on the Techstream.

**Powertrain > Engine > Active Test**

| TESTER DISPLAY                 | MEASUREMENT ITEM                 | CONTROL RANGE | DIAGNOSTIC NOTE   |
|--------------------------------|----------------------------------|---------------|---|
| Control the Engine Cooling Fan | Control engine cooling fan motor | ON/OFF        | Perform this test when the following conditions are met: <ul style="list-style-type: none"> <li>• Power switch is on (IG)</li> <li>• Engine is stopped</li> <li>• Shift lever in P</li> </ul> |

**Powertrain > Engine > Active Test**

| TESTER DISPLAY                 |
|--------------------------------|
| Control the Engine Cooling Fan |

OK:

Engine cooling fan operates smoothly.

OK  
▼

**3. CHECK REFRIGERANT PRESSURE**

(a) Install a manifold gauge set.

**HINT:**


Click here [INFO](#)

(b) Turn the power switch on (READY).

(c) Read the manifold gauge pressure when the following conditions are met.

(1) Prepare the vehicle according to the table below.

| ITEM                       | CONDITION               |
|----------------------------|-------------------------|
| Vehicle doors              | Fully open              |
| Temperature setting        | MAX COLD                |
| Blower speed               | HI                      |
| A/C switch                 | On                      |
| Recirculation/fresh switch | RECIRCULATION           |
| Interior temperature       | 25 to 35°C (77 to 95°F) |



Standard Pressure:

*Low pressure side*

150 to 250 kPa (1.5 to 2.5 kgf/cm<sup>2</sup>, 22 to 36 psi)

*High pressure side*

1370 to 1570 kPa (14 to 16 kgf/cm<sup>2</sup>, 199 to 228 psi)

OK  
▼

**4. CLEAR DTC**

(a) Clear the DTCs.

Body Electrical > Air Conditioner > Clear DTCs

**NEXT**



|           |                                    |
|-----------|------------------------------------|
| <b>5.</b> | <b>READ OUTPUT DTC (DTC B1475)</b> |
|-----------|------------------------------------|

(a) Turn the power switch on (READY).

(b) Prepare the vehicle according to the table below.

| ITEM                | CONDITION |
|---------------------|-----------|
| Blower speed        | HI        |
| A/C switch          | On        |
| Temperature setting | MAX COLD  |

(c) Check for DTCs.

Body Electrical > Air Conditioner > Trouble Codes


| RESULT              | PROCEED TO |
|---------------------|------------|
| B1475 is not output | A          |
| B1475 is output     | B          |

**NOTICE:**

If the engine idles continuously when ambient temperature is high, the compressor with motor assembly may automatically stop to protect the inverter circuit, and DTC B1475 may be stored.

**A**  **SYSTEM IS OK**

**B**  **REPLACE COMPRESSOR WITH MOTOR ASSEMBLY**



|  |                     |                                      |
|--|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000RW4P       |
| <b>Model Year Start:</b> 2016  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B1476/76; A/C Inverter Load System Malfunction; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

|            |                 |   |
|------------|-----------------|---|
| <b>DTC</b> | <b>B1476/76</b> | <b>A/C Inverter Load System Malfunction</b> |
|------------|-----------------|---|

## DESCRIPTION

The operation of the compressor with motor assembly is stopped and this DTC is stored if the rotation load is too large or too small while the compressor with motor assembly is operating.

Possible causes are refrigerant leaks, overcharged refrigerant, insufficient cooling due to a condenser fan circuit malfunction, or compressor lock.

| DTC NO.  | DETECTION ITEM                       | DTC DETECTION CONDITION   | TROUBLE AREA   | MEMORY    |
|----------|--------------------------------------|---|--|-----------|
| B1476/76 | A/C Inverter Load System Malfunction | Motor rotation load while compressor is operating is too large or too small | <ul style="list-style-type: none"> <li>Refrigerant volume</li> <li>Compressor with motor assembly</li> <li>Cooling fan system</li> <li>CAN communication system</li> </ul> | Memorized |

## CAUTION / NOTICE / HINT

### CAUTION:

- Before inspecting the high-voltage system, take safety precautions such as wearing insulated gloves and removing the service plug grip to prevent electrical shocks. After removing the service plug grip, put it in your pocket to prevent other technicians from accidentally reconnecting it while you are working on the high-voltage system.
- Do not touch the high-voltage connectors or terminals for 10 minutes after the service plug grip is removed.

### NOTICE:

- After turning the power switch off, waiting time may be required before disconnecting the cable from the negative (-) auxiliary battery terminal. Therefore, make sure to read the disconnecting the cable from the negative (-) auxiliary battery terminal notices before proceeding with work.

Click here [INFO](#) [INFO](#) [INFO](#)

- The hybrid control system and air conditioning system output DTCs separately. Perform troubleshooting for the hybrid control system first if DTCs for both systems are output simultaneously.

## PROCEDURE

|           |                                       |
|-----------|---------------------------------------|
| <b>1.</b> | <b>CHECK CAN COMMUNICATION SYSTEM</b> |
|-----------|---------------------------------------|

(a) Using the Techstream, check if the CAN communication system is functioning normally.

Click here [INFO](#) [INFO](#)

| RESULT                                       | PROCEED TO |
|--|------------|
| CAN communication system DTCs are not output | A          |
| CAN communication system DTCs are output     | B          |

**B**  **GO TO CAN COMMUNICATION SYSTEM** [INFO](#) [INFO](#)

**A**  
▼

|           |   |
|-----------|---|
| <b>2.</b> | <b>PERFORM ACTIVE TEST USING TECHSTREAM</b> |
|-----------|---|

- (a) Connect the Techstream to the DLC3.
- (b) Turn the power switch on (IG).
- (c) Turn the Techstream on.
- (d) Enter the following menus: Powertrain / Engine and ECT / Active Test.
- (e) Perform the Active Test according to the display on the Techstream.

**Powertrain > Engine > Active Test**

| TESTER DISPLAY                 | MEASUREMENT ITEM                 | CONTROL RANGE | DIAGNOSTIC NOTE   |
|--------------------------------|----------------------------------|---------------|---|
| Control the Engine Cooling Fan | Control engine cooling fan motor | ON/OFF        | Perform this test when the following conditions are met: <ul style="list-style-type: none"> <li>• Power switch is on (IG)</li> <li>• Engine is stopped</li> <li>• Shift lever in P</li> </ul> |

**Powertrain > Engine > Active Test**

| TESTER DISPLAY                 |
|--------------------------------|
| Control the Engine Cooling Fan |

**NG**  **GO TO COOLING FAN SYSTEM**

**3. CHECK REFRIGERANT PRESSURE**

(a) Install a manifold gauge set.


Click here [INFO](#)

(b) Turn the power switch on (READY).

(c) Read the manifold gauge pressure when the following conditions are met.

(1) Prepare the vehicle according to the table below.

| ITEM                       | CONDITION               |
|----------------------------|-------------------------|
| Vehicle doors              | Fully open              |
| Temperature setting        | MAX COLD                |
| Blower speed               | HI                      |
| A/C switch                 | On                      |
| Recirculation/fresh switch | RECIRCULATION           |
| Interior temperature       | 25 to 35°C (77 to 95°F) |



Standard Pressure:

*Low pressure side*


150 to 250 kPa (1.5 to 2.5 kgf/cm<sup>2</sup>, 22 to 36 psi)

*High pressure side*

1370 to 1570 kPa (14 to 16 kgf/cm<sup>2</sup>, 199 to 228 psi)

**OK** ▶ REPLACE COMPRESSOR WITH MOTOR ASSEMBLY [INFO](#) [INFO](#)

**NG** ▶ CHARGE REFRIGERANT



|  |                     |                                      |
|--|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000RW4Q       |
| <b>Model Year Start:</b> 2016  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B1477/77; A/C Inverter Low Voltage Power Resource System Malfunction; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

|            |                 |   |
|------------|-----------------|---|
| <b>DTC</b> | <b>B1477/77</b> | <b>A/C Inverter Low Voltage Power Resource System Malfunction</b> |
|------------|-----------------|---|

## DESCRIPTION

The compressor with motor assembly monitors the inverter control power source voltage. The hybrid vehicle control ECU stops the compressor control and stores this DTC if the monitored voltage is outside the specified range.

This DTC will be stored as a history DTC. Compressor control may not resume unless the power switch is turned off.

| DTC NO.  | DETECTION ITEM   | DTC DETECTION CONDITION   | TROUBLE AREA   | MEMORY    |
|----------|--|---|--|-----------|
| B1477/77 | A/C Inverter Low Voltage Power Resource System Malfunction | Open or short to ground in inverter control power voltage circuit | <ul style="list-style-type: none"> <li>Compressor with motor assembly</li> <li>CAN communication system</li> </ul> | Memorized |

## CAUTION / NOTICE / HINT

### CAUTION:

- Before inspecting the high-voltage system, take safety precautions such as wearing insulated gloves and removing the service plug grip to prevent electrical shocks. After removing the service plug grip, put it in your pocket to prevent other technicians from accidentally reconnecting it while you are working on the high-voltage system.
- Do not touch the high-voltage connectors or terminals for 10 minutes after the service plug grip is removed.

### NOTICE:

- After turning the power switch off, waiting time may be required before disconnecting the cable from the negative (-) auxiliary battery terminal. Therefore, make sure to read the disconnecting the cable from the negative (-) auxiliary battery terminal notices before proceeding with work.

Click here [INFO](#) [INFO](#) [INFO](#)

- The hybrid control system and air conditioning system output DTCs separately. Perform troubleshooting for the hybrid control system first if DTCs for both systems are output simultaneously.

## PROCEDURE

|           |                                       |
|-----------|---------------------------------------|
| <b>1.</b> | <b>CHECK CAN COMMUNICATION SYSTEM</b> |
|-----------|---------------------------------------|

(a) Using the Techstream, check if the CAN communication system is functioning normally.

Click here [INFO](#) [INFO](#)

| RESULT | PROCEED TO |
|--------|------------|
|        |            |

|  |   |
|--|---|
| CAN communication system DTCs are not output | A |
| CAN communication system DTCs are output     | B |

**A** ▶ REPLACE COMPRESSOR WITH MOTOR ASSEMBLY [INFO](#) [INFO](#)  
[INFO](#) [INFO](#)

**B** ▶ GO TO CAN COMMUNICATION SYSTEM [INFO](#) [INFO](#) [INFO](#) [INFO](#)





|  |                     |                                      |
|--|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM100000001FYJZ       |
| <b>Model Year Start:</b> 2019  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [12/2018 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B1497; BUS IC Communication Malfunction; 2019 MY Prius [12/2018 - ] |                     |                                      |

|            |              |   |
|------------|--------------|---|
| <b>DTC</b> | <b>B1497</b> | <b>BUS IC Communication Malfunction</b> |
|------------|--------------|---|


## DESCRIPTION

The air conditioning harness assembly connects the air conditioning amplifier assembly and the servo motors. The air conditioning amplifier assembly supplies power and sends operation instructions to each servo motor through the air conditioning harness assembly. Each servo motor sends damper position information to the air conditioning amplifier assembly.

| DTC NO. | DETECTION ITEM                   | DTC DETECTION CONDITION             | TROUBLE AREA  | MEMORY                       |
|---------|----------------------------------|-------------------------------------|---|------------------------------|
| B1497   | BUS IC Communication Malfunction | Error or open in communication line | <ul style="list-style-type: none"> <li>• Air conditioning harness assembly</li> <li>• No. 1 air conditioning radiator damper servo sub-assembly</li> <li>• No. 2 air conditioning radiator damper servo sub-assembly</li> <li>• No. 3 air conditioning radiator damper servo sub-assembly</li> <li>• Air conditioning amplifier assembly</li> </ul> | Memorized (10 sec. or more)* |

\*: The air conditioning amplifier assembly stores this DTC if the malfunction has occurred for the period of time indicated in the brackets.

## WIRING DIAGRAM



H

## PROCEDURE

1. PERFORM ACTIVE TEST USING TECHSTREAM

- (a) Connect the Techstream to the DLC3.
- (b) Turn the power switch on (IG).
- (c) Turn the Techstream on.
- (d) Enter the following menus: Body Electrical / Air Conditioner / Active test.
- (e) Perform the Active Test according to the display on the Techstream.

**Body Electrical > Air Conditioner > Active Test**

| TESTER DISPLAY              | MEASUREMENT ITEM  | CONTROL RANGE          | DIAGNOSTIC NOTE                    |
|-----------------------------|---|------------------------|------------------------------------|
| Air Mix Servo Targ Pulse(D) | No. 2 air conditioning radiator damper servo sub-assembly (air mix) pulse | Min.: 128<br>Max.: 383 | Operates between 165 to 257 pulses |
| Air Outlet Servo Pulse (D)  | No. 1 air conditioning radiator damper servo sub-assembly pulse           | Min.: 128<br>Max.: 383 | Operates between 164 to 256 pulses |
| A/O Servo Pulse(Rr D)       | No. 3 air conditioning radiator damper servo sub-assembly pulse           | Min.: 128<br>Max.: 383 | Operates between 250 to 297 pulses |

**Body Electrical > Air Conditioner > Active Test**

| TESTER DISPLAY              |
|-----------------------------|
| Air Mix Servo Targ Pulse(D) |

**Body Electrical > Air Conditioner > Active Test**

| TESTER DISPLAY             |
|----------------------------|
| Air Outlet Servo Pulse (D) |

**Body Electrical > Air Conditioner > Active Test**

| TESTER DISPLAY        |
|-----------------------|
| A/O Servo Pulse(Rr D) |

OK:

Each damper servo motor operates smoothly.

| RESULT  | PROCEED TO |
|---|------------|
| All of the damper servo motors are malfunctioning | A          |

Any of the damper servo motors is normal.

B

**B**  **GO TO STEP 4**

**A**



**2. PERFORM ACTIVE TEST USING TECHSTREAM**

- (a) Disconnect the No. 2 air conditioning radiator damper servo sub-assembly connector.
- (b) Connect the Techstream to the DLC3.
- (c) Turn the power switch on (IG).
- (d) Turn the Techstream on.
- (e) Enter the following menus: Body Electrical / Air Conditioner / Active test.
- (f) Perform the Active Test according to the display on the Techstream.

**Body Electrical > Air Conditioner > Active Test**

| TESTER DISPLAY        | MEASUREMENT ITEM  | CONTROL RANGE          | DIAGNOSTIC NOTE                    |
|-----------------------|---|------------------------|------------------------------------|
| A/O Servo Pulse(Rr D) | No. 3 air conditioning radiator damper servo sub-assembly pulse | Min.: 128<br>Max.: 383 | Operates between 250 to 297 pulses |


**Body Electrical > Air Conditioner > Active Test**

| TESTER DISPLAY        |
|-----------------------|
| A/O Servo Pulse(Rr D) |

OK:  
The damper servo motor operates smoothly.

**OK**  **REPLACE NO. 2 AIR CONDITIONING RADIATOR DAMPER SERVO SUB-ASSEMBLY**

**NG**



### 3. INSPECT AIR CONDITIONING AMPLIFIER ASSEMBLY

**NOTICE:**

When inspecting the air conditioning amplifier assembly, do not bring the tester probes too close to each other as a short circuit may occur.

- (a) Disconnect the z23 air conditioning amplifier assembly connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(z23\)](#)

[Click Connector\(z23\)](#)

| TESTER CONNECTION          | CONDITION | SPECIFIED CONDITION |
|----------------------------|-----------|---------------------|
| z23-2 (BUSG) - Body ground | Always    | Below 1 $\Omega$    |

- (c) Measure the voltage according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(z23\)](#)

[Click Connector\(z23\)](#)

| TESTER CONNECTION          | CONDITION            | SPECIFIED CONDITION |
|----------------------------|----------------------|---------------------|
| z23-4 (BBUS) - Body ground | Power switch on (IG) | 11 to 14 V          |

- (d) Turn the power switch on (IG).

- (e) Connect an oscilloscope to terminals z23-2 (BUSG) and z23-3 (BUS) of the air conditioning amplifier assembly and check the waveform.

OK:


Waveform is similar to that shown in the illustration.

**HINT:**

The waveform varies with the blower speed.

| ITEM         | CONTENT              |
|--------------|----------------------|
| Tool Setting | 2 V/DIV., 2 ms./DIV. |

|                   |                      |
|-------------------|----------------------|
|                   |                      |
| Vehicle Condition | Power switch on (IG) |



|    |  |
|----|--|
| *a | Component with harness connected (Air Conditioning Amplifier Assembly) |
|----|--|

**OK** ► REPLACE AIR CONDITIONING HARNESS ASSEMBLY

**NG** ► REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY

**4. PERFORM ACTIVE TEST USING TECHSTREAM**

- (a) Connect the Techstream to the DLC3.
- (b) Turn the power switch on (IG).
- (c) Turn the Techstream on.
- (d) Enter the following menus: Body Electrical / Air Conditioner / Active test.
- (e) Perform the Active Test according to the display on the Techstream.

**Body Electrical > Air Conditioner > Active Test**

| TESTER DISPLAY     | MEASUREMENT ITEM                                  | CONTROL RANGE | DIAGNOSTIC NOTE         |
|--------------------|---|---------------|-------------------------|
| Air Mix Servo Targ | No. 2 air conditioning radiator damper servo sub- | Min.: 128     | Operates between 165 to |

|                            |   |                        |                                    |
|----------------------------|---|------------------------|------------------------------------|
| Pulse(D)                   | assembly (air mix) pulse  | Max.: 383              | 257 pulses                         |
| Air Outlet Servo Pulse (D) | No. 1 air conditioning radiator damper servo sub-assembly pulse | Min.: 128<br>Max.: 383 | Operates between 164 to 256 pulses |
| A/O Servo Pulse(Rr D)      | No. 3 air conditioning radiator damper servo sub-assembly pulse | Min.: 128<br>Max.: 383 | Operates between 250 to 297 pulses |

**Body Electrical > Air Conditioner > Active Test**

|                             |
|-----------------------------|
| TESTER DISPLAY              |
| Air Mix Servo Targ Pulse(D) |

**Body Electrical > Air Conditioner > Active Test**

|                            |
|----------------------------|
| TESTER DISPLAY             |
| Air Outlet Servo Pulse (D) |

**Body Electrical > Air Conditioner > Active Test**

|                       |
|-----------------------|
| TESTER DISPLAY        |
| A/O Servo Pulse(Rr D) |

OK:  
Each damper servo motor operates smoothly.

| RESULT   | PROCEED TO |
|--|------------|
| Only the No. 2 air conditioning radiator damper servo sub-assembly does not operate. | A          |
| Only the No. 1 air conditioning radiator damper servo sub-assembly does not operate. | B          |
| Only the No. 3 air conditioning radiator damper servo sub-assembly does not operate. |            |
| Only the No. 1 air conditioning radiator damper servo sub-assembly operates.         |            |

**B** ▶ REPLACE AIR CONDITIONING HARNESS ASSEMBLY

**A**  
▼

|  |
|--|
| INSPECT AIR CONDITIONING HARNESS ASSEMBLY (AIR CONDITIONING AMPLIFIER) |
|--|

5.

**ASSEMBLY - NO. 2 AIR CONDITIONING RADIATOR DAMPER SERVO SUB-ASSEMBLY)**

- (a) Disconnect the z23 air conditioning amplifier assembly connector.
- (b) Disconnect the No. 2 air conditioning radiator damper servo sub-assembly connector.
- (c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:




[Click Location & Routing\(z23\)](#)

[Click Connector\(z23\)](#)

| TESTER CONNECTION      | CONDITION | SPECIFIED CONDITION |
|------------------------|-----------|---------------------|
| z23-2 (BUSG) - 3 (GND) | Always    | Below 1 $\Omega$    |
| z23-3 (BUS) - 2 (LIN)  | Always    | Below 1 $\Omega$    |
| z23-4 (BBUS) - 1 (+B)  | Always    | Below 1 $\Omega$    |

**OK** ► **REPLACE NO. 2 AIR CONDITIONING RADIATOR DAMPER SERVO SUB-ASSEMBLY**

**NG** ► **REPLACE AIR CONDITIONING HARNESS ASSEMBLY**





|   |                     |  |
|---|---------------------|--|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000RW4R           |
| <b>Model Year Start:</b> 2016   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 -     ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: B1498; Communication Malfunction (A/C Inverter Local); 2016 - 2019 MY Prius [11/2015 -     ] |                     |  |

|            |              |   |
|------------|--------------|---|
| <b>DTC</b> | <b>B1498</b> | <b>Communication Malfunction (A/C Inverter Local)</b> |
|------------|--------------|---|

## DESCRIPTION


The hybrid vehicle control ECU and compressor with motor assembly communicate via direct line. Compressor control is stopped and this DTC is stored if communication information is cut off or abnormal information is received.

This DTC is also detected if high-voltage electricity supplied from the inverter with converter assembly to the compressor control circuit is shut off.

This DTC will be stored as a history DTC.

| DTC NO. | DETECTION ITEM                                 | DTC DETECTION CONDITION   | TROUBLE AREA  | MEMORY    |
|---------|--|---|---|-----------|
| B1498   | Communication Malfunction (A/C Inverter Local) | <ul style="list-style-type: none"> <li>Error or open in communication line between the hybrid vehicle control ECU and compressor with motor assembly</li> <li>High-voltage power source shut off</li> </ul> | <ul style="list-style-type: none"> <li>Harness or connector between compressor with motor assembly and body ground</li> <li>Harness or connector between hybrid vehicle control ECU and compressor with motor assembly, battery state sensor assembly</li> <li>Hybrid vehicle control ECU</li> <li>Compressor with motor assembly</li> <li>Air conditioning wire (harness or connector between compressor with motor assembly and inverter with converter assembly)</li> <li>CAN communication system</li> <li>Hybrid control system</li> </ul> | Memorized |

## WIRING DIAGRAM



## CAUTION / NOTICE / HINT

### CAUTION:

- Before inspecting the high-voltage system, take safety precautions such as wearing insulated gloves and removing the service plug grip to prevent electrical shocks. After removing the service plug grip, put it in your pocket to prevent other technicians from accidentally reconnecting it while you are working on the high-voltage system.
- Do not touch the high-voltage connectors or terminals for 10 minutes after the service plug grip is removed.

### NOTICE:

- Inspect the fuses for circuits related to this system before performing the following procedure.
- After turning the power switch off, waiting time may be required before disconnecting the cable from the negative (-)

auxiliary battery terminal. Therefore, make sure to read the disconnecting the cable from the negative (-) auxiliary battery terminal notices before proceeding with work.

Click here [INFO](#) [INFO](#) [INFO](#)

- The hybrid control system and air conditioning system output DTCs separately. Perform troubleshooting for the hybrid control system first if DTCs for both systems are output simultaneously.
- Depending on the timing of the power supply to the 12 V power supply circuit and high-voltage circuit when the power switch is turned on (READY), an abnormal information signal may be output, causing this DTC to be stored. If the output DTC is a code that was memorized in the past, check the fuses and wire harnesses. If there is no malfunction, clear the DTC.

## PROCEDURE

### 1. CHECK CAN COMMUNICATION SYSTEM

(a) Using the Techstream, check if the CAN communication system is functioning normally.

#### HINT:

Click here [INFO](#) [INFO](#)

| RESULT                                       | PROCEED TO |
|--|------------|
| CAN communication system DTCs are not output | A          |
| CAN communication system DTCs are output     | B          |

**B**  GO TO CAN COMMUNICATION SYSTEM [INFO](#) [INFO](#)

**A**



### 2. CHECK FOR DTC

(a) Check if hybrid control system DTCs are output.

**Powertrain > Hybrid Control > Trouble Codes**

| RESULT                                  | PROCEED TO |
|---|------------|
| Both P058A01 and P162B87 are not output | A          |
| P058A01 and P162B87 are output          | B          |

**B**  GO TO STEP 9

A



|    |   |
|----|---|
| 3. | <b>CHECK HARNESS AND CONNECTOR (COMPRESSOR WITH MOTOR ASSEMBLY - BODY GROUND)</b> |
|----|---|

**CAUTION:**

Do not disconnect the connector on the high-voltage side.

- (a) Disconnect the C12 compressor with motor assembly connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(C12\)](#)

[Click Connector\(C12\)](#)

| TESTER CONNECTION         | CONDITION | SPECIFIED CONDITION |
|---------------------------|-----------|---------------------|
| C12-2 (GND) - Body ground | Always    | Below 1 Ω           |

**NG** REPAIR OR REPLACE HARNESS OR CONNECTOR

OK



|    |  |
|----|--|
| 4. | <b>CHECK HARNESS AND CONNECTOR (COMPRESSOR WITH MOTOR ASSEMBLY - IG CIRCUIT, GROUND)</b> |
|----|--|

- (a) Measure the voltage according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(C12\)](#)

[Click Connector\(C12\)](#)

| TESTER CONNECTION         | CONDITION            | SPECIFIED CONDITION |
|---------------------------|----------------------|---------------------|
| C12-1 (IG1) - C12-2 (GND) | Power switch on (IG) | 11 to 14 V          |
| C12-1 (IG1) - C12-2 (GND) | Power switch off     | Below 1 V           |

**NG** REPAIR OR REPLACE HARNESS OR CONNECTOR

OK



|           |  |
|-----------|--|
| <b>5.</b> | <b>CHECK HARNESS AND CONNECTOR (HYBRID VEHICLE CONTROL ECU - COMPRESSOR WITH MOTOR ASSEMBLY)</b> |
|-----------|--|

- (a) Disconnect the A50 hybrid vehicle control ECU connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A50\)](#)

[Click Location & Routing\(C12\)](#)

[Click Connector\(A50\)](#)

[Click Connector\(C12\)](#)

| TESTER CONNECTION                          | CONDITION | SPECIFIED CONDITION |
|--|-----------|---------------------|
| A50-8 (LIN3) - C12-3 (DOUT)                | Always    | Below 1 Ω           |
| A50-8 (LIN3) or C12-3 (DOUT) - Body ground | Always    | 10 kΩ or higher     |

**NG** **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK



|           |                                      |
|-----------|--------------------------------------|
| <b>6.</b> | <b>INSPECT AIR CONDITIONING WIRE</b> |
|-----------|--------------------------------------|

**CAUTION:**

Be sure to wear insulated gloves.

- (a) Disconnect the T1 and T2 air conditioning wire connectors.

**HINT:**

[Click here](#)

- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(T1,T2\)](#)

[Click Connector\(T1\)](#)

[Click Connector\(T2\)](#)

| TESTER CONNECTION                      | CONDITION | SPECIFIED CONDITION     |
|--|-----------|-------------------------|
| T1-2 (PB) - T2-1 (ACPB)                | Always    | Below 1 $\Omega$        |
| T1-2 (PB) or T2-1 (ACPB) - Body ground | Always    | 10 k $\Omega$ or higher |

**NG**  **GO TO STEP 8**

**OK**



**7. INSPECT AIR CONDITIONING WIRE**

**CAUTION:**

Be sure to wear insulated gloves.

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(T1,T2\)](#)

[Click Connector\(T1\)](#)

[Click Connector\(T2\)](#)

| TESTER CONNECTION                      | CONDITION | SPECIFIED CONDITION     |
|--|-----------|-------------------------|
| T1-1 (PE) - T2-2 (ACPE)                | Always    | Below 1 $\Omega$        |
| T1-1 (PE) or T2-2 (ACPE) - Body ground | Always    | 10 k $\Omega$ or higher |

**OK**  **REPLACE COMPRESSOR WITH MOTOR ASSEMBLY**    
 

**NG**  **REPLACE AIR CONDITIONING WIRE**    

**8. INSPECT AIR CONDITIONING WIRE**

**CAUTION:**

Be sure to wear insulated gloves.

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

[Click Location & Routing\(T1\)](#)

[Click Connector\(T1\)](#)

| TESTER CONNECTION       | CONDITION | SPECIFIED CONDITION |
|-------------------------|-----------|---------------------|
| T1-2 (PB) - Body ground | Always    | 10 kΩ or higher     |

**OK**  **REPLACE COMPRESSOR WITH MOTOR ASSEMBLY**    
 

**NG**  **REPLACE AIR CONDITIONING WIRE**    

**9. CHECK FOR DTC**

- (a) Disconnect the C19 battery state sensor assembly connector.
- (b) Check if air conditioning system DTCs are output.

**Body Electrical > Air Conditioner > Trouble Codes**

| RESULT              | PROCEED TO |
|---------------------|------------|
| B1498 is not output | A          |
| B1498 is output     | B          |

**A**  **REPLACE BATTERY STATE SENSOR ASSEMBLY**  

**B**  


**10. CHECK FOR DTC**

- (a) Reconnect the C19 battery state sensor assembly connector.
- (b) Disconnect the C12 compressor with motor assembly connector.
- (c) Check if hybrid control system DTCs are output.

**Powertrain > Hybrid Control > Trouble Codes**

| RESULT | PROCEED TO |
|--------|------------|
|        |            |

|   |   |
|---|---|
| Both P058A01 and P162B87 are not output | A |
| P058A01 and P162B87 are output          | B |

**A** ▶ REPLACE COMPRESSOR WITH MOTOR ASSEMBLY INFO INFO

**B**



**11. CHECK HARNESS AND CONNECTOR (HYBRID VEHICLE CONTROL ECU - COMPRESSOR WITH MOTOR ASSEMBLY, BATTERY STATE SENSOR ASSEMBLY)**

- (a) Disconnect the A50 hybrid vehicle control ECU connector.
- (b) Disconnect the C19 battery state sensor assembly connector.
- (c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A50\)](#)

[Click Location & Routing\(C12,C19\)](#)

[Click Connector\(A50\)](#)

[Click Connector\(C12\)](#)

[Click Connector\(C19\)](#)

| TESTER CONNECTION                          | CONDITION | SPECIFIED CONDITION |
|--|-----------|---------------------|
| A50-8 (LIN3) - C12-3 (DOUT)                | Always    | Below 1 Ω           |
| A50-8 (LIN3) - C19-2 (LIN)                 | Always    | Below 1 Ω           |
| A50-8 (LIN3) or C12-3 (DOUT) - Body ground | Always    | 10 kΩ or higher     |
| A50-8 (LIN3) or C19-2 (LIN) - Body ground  | Always    | 10 kΩ or higher     |

**OK** ▶ REPLACE HYBRID VEHICLE CONTROL ECU INFO INFO

**NG** ▶ REPAIR OR REPLACE HARNESS OR CONNECTOR






|  |                     |                                      |
|--|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000RW30       |
| <b>Model Year Start:</b> 2016  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: Back-up Power Source Circuit; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

## Back-up Power Source Circuit

## DESCRIPTION

The back-up power source circuit for the air conditioning amplifier assembly is shown below. Power is supplied even when the power switch is off. This power is used for diagnostic trouble code memory, etc.

## WIRING DIAGRAM



## CAUTION / NOTICE / HINT

### NOTICE:

Inspect the fuses for circuits related to this system before performing the following procedure.

## PROCEDURE

|           |   |
|-----------|---|
| <b>1.</b> | <b>CHECK HARNESS AND CONNECTOR (AIR CONDITIONING AMPLIFIER ASSEMBLY - POWER SOURCE)</b> |
|-----------|---|

- (a) Disconnect the F58 air conditioning amplifier assembly connector.
- (b) Measure the voltage according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(F58\)](#)

[Click Connector\(F58\)](#)

| TESTER CONNECTION       | CONDITION        | SPECIFIED CONDITION |
|-------------------------|------------------|---------------------|
| F58-1 (B) - Body ground | Power switch off | 11 to 14 V          |

**NG** ► REPAIR OR REPLACE HARNESS OR CONNECTOR

**OK**



|           |  |
|-----------|--|
| <b>2.</b> | <b>CHECK HARNESS AND CONNECTOR (AIR CONDITIONING AMPLIFIER ASSEMBLY - BODY GROUND)</b> |
|-----------|--|

- (a) Disconnect the F58 air conditioning amplifier assembly connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(F58\)](#)

[Click Connector\(F58\)](#)

| TESTER CONNECTION         | CONDITION | SPECIFIED CONDITION |
|---------------------------|-----------|---------------------|
| F58-4 (GND) - Body ground | Always    | Below 1 $\Omega$    |

**OK** ► PROCEED TO NEXT SUSPECTED AREA SHOWN IN PROBLEM SYMPTOMS TABLE [INFO](#) [INFO](#) [INFO](#)

**NG** ► REPAIR OR REPLACE HARNESS OR CONNECTOR




|  |              |                               |
|--|--------------|-------------------------------|
| Last Modified: 01-14-2019  | 6.8:8.0.48   | Doc ID: RM100000001FZTN       |
| Model Year Start: 2019   | Model: Prius | Prod Date Range: [12/2018 - ] |
| Title: HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: Blower Motor Circuit; 2019 MY Prius [12/2018 - ] |              |                               |

## Blower Motor Circuit

### DESCRIPTION

The blower motor with fan sub-assembly is operated by signals from the air conditioning amplifier assembly. Blower motor speed signals are transmitted in accordance with changes in the duty ratio.

### WIRING DIAGRAM



### CAUTION / NOTICE / HINT

#### NOTICE:

Inspect the fuses for circuits related to this system before performing the following procedure.

### PROCEDURE

#### 1. PERFORM ACTIVE TEST USING TECHSTREAM

- Connect the Techstream to the DLC3.
- Turn the power switch on (IG).
- Turn the Techstream on.
- Enter the following menus: Body Electrical / Air Conditioner / Active Test.
- Perform the Active Test according to the display on the Techstream.

Body Electrical > Air Conditioner > Active Test



| TESTER DISPLAY | MEASUREMENT ITEM                   | CONTROL RANGE     | DIAGNOSTIC NOTE |
|----------------|------------------------------------|-------------------|-----------------|
| Blower Motor   | Blower motor with fan sub-assembly | Min.: 0, Max.: 31 | -               |

**Body Electrical > Air Conditioner > Active Test**

| TESTER DISPLAY |
|----------------|
| Blower Motor   |

| RESULT   | PROCEED TO |
|--|------------|
| OK   | A          |
| NG (Blower motor with fan sub-assembly does not operate)                   | B          |
| NG (Blower motor with fan sub-assembly operates but does not change speed) | C          |

**A** ► **PROCEED TO NEXT SUSPECTED AREA SHOWN IN PROBLEM SYMPTOMS TABLE**

**C** ► **GO TO STEP 6**

**B**  
▼

|           |   |
|-----------|---|
| <b>2.</b> | <b>CHECK HARNESS AND CONNECTOR (BLOWER MOTOR WITH FAN SUB-ASSEMBLY - BODY GROUND)</b> |
|-----------|---|

(a) Disconnect the A63 blower motor with fan sub-assembly connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A63\)](#)

[Click Connector\(A63\)](#)

| TESTER CONNECTION         | CONDITION | SPECIFIED CONDITION |
|---------------------------|-----------|---------------------|
| A63-1 (GND) - Body ground | Always    | Below 1 Ω           |

**REPAIR OR REPLACE HARNESS OR CONNECTOR**

NG 

OK



|    |   |
|----|---|
| 3. | <b>CHECK HARNESS AND CONNECTOR (BLOWER MOTOR WITH FAN SUB-ASSEMBLY - AUXILIARY BATTERY)</b> |
|----|---|

(a) Measure the voltage according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(A63\)](#)

[Click Connector\(A63\)](#)

| TESTER CONNECTION        | CONDITION        | SPECIFIED CONDITION |
|--------------------------|------------------|---------------------|
| A63-3 (+B) - Body ground | Power switch off | 11 to 14 V          |

NG  **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK



|    |   |
|----|---|
| 4. | <b>CHECK HARNESS AND CONNECTOR (AIR CONDITIONING AMPLIFIER ASSEMBLY - BLOWER MOTOR WITH FAN SUB-ASSEMBLY)</b> |
|----|---|

(a) Disconnect the F58 air conditioning amplifier assembly connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(F58\)](#)

[Click Location & Routing\(A63\)](#)

[Click Connector\(F58\)](#)

[Click Connector\(A63\)](#)

| TESTER CONNECTION                       | CONDITION | SPECIFIED CONDITION     |
|---|-----------|-------------------------|
| F58-6 (BLW) - A63-2 (SI)                | Always    | Below 1 $\Omega$        |
| F58-6 (BLW) or A63-2 (SI) - Body ground | Always    | 10 k $\Omega$ or higher |

**NG**  **REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**



**5. INSPECT BLOWER MOTOR WITH FAN SUB-ASSEMBLY**

- (a) Reconnect the A63 blower motor with fan sub-assembly connector.
- (b) Measure the voltage according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(F58\)](#)

[Click Connector\(F58\)](#)

| TESTER CONNECTION         | CONDITION | SPECIFIED CONDITION |
|---------------------------|-----------|---------------------|
| F58-6 (BLW) - Body ground | Always    | 4.75 to 5.25 V      |

**NG**  **REPLACE BLOWER MOTOR WITH FAN SUB-ASSEMBLY**

**OK**



**6. INSPECT AIR CONDITIONING AMPLIFIER ASSEMBLY**

- (a) Reconnect the F58 air conditioning amplifier assembly connector.
- (b) Turn the power switch on (IG).
- (c) Turn the blower switch on (LO).

- (d) Connect an oscilloscope to terminals F58-6 (BLW) and F58-4 (GND) of the air conditioning amplifier assembly and


check the waveform.

OK:  
Waveform is similar to that shown in the illustration.

**HINT:**

The waveform varies with the blower speed.

| ITEM              | CONTENT   |
|-------------------|---|
| Tool Setting      | 2 V/DIV., 1 ms./DIV.  |
| Vehicle Condition | <ul style="list-style-type: none"> <li>• Power switch on (IG)</li> <li>• Blower switch: LO</li> </ul> |



\*a Component with harness connected (Air Conditioning Amplifier Assembly)

**OK** ► REPLACE BLOWER MOTOR WITH FAN SUB-ASSEMBLY

**NG** ► REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY




|   |              |                               |
|---|--------------|-------------------------------|
| Last Modified: 01-14-2019   | 6.8:8.0.48   | Doc ID: RM1000000018JLL       |
| Model Year Start: 2018  | Model: Prius | Prod Date Range: [11/2017 - ] |
| Title: HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: CHECK MODE PROCEDURE; 2018 - 2019 MY Prius [11/2017 - ] |              |                               |

## CHECK MODE PROCEDURE

### REFRIGERANT SHORTAGE CHECK IN NORMAL OPERATION (CHECK A/C SWITCH INDICATOR AND DTC)

- (a) Turn the power switch on (READY).
- (b) Check that the A/C switch indicator remains on when the following conditions are met.



|    |  |    |  |
|----|--|----|--|
| *1 | Air Conditioning Control Assembly (for 7 Inch Display) | *2 | Navigation Receiver Assembly (for 11.6 Inch Display) |
|----|--|----|--|

#### Measurement Condition:

| ITEM                       | CONDITION               |
|----------------------------|-------------------------|
| A/C switch                 | On                      |
| A/C operation time         | 15 minutes or more      |
| Ambient temperature*       | 0 to 49°C (32 to 120°F) |
| Engine coolant temperature | 45°C (113°F) or more    |

\*: If the ambient temperature is not within the range shown, do not perform this check.

#### HINT:

The A/C switch indicator and air conditioning system turn off if the amount of refrigerant in the system is insufficient.

- (c) Connect the Techstream to the DLC3.
- (d) Check for DTC B14B8.

Click here [INFO](#)

#### Result:

| RESULT | AMOUNT OF REFRIGERANT | CORRECTIVE ACTION |
|--------|-----------------------|-------------------|
|        |                       |                   |




|                         |                         |  |
|-------------------------|-------------------------|--|
| DTC B14B8 is output     | Empty or nearly empty   | Check for refrigerant leaks using a halogen leak detector, and repair if necessary.<br>Click here <a href="#">INFO</a> |
| DTC B14B8 is not output | Correct or insufficient | Perform a refrigerant shortage check using the Techstream.   |

## REFRIGERANT SHORTAGE CHECK USING TECHSTREAM

- Connect the Techstream to the DLC3.
- Turn the power switch on (READY).
- Turn the Techstream on.
- Enter the following menus: Body Electrical / Air Conditioner / Utility / Refrigerant Gas Volume Check.

### Body Electrical > Air Conditioner > Utility



- According to the display on the Techstream, perform the refrigerant shortage check when the following conditions are met.

### Measurement Condition:

| ITEM                 | CONDITION               |
|----------------------|-------------------------|
| A/C switch           | On                      |
| Ambient temperature* | 0 to 49°C (32 to 120°F) |
| Blower speed         | HI                      |


\*: If the ambient temperature is not within the range shown, do not perform this check.

### HINT:

- Refer to the Techstream operator's manual for further details.
- A message indicating a refrigerant shortage is displayed on the Techstream and the air conditioning system turns off if the amount of refrigerant in the system is insufficient.
- DTCs are not stored when performing the refrigerant shortage check using the Techstream.

### Result:

| RESULT               | AMOUNT OF REFRIGERANT   | CORRECTIVE ACTION   |
|----------------------|-------------------------|---|
| Refrigerant shortage | Insufficient or leakage | <ol style="list-style-type: none"> <li>Check for refrigerant leaks using a halogen leak detector, and repair if necessary.</li> <li>Evacuate the air conditioning system and charge it with the appropriate volume of new or purified refrigerant.</li> </ol> Click here <a href="#">INFO</a> |
| Refrigerant correct  | Correct                 | -   |



|   |              |                               |
|---|--------------|-------------------------------|
| Last Modified: 01-14-2019   | 6.8:8.0.48   | Doc ID: RM100000018JLB        |
| Model Year Start: 2018  | Model: Prius | Prod Date Range: [11/2017 - ] |
| Title: HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: CUSTOMIZE PARAMETERS; 2018 - 2019 MY Prius [11/2017 - ] |              |                               |

## CUSTOMIZE PARAMETERS

### CUSTOMIZE AIR CONDITIONING SYSTEM

(a) Customizing with the Techstream.

#### NOTICE:

- When the customer requests a change in a function, first make sure that the function can be customized.
- Be sure to make a note of the current settings before customizing.
- When troubleshooting a function, first make sure that the function is set to the default setting.

#### HINT:

The following items can be customized.

- (1) Connect the Techstream.
- (2) Turn the power switch on (IG).
- (3) Turn the Techstream on.
- (4) Enter the following menus: Customize Setting / Air Conditioner.
- (5) Select the setting by referring to the table below.

#### Air Conditioner

| TESTER DISPLAY               | DESCRIPTION  | DEFAULT   | SETTING   | ECU                                 |
|------------------------------|--|-----------|---|-------------------------------------|
| S-FLOW Control Auto Function | Function to turn the S-FLOW control on automatically when the power switch is turned on (IG)                   | ON        | 0: ON, 1: OFF   | Air conditioning amplifier assembly |
| Set Temperature Shift        | Function to perform control with the shifted temperature versus the displayed temperature                      | Normal    | 00001: -2C, 00010: -1C, 00100: Normal, 01000: +1C, 10000: +2C | Air conditioning amplifier assembly |
| Compressor Mode              | Function to turn the A/C on automatically by pressing the AUTO button when the blower is on and the A/C is off | Automatic | 0: Automatic, 1: Manual                                       | Air conditioning amplifier assembly |
| Foot/DEF Auto Mode           | Function to turn the airflow to foot/defroster automatically when AUTO   | ON        | 0: ON, 1: OFF   | Air conditioning amplifier assembly |

|                                       |  |        |   |                                     |
|---------------------------------------|--|--------|---|-------------------------------------|
|                                       | mode is on   |        |   |                                     |
| Foot/DEF Automatic Blow Up Function   | Function to increase the blower level automatically when the defroster is on                               | ON     | 0: ON, 1: OFF   | Air conditioning amplifier assembly |
| Ambient Temperature Shift             | Function to display the shifted ambient temperature versus the actual ambient temperature                  | Normal | 0000001: -3C, 0000010: -2C, 0000100: -1C, 0001000: Normal, 0010000: +1C, 0100000: +2C, 1000000: +3C | Air conditioning amplifier assembly |
| ECO MODE Cancel                       | Function to cancel ECO mode when set to ON   | ON     | 0: OFF, 1: ON   | Air conditioning amplifier assembly |
| Noise and Vibration Reduction         | Function to change the speed of the compressor when set to ON  | OFF    | 0: OFF, 1: ON   | Air conditioning amplifier assembly |
| Refrigerant Shortage Check            | Function to cancel the refrigerant shortage check (check performed during normal operation) when set to ON | ON     | 0: ON, 1: OFF   | Air conditioning amplifier assembly |
| Fan speed increment control           | Function to set the speed to reach the target blower fan speed when AUTO mode is on                        | Normal | 001: Slow, 010: Normal, 100: Fast   | Air conditioning amplifier assembly |
| Outside Air Mode Auto Switch Function | Function to automatically change the air inlet to FRESH mode when the power switch is off for 60 seconds   | ON     | 0: ON, 1: OFF   | Air conditioning amplifier assembly |

(b) Customizing with the multi-display (w/ Multi-display).

(1) Turn the power switch on (IG).

(2) Enter the following menus:

Type A: SETUP / Vehicle / Vehicle Customization / Climate Settings.


Type B: APPS / Setup / Vehicle / Vehicle Customization / Climate Settings.

Type C: MENU / Settings / Vehicle / Vehicle Customization / Climate Settings.

(3) Select the setting by referring to the table below.

### Climate Settings

| DISPLAY       | DEFAULT | CONTENT  | SETTING   | ECU                                 |
|---------------|---------|--|-----------|-------------------------------------|
| Auto A/C Mode | On      | Function to turn the A/C on automatically by pressing the AUTO button when the blower is on and the A/C is off | On or Off | Air conditioning amplifier assembly |



|   |                     |  |
|---|---------------------|--|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000RW3S           |
| <b>Model Year Start:</b> 2016   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 -     ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: DATA LIST / ACTIVE TEST; 2016 - 2019 MY Prius [11/2015 -     ] |                     |  |

## DATA LIST / ACTIVE TEST

### DATA LIST

#### NOTICE:

In the table below, the values listed under "Normal Condition" are reference values. Do not depend solely on these reference values when deciding whether a part is faulty or not.

#### HINT:

Using the Techstream to read the Data List allows the values or states of switches, sensors, actuators and other items to be read without removing any parts. This non-intrusive inspection can be very useful because intermittent conditions or signals may be discovered before parts or wiring is disturbed. Reading the Data List information early in troubleshooting is one way to save diagnostic time.

- (a) Connect the Techstream to the DLC3.
- (b) Turn the power switch on (IG).
- (c) Turn the Techstream on.
- (d) Enter the following menus: Body Electrical / Air Conditioner / Data List.
- (e) Read the Data List according to the display on the Techstream.

#### Body Electrical > Air Conditioner > Data List

| TESTER DISPLAY            | MEASUREMENT ITEM                      | RANGE   | NORMAL CONDITION                        | DIAGNOSTIC NOTE |
|---------------------------|---------------------------------------|---|---|-----------------|
| Room Temperature Sensor   | Cooler (room temp. sensor) thermistor | Min.: -6.50°C<br>(20.30°F)<br>Max.: 57.25°C<br>(135.05°F)   | Actual cabin temperature displayed      | -               |
| Ambient Temp Sensor       | Thermistor assembly                   | Min.: -23.30°C<br>(-9.94°F)<br>Max.: 65.95°C<br>(150.71°F)  | Actual ambient temperature displayed    | -               |
| Adjusted Ambient Temp     | Adjusted ambient temperature          | Min.: -30.80°C<br>(-23.44°F)<br>Max.: 50.80°C<br>(123.44°F) | -                                       | -               |
| Evaporator Fin Thermistor | No. 1 cooler thermistor               | Min.: -29.70°C<br>(-21.46°F)<br>Max.: 59.55°C<br>(139.19°F) | Actual evaporator temperature displayed | -               |
|                           |                                       |   |   |                 |

|                                |  |  |   |   |
|--------------------------------|--|--|---|---|
| Evaporator Target Temp         | Evaporator target temperature  | Min.: -327.68°C<br>(-557.82°F)<br>Max.: 327.67°C<br>(621.81°F) | Evaporator target temperature displayed   | - |
| Solar Sensor (D Side)          | Solar sensor   | Min.: 0<br>Max.: 255   | Solar sensor value increases as brightness increases  | - |
| Engine Coolant Temp            | Engine coolant temperature sensor  | Min.: 1.30°C<br>(34.34°F)<br>Max.: 90.55°C<br>(194.99°F)       | Actual engine coolant temperature displayed   | - |
| Blower Motor Speed Level       | Blower motor speed level   | Min.: 0<br>Max.: 31  | Displayed speed level increases in range between 0 and 31 as blower motor speed increases   | - |
| Regulator Pressure Sensor      | Air conditioner pressure sensor  | Min.: -456.6 kPaG<br>Max.: 3294.3 kPaG                         | Actual refrigerant pressure displayed   | - |
| Air Outlet Servo Pulse (R)     | No. 3 air conditioning radiator damper servo sub-assembly target pulse           | Min.: 128<br>Max.: 383   | <ul style="list-style-type: none"> <li>• FACE: 250 (pulse)</li> <li>• B/L: 281 (pulse)</li> <li>• FOOT-F: 287 (pulse)</li> <li>• FOOT: 297 (pulse)</li> <li>• S-FLOW (Front Seat Control Modes): 250 (pulse)</li> </ul> | - |
| Air Outlet Servo Actual Pls(R) | No. 3 air conditioning radiator damper servo sub-assembly actual pulse           | Min.: 128<br>Max.: 383   | <ul style="list-style-type: none"> <li>• FACE: 250 (pulse)</li> <li>• B/L: 281 (pulse)</li> <li>• FOOT-F: 287 (pulse)</li> <li>• FOOT: 297 (pulse)</li> <li>• S-FLOW (Front Seat Control Modes): 250 (pulse)</li> </ul> | - |
| Air Mix Servo Targ Pulse(D)    | No. 2 air conditioning radiator damper servo sub-assembly (air mix) target pulse | Min.: 128<br>Max.: 383   | <ul style="list-style-type: none"> <li>• MAX COLD: 257 (pulse)</li> <li>• MAX HOT: 165 (pulse)</li> </ul>   | - |
| Air Mix Servo Actual Pulse(D)  | No. 2 air conditioning radiator damper servo sub-assembly (air mix) actual pulse | Min.: 128<br>Max.: 383   | <ul style="list-style-type: none"> <li>• MAX COLD: 257 (pulse)</li> <li>• MAX HOT: 165 (pulse)</li> </ul>   | - |
|                                |  |  | <ul style="list-style-type: none"> <li>• FACE: 256 (pulse)</li> <li>• FACE1: 256 (pulse)</li> </ul>   |   |

|                                       |   |                                |  |          |
|---------------------------------------|---|--------------------------------|--|----------|
| <p>Air Outlet Servo Pulse (D)</p>     | <p>No. 1 air conditioning radiator damper servo sub-assembly target pulse</p>                             | <p>Min.: 128<br/>Max.: 383</p> | <ul style="list-style-type: none"> <li>• FACE2: 256 (pulse)</li> <li>• B/L: 245 (pulse)</li> <li>• B/L2: 245 (pulse)</li> <li>• FOOT-R: 215 (pulse)</li> <li>• FOOT-M: 215 (pulse)</li> <li>• FOOT: 215 (pulse)</li> <li>• FOOT-D: 207 (pulse)</li> <li>• FOOT-0: 224 (pulse)</li> <li>• FOOT-F: 215 (pulse)</li> <li>• FOOT/DEF: 192 (pulse)</li> <li>• DEF: 164 (pulse)</li> <li>• S-FLOW (Single Seat Control Modes): 164 (pulse)</li> </ul>  | <p>-</p> |
| <p>Air Outlet Servo Actu Pulse(D)</p> | <p>No. 1 air conditioning radiator damper servo sub-assembly actual pulse</p>                             | <p>Min.: 128<br/>Max.: 383</p> | <ul style="list-style-type: none"> <li>• FACE: 256 (pulse)</li> <li>• FACE1: 256 (pulse)</li> <li>• FACE2: 256 (pulse)</li> <li>• B/L: 245 (pulse)</li> <li>• B/L2: 245 (pulse)</li> <li>• FOOT-R: 215 (pulse)</li> <li>• FOOT-M: 215 (pulse)</li> <li>• FOOT: 215 (pulse)</li> <li>• FOOT-D: 207 (pulse)</li> <li>• FOOT-0: 224 (pulse)</li> <li>• FOOT-F: 215 (pulse)</li> <li>• FOOT/DEF: 192 (pulse)</li> <li>• DEF: 164 (pulse)</li> <li>• S-FLOW (Single Seat Control Modes): 164 (pulse)</li> </ul> | <p>-</p> |
| <p>Air Outlet Servo Targ Pulse(P)</p> | <p>No. 2 air conditioning radiator damper servo sub-assembly (front passenger side mode) target pulse</p> | <p>Min.: 128<br/>Max.: 383</p> | <ul style="list-style-type: none"> <li>• FACE: 256 (pulse)</li> <li>• FACE1: 256 (pulse)</li> <li>• FACE2: 256 (pulse)</li> <li>• B/L: 267 (pulse)</li> <li>• B/L2: 267 (pulse)</li> <li>• FOOT-R: 297 (pulse)</li> <li>• FOOT-M: 297 (pulse)</li> <li>• FOOT: 297 (pulse)</li> <li>• FOOT-D: 305 (pulse)</li> <li>• FOOT-0: 288 (pulse)</li> <li>• FOOT-F: 297 (pulse)</li> <li>• FOOT/DEF: 320 (pulse)</li> <li>• DEF: 348 (pulse)</li> <li>• S-FLOW (Single Seat Control Modes): 348 (pulse)</li> </ul> | <p>-</p> |

|                                |  |  |  |                   |
|--------------------------------|--|--|--|-------------------|
| Air Outlet Servo Actu Pulse(P) | No. 2 air conditioning radiator damper servo sub-assembly (front passenger side mode) actual pulse | Min.: 128<br>Max.: 383                     | <ul style="list-style-type: none"> <li>FACE: 256 (pulse)</li> <li>• FACE1: 256 (pulse)</li> <li>• FACE2: 256 (pulse)</li> <li>• B/L: 267 (pulse)</li> <li>• B/L2: 267 (pulse)</li> <li>• FOOT-R: 297 (pulse)</li> <li>• FOOT-M: 297 (pulse)</li> <li>• FOOT: 297 (pulse)</li> <li>• FOOT-D: 305 (pulse)</li> <li>• FOOT-O: 288 (pulse)</li> <li>• FOOT-F: 297 (pulse)</li> <li>• FOOT/DEF: 320 (pulse)</li> <li>• DEF: 348 (pulse)</li> <li>• S-FLOW (Single Seat Control Modes): 348 (pulse)</li> </ul> | -                 |
| Air Inlet Damper Targ Pulse    | No. 1 blower damper servo sub-assembly target pulse  | Min.: 128<br>Max.: 383                     | <ul style="list-style-type: none"> <li>• Recirculation: 256 (pulse)</li> <li>• Fresh: 220 (pulse)</li> </ul>   | -                 |
| Air Inlet Damper Actual Pulse  | No. 1 blower damper servo sub-assembly actual pulse  | Min.: 128<br>Max.: 383                     | <ul style="list-style-type: none"> <li>• Recirculation: 256 (pulse)</li> <li>• Fresh: 220 (pulse)</li> </ul>   | -                 |
| Compressor Speed               | Compressor speed   | Min.: 0 rpm<br>Max.: 65535 rpm             | Actual compressor speed displayed  | -                 |
| Compressor Target Speed        | Compressor target speed  | Min.: 0 rpm<br>Max.: 65535 rpm             | Compressor target speed displayed  | -                 |
| Shift Set Temperature          | Shift set temperature  | 2C decr, 1C decr, Normal, 1C incr, 2C incr | Customized value displayed   | -                 |
| Compressor Mode                | Compressor mode  | Auto or Manual                             | Customized value displayed   | -                 |
| Noise and Vibration Reduction  | Noise and vibration reduction  | OFF or ON                                  | Customized value displayed   | -                 |
| ECO MODE Cancel                | ECO drive mode cancel  | OFF or ON                                  | Customized value displayed   | -                 |
| ECO Switch                     | -  | -  | -  | Not applicable to |



|                                |   |  |  |             |
|--------------------------------|---|--|--|-------------|
|                                |   |  |  | the vehicle |
| Refrigerant Shortage Check     | Refrigerant shortage check                | ON or OFF  | Customized value displayed                                 | -           |
| Fan speed increment control    | Fan speed increment control               | Slow, Normal, Fast   | Customized value displayed                                 | -           |
| Foot/DEF Auto Mode             | Foot/defroster auto mode                  | ON or OFF  | Customized value displayed                                 | -           |
| Foot/DEF Auto Blow Up          | Foot/defroster auto blower speed increase | ON or OFF  | Customized value displayed                                 | -           |
| Ambient Temperature Shift      | Ambient temperature shift                 | 3C decr, 2C decr, 1C decr, Normal, 1C incr, 2C incr, 3C incr | Customized value displayed                                 | -           |
| Compressor Drive Check         | Compressor drive check                    | OK or NG   | NG: Compressor does not operate<br>OK: Compressor operates | -           |
| Glass Temperature              | Windshield glass temperature              | Min.: -327.68°C (-557.82°F)<br>Max.: 327.67°C (621.81°F)     | Actual windshield glass temperature is displayed           | *           |
| Glass Surroundings Temperature | Temperature around windshield glass       | Min.: -327.68°C (-557.82°F)<br>Max.: 327.67°C (621.81°F)     | Actual temperature around windshield glass is displayed    | *           |
| Glass Humidity                 | Windshield glass humidity                 | Min.: 0.00%<br>Max.: 100.00%                                 | Actual windshield glass humidity is displayed              | *           |
| Refrigerant Gas Type           | Refrigerant gas type                      | R134a or 1234yf  | Refrigerant gas type displayed                             | -           |
| Set Temperature (D Side)       | Driver side set temperature               | Min.: MAX COLD<br>Max.: MAX HOT                              | Driver side set temperature displayed                      | -           |
| Outside Air Mode Auto          | Outside air mode auto switch              |  |  |             |

|                                    |                              |                      |  |   |
|------------------------------------|------------------------------|----------------------|--|---|
| Switch Function                    | function                     | ON or OFF            | Customized value displayed                               | - |
| S-FLOW Control Auto Function       | S-FLOW control auto function | ON or OFF            | Customized value displayed                               | - |
| Communication Wiper ECU            | Existence of function        | With or Without      | With: w/ Wiper ECU<br>Without: w/o Wiper ECU             | - |
| Communication Wiper Switch         | Existence of function        | With or Without      | With: w/ Wiper switch<br>Without: w/o Wiper switch       | - |
| Communication Humidity/Rain Sensor | Existence of function        | With or Without      | With: w/ Humidity sensor<br>Without: w/o Humidity sensor | - |
| Number of Trouble Codes            | Number of trouble codes      | Min.: 0<br>Max.: 255 | Number of DTCs displayed                                 | - |

\*: w/ Humidity Sensor

## ACTIVE TEST

### HINT:

Using the Techstream to perform Active Tests allows relays, VSVs, actuators and other items to be operated without removing any parts. This non-intrusive functional inspection can be very useful because intermittent operation may be discovered before parts or wiring is disturbed. Performing Active Tests early in troubleshooting is one way to save diagnostic time. Data List information can be displayed while performing Active Tests.

- Connect the Techstream to the DLC3.
- Turn the power switch on (IG).
- Turn the Techstream on.
- Enter the following menus: Body Electrical / Air Conditioner / Active Test.
- Perform the Active Test according to the display on the Techstream.


### Body Electrical > Air Conditioner > Active Test

| TESTER DISPLAY          | MEASUREMENT ITEM                   | CONTROL RANGE          | DIAGNOSTIC NOTE |
|-------------------------|------------------------------------|------------------------|-----------------|
| Blower Motor            | Blower motor with fan sub-assembly | Min.: 0,<br>Max.: 31   | -               |
| Compressor Target Speed | Compressor with motor assembly     | Min.: 0,<br>Max.: 7500 | -               |
| Defogger Relay          | Rear window defogger               | OFF, ON                | -               |

|                             |   |                        |                                    |
|-----------------------------|---|------------------------|------------------------------------|
| (Rear)                      |   |                        |                                    |
| Air Mix Servo Targ Pulse(D) | No. 2 air conditioning radiator damper servo sub-assembly (air mix) pulse                   | Min.: 128<br>Max.: 383 | Operates between 165 to 257 pulses |
| Air Outlet Servo Pulse (D)  | No. 1 air conditioning radiator damper servo sub-assembly pulse                             | Min.: 128<br>Max.: 383 | Operates between 164 to 256 pulses |
| Air Inlet Damper Targ Pulse | No. 1 blower damper servo sub-assembly pulse  | Min.: 128<br>Max.: 383 | Operates between 220 to 256 pulses |
| Air Outlet Servo Pulse (P)  | No. 2 air conditioning radiator damper servo sub-assembly (front passenger side mode) pulse | Min.: 128<br>Max.: 383 | Operates between 256 to 348 pulses |
| A/O Servo Pulse(Rr D)       | No. 3 air conditioning radiator damper servo sub-assembly pulse                             | Min.: 128<br>Max.: 383 | Operates between 250 to 297 pulses |

**Powertrain > Engine and ECT > Active Test**

| TESTER DISPLAY                   | MEASUREMENT ITEM                   | CONTROL RANGE | DIAGNOSTIC NOTE  |
|----------------------------------|------------------------------------|---------------|--|
| Control the Electric Cooling Fan | Control electric cooling fan motor | ON/OFF        | <p>Perform this test when the following conditions are met:</p> <ul style="list-style-type: none"> <li>• Power switch is on (IG)</li> <li>• Engine is stopped</li> <li>• Shift lever in P</li> </ul> |



|  |                     |                                      |
|--|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM1000000018JLJ       |
| <b>Model Year Start:</b> 2018  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2017 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: DIAGNOSIS SYSTEM; 2018 - 2019 MY Prius [11/2017 - ] |                     |                                      |

## **DIAGNOSIS SYSTEM**

### **DESCRIPTION**

Air conditioning system data and Diagnostic Trouble Codes (DTCs) can be read through the Data Link Connector 3 (DLC3) of the vehicle. When the system seems to be malfunctioning, use the Techstream to check for malfunctions and perform troubleshooting.

### **CHECK DLC3**

Check the DLC3.


Click here [INFO](#)


### **LIST OF OPERATION METHODS**

By operating each of the air conditioning control switches as shown in the diagram below, it is possible to enter diagnostic check mode.

Turn the power switch on (IG) and press the air conditioning control assembly AUTO and recirculation/fresh switches simultaneously within 5 seconds.

The AUTO and recirculation/fresh switches are not pressed simultaneously.



 : Indicates switch operation

AUTO: Automatic air conditioning switch

OFF: Blower fan off switch

UP Dr: Driver side temperature up switch

UP: Temperature up switch

H


## INDICATOR CHECK

- (a) Turn the power switch off.
- (b) Turn the power switch on (ACC) and wait at least 5 seconds. (for 11.6 Inch Display)
- (c) Turn the power switch on (IG) and press the air conditioning control assembly\*1 or navigation receiver assembly\*2

AUTO and recirculation/fresh switches simultaneously within 5 seconds.

\*1: for 7 Inch Display

\*2: for 11.6 Inch Display




H



|    |  |    |  |
|----|--|----|--|
| *1 | Air Conditioning Control Assembly (for 7 Inch Display) | *2 | Navigation Receiver Assembly (for 11.6 Inch Display) |
|----|--|----|--|

(d) The indicator check is automatically performed when panel diagnosis is activated. Check that the indicators light up and go off 4 times at 1 second intervals continuously.

\*1



\*2



H

|    |  |    |  |
|----|--|----|--|
| *1 | Air Conditioning Control Assembly (for 7 Inch Display) | *2 | Navigation Receiver Assembly (for 11.6 Inch Display) |
| *a | Indicator Blinking Pattern                             | *b | ON   |
| *c | OFF  | *d | 1 Sec.   |

**HINT:**

- The sensor check automatically starts when the indicator check is completed.
- Press the OFF switch to cancel check mode.


**SENSOR CHECK (DTC CHECK)**

(a) Perform the indicator check.

**HINT:**

After the indicator check is completed, the system enters DTC check mode automatically.

(b) Read the DTCs displayed on the display.



H

|    |  |    |  |
|----|--|----|--|
| *1 | Air Conditioning Control Assembly (for 7 Inch Display) | *2 | Navigation Receiver Assembly (for 11.6 Inch Display) |
| *3 | Diagnostic Trouble Code (DTC)                          | -  | -  |

**NOTICE:**

In sensor check mode, which is automatically entered after indicator check mode, troubleshooting may be partially performed. Be sure to perform the sensor check again.

**HINT:**


Refer to Diagnostic Trouble Code Chart for details of the codes.

Click here [INFO](#) [INFO](#)

- When there are no problems, DTC 00 is output.
- As an example, the illustration shows that DTC 12 is output.

(c) If the DTCs are difficult to read because they change automatically, Push the TEMP up switch to display the steps one at a time so that they can be read easily. The items are displayed step by step each time the TEMP up switch is pushed.






|    |  |    |  |
|----|--|----|--|
| *1 | Air Conditioning Control Assembly (for 7 Inch Display) | *2 | Navigation Receiver Assembly (for 11.6 Inch Display) |
|----|--|----|--|

**HINT:**

Press the OFF switch to finish panel diagnosis.

(d) Clear the DTCs.

(1) During the sensor check, press the front defroster switch and rear defogger switch simultaneously.



|    |  |    |  |
|----|--|----|--|
| *1 | Air Conditioning Control Assembly (for 7 Inch Display) | *2 | Navigation Receiver Assembly (for 11.6 Inch Display) |
|----|--|----|--|



|  |                     |                                      |
|--|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM100000001FZBW       |
| <b>Model Year Start:</b> 2019  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [12/2018 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: DIAGNOSTIC TROUBLE CODE CHART; 2019 MY Prius [12/2018 - ] |                     |                                      |

## DIAGNOSTIC TROUBLE CODE CHART

### AIR CONDITIONING SYSTEM

| DTC NO.  | DETECTION ITEM  | DTC DETECTION CONDITION  | LINK                 |
|----------|---|--|----------------------|
| B1245    | Lost Communication with Wiper ECU LIN                       | Lost communication with windshield wiper relay assembly  | <a href="#">INFO</a> |
| B1279    | Lost Communication with Humidity/Rain Sensor LIN            | Lost communication with air conditioning thermistor assembly   | <a href="#">INFO</a> |
| B1373    | Lost Communication with Wiper System LIN BUS                | Lost communication with wiper system LIN communication line  | <a href="#">INFO</a> |
| B1411/11 | Room Temperature Sensor Circuit                             | Open or short in room temperature sensor circuit   | <a href="#">INFO</a> |
| B1412/12 | Ambient Temperature Sensor Circuit                          | Open or short in ambient temperature sensor circuit  | <a href="#">INFO</a> |
| B1413/13 | Evaporator Temperature Sensor Circuit                       | Open or short in evaporator temperature sensor circuit   | <a href="#">INFO</a> |
| B1423    | Pressure Sensor Circuit                                     | <ul style="list-style-type: none"> <li>Open or short in air conditioner pressure sensor circuit</li> <li>Refrigerant pressure on high pressure side is extremely low (176 kPa (1.8 kgf/cm<sup>2</sup>, 26 psi) or less) or extremely high (3025 kPa (30.8 kgf/cm<sup>2</sup>, 439 psi) or more)</li> </ul> | <a href="#">INFO</a> |
| B1441    | Air Mix Damper Control Servo Motor Circuit (Passenger Side) | Air mix damper position sensor value does not change even if air conditioning amplifier assembly operates No. 2 air conditioning radiator damper servo sub-assembly  | <a href="#">INFO</a> |
| B1442    | Air Inlet Damper Control Servo Motor Circuit                | Air inlet damper position sensor value does not change even if air conditioning amplifier assembly operates No. 1 blower damper servo sub-assembly   | <a href="#">INFO</a> |
| B1443    | Air Outlet Damper Control Servo Motor Circuit               | Air outlet damper position sensor value does not change even if air conditioning amplifier assembly operates No. 1 air conditioning radiator damper servo sub-assembly   | <a href="#">INFO</a> |

|          |   |   |      |
|----------|---|---|------|
| B1448    | Passenger Side FACE Servo Motor Circuit                     | Air outlet damper position sensor value does not change even if air conditioning amplifier assembly operates No. 2 air conditioning radiator damper servo sub-assembly  | INFO |
| B1449    | Rear Air Outlet Damper Control Servo Motor Circuit          | Air mix damper position sensor value does not change even if air conditioning amplifier assembly operates No. 3 air conditioning radiator damper servo sub-assembly   | INFO |
| B1471    | A/C Inverter High Voltage Power Resource System Malfunction | <ul style="list-style-type: none"> <li>• Open or short in A/C inverter high voltage power resource system</li> <li>• Boost inverter malfunctioning</li> </ul>   | INFO |
| B1472/72 | A/C Inverter High Voltage Output System Malfunction         | Open or short in A/C inverter high voltage output circuit   | INFO |
| B1473    | A/C Inverter Start-up Signal System Malfunction             | Open or short in A/C inverter start-up signal circuit   | INFO |
| B1474/74 | A/C Inverter Malfunction                                    | A/C inverter malfunction  | INFO |
| B1475    | A/C Inverter Cooling / Heating System Malfunction           | A/C inverter temperature outside specified range (temperature too high) or open or short to ground in temperature sensor circuit  | INFO |
| B1476/76 | A/C Inverter Load System Malfunction                        | Motor rotation load while compressor is operating is too large or too small   | INFO |
| B1477/77 | A/C Inverter Low Voltage Power Resource System Malfunction  | Open or short to ground in inverter control power voltage circuit   | INFO |
| B1497    | BUS IC Communication Malfunction                            | Error or open in communication line   | INFO |
| B1498    | Communication Malfunction (A/C Inverter Local)              | <ul style="list-style-type: none"> <li>• Error or open in communication line between the hybrid vehicle control ECU and compressor with motor assembly</li> <li>• High-voltage power source shut off</li> </ul> | INFO |
| B14A2    | Driver Side Solar Sensor Short Circuit                      | Short in cooler (solar sensor) thermistor circuit   | INFO |
| B14A8    | Glass Temperature Sensor Circuit                            | Open or short in glass temperature sensor circuit   | INFO |
| B14A9    | Glass Surroundings Temperature Sensor Circuit               | Open or short in glass surroundings temperature sensor circuit  | INFO |
|          |   |   |      |

|         |   |  |      |
|---------|---|--|------|
| B14AA   | Glass Humidity Sensor Circuit   | Open or short in glass humidity sensor circuit   | INFO |
| B14B2   | Lost Communication with Front Panel LIN   | Lost communication with air conditioning control assembly  | INFO |
| B14B8   | Refrigerant Shortage  | When following condition is detected in refrigerant shortage check in normal operation:<br><br>Amount of refrigerant is insufficient | INFO |
| P1C7C49 | Hybrid/EV Battery Voltage System Isolation (A/C Area) Internal Electronic Failure | High voltage system insulation malfunction   | INFO |
| U0131   | Lost Communication with Electric Power Steering ECU                               | No communication with power steering ECU assembly  | INFO |
| U0142   | Lost Communication with Main Body ECU   | No communication with main body ECU (multiplex network body ECU)   | INFO |
| U0151   | Lost Communication with Restraints Control Module                                 | No communication with airbag sensor assembly   | INFO |
| U0155   | Lost Communication with Combination Meter   | No communication with combination meter assembly   | INFO |
| U0163   | Lost Communication with Navigation Control Module                                 | No communication with navigation receiver assembly*  | INFO |
| U0293   | Lost Communication with HV ECU  | No communication with hybrid vehicle control ECU   | INFO |



|   |                     |                                      |
|---|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000RW43       |
| <b>Model Year Start:</b> 2016   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: DTC CHECK / CLEAR; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

## **DTC CHECK / CLEAR**

### **DTC CHECK USING TECHSTREAM**

- (a) Connect the Techstream to the DLC3.
- (b) Turn the power switch on (IG).
- (c) Turn the Techstream on.
- (d) Enter the following menus: Body Electrical / Air Conditioner / Trouble Codes.

#### **Body Electrical > Air Conditioner > Trouble Codes**


- (e) Check for DTCs.

### **DTC CLEAR USING TECHSTREAM**

- (a) Connect the Techstream to the DLC3.
- (b) Turn the power switch on (IG).
- (c) Turn the Techstream on.
- (d) Enter the following menus: Body Electrical / Air Conditioner / Trouble Codes.

#### **Body Electrical > Air Conditioner > Clear DTCs**

- (e) Clear the DTCs.



|   |                     |                                      |
|---|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000RW45       |
| <b>Model Year Start:</b> 2016   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: HOW TO PROCEED WITH TROUBLESHOOTING; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

## HOW TO PROCEED WITH TROUBLESHOOTING

## CAUTION / NOTICE / HINT

### HINT:

- Use the following procedure to troubleshoot the air conditioning system.
- \*: Use the Techstream.

## PROCEDURE

### 1. VEHICLE BROUGHT TO WORKSHOP

### NEXT



### 2. INSPECT AUXILIARY BATTERY VOLTAGE

(a) Inspect the auxiliary battery voltage with the power switch off.

Standard Voltage:

11 to 14 V

If the voltage is below 11 V, recharge or replace the auxiliary battery before proceeding to the next step.

### NEXT



### 3. CHECK COMMUNICATION FUNCTION OF CAN COMMUNICATION SYSTEM\*

(a) Using the Techstream, check for CAN communication system DTCs.

Click here [INFO](#)

| RESULT                                       | PROCEED TO |
|--|------------|
| CAN communication system DTCs are not output | A          |

CAN communication system DTCs are output

B

**B**  **GO TO CAN COMMUNICATION SYSTEM** [INFO](#) [INFO](#)

**A**



**4. CHECK FOR DTC \***

(a) Check for DTCs and note any codes that are output.

Click here [INFO](#)

**Body Electrical > Air Conditioner > Trouble Codes**

(b) Clear the DTCs.

Click here [INFO](#)

**Body Electrical > Air Conditioner > Clear DTCs**

(c) Recheck for DTCs. Based on the DTCs output above, try to force output of the air conditioning system DTC by simulating the operation indicated by the DTC.

Click here [INFO](#)

**Body Electrical > Air Conditioner > Trouble Codes**

| RESULT              | PROCEED TO |
|---------------------|------------|
| DTCs are not output | A          |
| DTCs are output     | B          |

**B**  **GO TO DIAGNOSTIC TROUBLE CODE CHART** [INFO](#) [INFO](#) [INFO](#)

**A**



**5. PROBLEM SYMPTOMS TABLE**

(a) Refer to Problem Symptoms Table.

Click here [INFO](#) [INFO](#) [INFO](#)



| RESULT  | PROCEED TO |
|---|------------|
| Fault is not listed in Problem Symptoms Table | A          |
| Fault is listed in Problem Symptoms Table     | B          |

**B**  **GO TO PROBLEM SYMPTOMS TABLE**   

**A**



**6. OVERALL ANALYSIS AND TROUBLESHOOTING\***

(a) Panel diagnosis (indicator check, sensor check).

Click here  

(b) Data List / Active Test.

Click here 

(c) Terminals of ECU.

Click here   

(d) On-vehicle Inspection.

(e) Inspection.

**NEXT**



**7. ADJUST, REPAIR OR REPLACE**

**NEXT**  **END**




|   |                     |                                      |
|---|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000RW3N       |
| <b>Model Year Start:</b> 2016   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: IG Power Source Circuit; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

## IG Power Source Circuit

### DESCRIPTION

Power source voltage is supplied to the air conditioning amplifier assembly when the power switch is turned on (IG). This power is used for operating the air conditioning amplifier assembly, servo motors, etc.

### WIRING DIAGRAM



### CAUTION / NOTICE / HINT

#### NOTICE:

Inspect the fuses for circuits related to this system before performing the following procedure.

### PROCEDURE

|    |   |
|----|---|
| 1. | CHECK HARNESS AND CONNECTOR (AIR CONDITIONING AMPLIFIER ASSEMBLY - IG POWER SOURCE) |
|----|---|

- (a) Disconnect the F58 air conditioning amplifier assembly connector.
- (b) Measure the voltage according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(F58\)](#)

[Click Connector\(F58\)](#)

| TESTER CONNECTION         | CONDITION            | SPECIFIED CONDITION |
|---------------------------|----------------------|---------------------|
| F58-2 (IG+) - Body ground | Power switch off     | Below 1 V           |
| F58-2 (IG+) - Body ground | Power switch on (IG) | 11 to 14 V          |

**NG** ▶ REPAIR OR REPLACE HARNESS OR CONNECTOR

**OK**



|    |  |
|----|--|
| 2. | <b>CHECK HARNESS AND CONNECTOR (AIR CONDITIONING AMPLIFIER ASSEMBLY - BODY GROUND)</b> |
|----|--|

- (a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:




[Click Location & Routing\(F58\)](#)

[Click Connector\(F58\)](#)

| TESTER CONNECTION         | CONDITION | SPECIFIED CONDITION |
|---------------------------|-----------|---------------------|
| F58-4 (GND) - Body ground | Always    | Below 1 Ω           |

**OK** ▶ PROCEED TO NEXT SUSPECTED AREA SHOWN IN PROBLEM SYMPTOMS TABLE INFO INFO INFO

**NG** ▶ REPAIR OR REPLACE HARNESS OR CONNECTOR




|  |                     |                                      |
|--|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000RW40       |
| <b>Model Year Start:</b> 2016  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: INITIALIZATION; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

## INITIALIZATION

### INITIALIZATION SERVO MOTOR

- (a) Turn the power switch off.
- (b) Connect the Techstream to the DLC3.
- (c) Turn the power switch on (IG).
- (d) Press the A/C OFF switch.
- (e) Turn the Techstream on.
- (f) Enter the following menus: Body Electrical / Air Conditioner / Utility / Servomotor Initialization.
- (g) According to the Techstream display, perform servo motor initialization.


#### **Body Electrical > Air Conditioner > Utility**



#### **HINT:**

During initialization, the AUTO indicator light comes on, and then goes off when initialization has finished.

- (h) According to the Techstream display, select the Exit switch to finish initialization.



|  |                     |                                      |
|--|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000RW4S       |
| <b>Model Year Start:</b> 2016  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: P1C7C49; Hybrid/EV Battery Voltage System Isolation (A/C Area) Internal Electronic Failure; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

|            |                |  |
|------------|----------------|--|
| <b>DTC</b> | <b>P1C7C49</b> | <b>Hybrid/EV Battery Voltage System Isolation (A/C Area) Internal Electronic Failure</b> |
|------------|----------------|--|

## DESCRIPTION

This DTC is stored if there is insulation malfunction in the high-voltage circuit in the air conditioning system. Possible causes are poor insulation in the compressor with motor assembly, or mixing of any oil other than ND-OIL 11 in the refrigerant cycle.


A high-voltage motor is built into the compressor with motor assembly and is cooled directly with refrigerant. Compressor oil (ND-OIL 11) with high insulation performance is used because leakage of electrical power may occur if regular compressor oil (ND-OIL 8) is used.

### **CAUTION:**

- Before inspecting the high-voltage system, take safety precautions such as wearing insulated gloves and removing the service plug grip to prevent electrical shocks. After removing the service plug grip, put it in your pocket to prevent other technicians from accidentally reconnecting it while you are working on the high-voltage system.
- Do not touch the high-voltage connectors or terminals for 10 minutes after the service plug grip is removed.

| DTC NO. | DETECTION ITEM  | DTC DETECTION CONDITION                    | TROUBLE AREA  | MEMORY    |
|---------|---|--|---|-----------|
| P1C7C49 | Hybrid/EV Battery Voltage System Isolation (A/C Area) Internal Electronic Failure | High voltage system insulation malfunction | <ul style="list-style-type: none"> <li>• Compressor oil</li> <li>• Refrigerant pipe line</li> <li>• Compressor with motor assembly</li> <li>• CAN communication system</li> </ul> | Memorized |

## WIRING DIAGRAM



## CAUTION / NOTICE / HINT

### CAUTION:

- Before inspecting the high-voltage system, take safety precautions such as wearing insulated gloves and removing the service plug grip to prevent electrical shocks. After removing the service plug grip, put it in your pocket to prevent other technicians from accidentally reconnecting it while you are working on the high-voltage system.
- Do not touch the high-voltage connectors or terminals for 10 minutes after the service plug grip is removed.

### NOTICE:

- After turning the power switch off, waiting time may be required before disconnecting the cable from the negative (-) auxiliary battery terminal. Therefore, make sure to read the disconnecting the cable from the negative (-) auxiliary

battery terminal notices before proceeding with work.

Click here [INFO](#) [INFO](#) [INFO](#)

- Electrical insulation performance may decrease significantly if even a small amount of oil other than ND-OIL 11 is used (or enters) in the refrigerant cycle, causing a DTC to be output.
- If oil other than ND-OIL 11 is accidentally used and a DTC is output, collect as much of the oil in the refrigerant cycle into the compressor with motor assembly as possible and replace it with ND-OIL 11 to increase the ND-OIL 11 ratio.
- Replace the main components of the refrigerant cycle (evaporator, condenser, and compressor) if a large amount of oil other than ND-OIL 11 enters the system. Failing to do so may cause electrical insulation performance to remain low, causing a DTC to be stored.
- The hybrid control system and air conditioning system output DTCs separately. Perform troubleshooting for the hybrid control system first if DTCs for both systems are output simultaneously.

**HINT:**

If it can be confirmed that any compressor oil other than ND-OIL 11 has been used, replace the main components of the refrigerant cycle.

## PROCEDURE

|           |                                       |
|-----------|---------------------------------------|
| <b>1.</b> | <b>CHECK CAN COMMUNICATION SYSTEM</b> |
|-----------|---------------------------------------|

(a) Using the Techstream, check if the CAN communication system is functioning normally.

**HINT:**

Click here [INFO](#) [INFO](#)

| RESULT                                       | PROCEED TO |
|--|------------|
| CAN communication system DTCs are not output | A          |
| CAN communication system DTCs are output     | B          |

**B**  **GO TO CAN COMMUNICATION SYSTEM** [INFO](#) [INFO](#)

**A**



|           |   |
|-----------|---|
| <b>2.</b> | <b>INSPECT COMPRESSOR WITH MOTOR ASSEMBLY</b> |
|-----------|---|

**CAUTION:**

Because the compressor with motor assembly has a high-voltage circuit, put on insulated gloves and remove the service plug grip to cut off the high-voltage circuit before inspecting the compressor with motor assembly.

(a) Clear the DTCs.

**Powertrain > Hybrid Control > Clear DTCs**

(b) Turn the power switch on (READY).

(c) Prepare the vehicle according to the table below for 3 minutes.

| ITEM                | CONDITION |
|---------------------|-----------|
| Blower speed        | HI        |
| Temperature setting | MAX COLD  |
| A/C switch          | On        |

(d) Turn the power switch off.

(e) Remove the service plug grip.

**HINT:**

Click here [INFO](#) [INFO](#)


**CAUTION:**

Do not touch the high-voltage connectors or terminals for 10 minutes after the service plug grip is removed.

**NOTICE:**

After removing the service plug grip, turning the power switch on (READY) may cause a malfunction. Do not turn the power switch on (READY) with the service plug grip removed.

(f) Disconnect the compressor with motor assembly connector.



(g) Using a megohmmeter, measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(T1\)](#)

[Click Connector\(T1\)](#)

| TESTER CONNECTION       | CONDITION | SPECIFIED CONDITION |
|-------------------------|-----------|---------------------|
| T1-1 (PE) - Body ground | Always    | 2 MΩ or higher      |
| T1-2 (PB) - Body ground | Always    | 2 MΩ or higher      |

**NG**  REPLACE COMPRESSOR WITH MOTOR ASSEMBLY  

**OK**



|           |                                  |
|-----------|----------------------------------|
| <b>3.</b> | <b>INSPECT REFRIGERANT CYCLE</b> |
|-----------|----------------------------------|

**CAUTION:**

Because the compressor with motor assembly has a high-voltage circuit, put on insulated gloves and remove the service plug grip to cut off the high-voltage circuit before inspecting the compressor with motor assembly.

- (a) Reconnect the compressor with motor assembly connector.
- (b) Install the service plug grip.

**HINT:**

[Click here](#) 

- (c) Turn the power switch on (READY).
- (d) Set the A/C temperature to 25°C (77°F) and blower switch to LO and operate the compressor with motor assembly for 10 minutes to circulate the refrigerant and collect as much compressor oil as possible in the compressor with motor assembly.
- (e) Turn the power switch off.
- (f) Using a spot cooler or other tool, cool down the compressor with motor assembly for 30 minutes, or leave the vehicle overnight before inspection.

**NOTICE:**

Do not operate the compressor before inspection.

- (g) Remove the service plug grip.

**CAUTION:**


Do not touch the high-voltage connectors or terminals for 10 minutes after the service plug grip is removed.

**NOTICE:**

After removing the service plug grip, turning the power switch on (READY) may cause a malfunction. Do not turn the power switch on (READY) with the service plug grip removed.

**HINT:**

(h) Disconnect the compressor with motor assembly connector.



(i) Using a megohmmeter, measure the resistance according to the value(s) in the table below.

Standard Resistance:




[Click Location & Routing\(T1\)](#)

[Click Connector\(T1\)](#)

| TESTER CONNECTION       | CONDITION | SPECIFIED CONDITION |
|-------------------------|-----------|---------------------|
| T1-1 (PE) - Body ground | Always    | 3 MΩ or higher      |
| T1-2 (PB) - Body ground | Always    | 3 MΩ or higher      |

**NOTICE:**



If the result is not as specified, replace the compressor without operating it.



|   |                     |                                      |
|---|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000001FLBF       |
| <b>Model Year Start:</b> 2019   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [12/2018 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: PARTS LOCATION; 2019 MY Prius [12/2018 - ] |                     |                                      |

## [PARTS LOCATION](#)

## [ILLUSTRATION](#)





H

|    |                                 |    |  |
|----|---------------------------------|----|--|
| *1 | AIR CONDITIONER PRESSURE SENSOR | *2 | THERMISTOR ASSEMBLY                                    |
|    |                                 |    | NO. 1 ENGINE ROOM RELAY BLOCK AND NO. 1 JUNCTION BLOCK |

|     |  |     |   |
|-----|--|-----|---|
| *3  | AIR CONDITIONING THERMISTOR ASSEMBLY (w/ Humidity Sensor)      | *4  | ASSEMBLY<br>- HTR FUSE<br>- S/HTR F/L FUSE            |
| *5  | ECM  | *6  | FORWARD RECOGNITION CAMERA (w/ Pre-collision System)  |
| *7  | SKID CONTROL ECU (BRAKE BOOSTER WITH MASTER CYLINDER ASSEMBLY) | *8  | COOLER CONDENSER ASSEMBLY                             |
| *9  | COMPRESSOR WITH MOTOR ASSEMBLY                                 | *10 | SWING GRILL ACTUATOR ASSEMBLY                         |
| *11 | AIR CONDITIONING WIRE  | *12 | INVERTER WITH CONVERTER ASSEMBLY                      |
| *13 | POWER STEERING ECU ASSEMBLY                                    | *14 | BATTERY STATE SENSOR ASSEMBLY                         |
| *15 | BATTERY ECU ASSEMBLY (for Lithium-ion Battery)                 | *16 | REAR HYBRID MOTOR CONTROL INVERTER ASSEMBLY (for AWD) |

## ILLUSTRATION




H

|    |  |    |   |
|----|--|----|---|
| *A | except 11.6 Inch Display                 | *B | for 11.6 Inch Display                   |
| *C | w/ Navigation System                     | *D | w/ Audio and Visual System              |
| *E | w/ Automatic Light Control               | *F | w/o Automatic Light Control             |
| *G | w/ Pre-collision System                  | *H | w/ Auto Wiper System                    |
| *1 | COOLER (ROOM TEMP. SENSOR)<br>THERMISTOR | *2 | SEAT HEATER SWITCH (for Driver<br>Side) |
| *3 | AUTOMATIC LIGHT CONTROL SENSOR           | *4 | COOLER (SOLAR SENSOR)<br>THERMISTOR     |

|     |  |     |  |
|-----|--|-----|--|
| *5  | NAVIGATION RECEIVER ASSEMBLY               | *6  | RADIO AND DISPLAY RECEIVER ASSEMBLY  |
| *7  | MAIN BODY ECU (MULTIPLEX NETWORK BODY ECU) | *8  | INSTRUMENT PANEL JUNCTION BLOCK ASSEMBLY<br>- ECU-B NO. 2 FUSE<br>- ECU-IG1 NO. 3 FUSE<br>- ECU-IG1 NO. 4 FUSE |
| *9  | AIRBAG SENSOR ASSEMBLY                     | *10 | HYBRID VEHICLE CONTROL ECU   |
| *11 | DRIVING SUPPORT ECU ASSEMBLY               | *12 | AIR CONDITIONING CONTROL ASSEMBLY  |
| *13 | CLEARANCE WARNING ECU ASSEMBLY             | *14 | CERTIFICATION ECU (SMART KEY ECU ASSEMBLY)   |
| *15 | AIR CONDITIONING AMPLIFIER ASSEMBLY        | *16 | COMBINATION METER ASSEMBLY   |
| *17 | WINDSHIELD WIPER RELAY ASSEMBLY            | *18 | DLC3   |

## ILLUSTRATION






H


|    |                                      |    |                                   |
|----|--------------------------------------|----|-----------------------------------|
| *1 | NO. 1 COOLER THERMISTOR              | *2 | HEATER RADIATOR UNIT SUB-ASSEMBLY |
| *3 | AIR CONDITIONING RADIATOR ASSEMBLY   | *4 | BLOWER ASSEMBLY                   |
| *5 | BLOWER MOTOR WITH FAN SUB-ASSEMBLY   | *6 | COOLER EXPANSION VALVE            |
| *7 | NO. 1 COOLER EVAPORATOR SUB-ASSEMBLY | -  | -                                 |

## ILLUSTRATION



H

|    |   |    |   |
|----|---|----|---|
| *1 | NO. 1 AIR CONDITIONING RADIATOR DAMPER SERVO SUB-ASSEMBLY | *2 | NO. 2 AIR CONDITIONING RADIATOR DAMPER SERVO SUB-ASSEMBLY |
| *3 | NO. 3 AIR CONDITIONING RADIATOR DAMPER SERVO SUB-ASSEMBLY | *4 | NO. 1 BLOWER DAMPER SERVO SUB-ASSEMBLY                    |
| *5 | AIR CONDITIONING HARNESS ASSEMBLY                         | -  | -   |




|   |                     |                                      |
|---|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000001GWZC       |
| <b>Model Year Start:</b> 2019   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [12/2018 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: PRECAUTION; 2019 MY Prius [12/2018 - ] |                     |                                      |

## PRECAUTION


### PRECAUTION FOR DISCONNECTING CABLE FROM NEGATIVE AUXILIARY BATTERY TERMINAL

#### NOTICE:

When disconnecting the cable from the negative (-) auxiliary battery terminal, initialize the following systems after the cable is reconnected.

| SYSTEM NAME                                       | SEE PROCEDURE   |
|---|---|
| Lane Departure Alert System (w/ Steering Control) |  |
| Intelligent Clearance Sonar System                |   |
| Simple Advanced Parking Guidance System           |   |
| Power Door Lock Control System                    |   |
| Pre-collision System                              |   |
| AFS (Adaptive Front-lighting System)              |   |
|   |   |


### DO NOT HANDLE REFRIGERANT IN AN ENCLOSED AREA OR NEAR AN OPEN FLAME



|    |                   |
|----|-------------------|
| *a | Charging Cylinder |
|----|-------------------|

### ALWAYS WEAR EYE PROTECTION

### BE CAREFUL NOT TO GET LIQUID REFRIGERANT IN YOUR EYES OR ON YOUR SKIN



If liquid refrigerant gets in your eyes or on your skin.

(a) Wash the area with lots of cold water.

**CAUTION:**

Do not rub your eyes or skin.

(b) Apply clean petroleum jelly to the skin.

(c) Go immediately to a hospital or see a physician for professional treatment.

**NEVER HEAT CONTAINER OR EXPOSE CONTAINER TO AN OPEN FLAME**


**BE CAREFUL NOT TO DROP CONTAINER OR APPLY PHYSICAL SHOCKS TO IT**

**DO NOT OPERATE COMPRESSOR WITHOUT ENOUGH REFRIGERANT IN REFRIGERANT SYSTEM**

If there is not enough refrigerant in the air conditioning system, oil lubrication will be insufficient and the compressor may be damaged.

Necessary care should be taken to avoid this.

**DO NOT OPEN HIGH PRESSURE MANIFOLD VALVE WHILE COMPRESSOR IS OPERATING**



|    |       |
|----|-------|
| *a | Wrong |
| *b | Okay  |

Open and close only the low pressure valve.

If the high pressure valve is opened, refrigerant will flow in the reverse direction causing the charging cylinder to rupture.

**BE CAREFUL NOT TO OVERCHARGE SYSTEM WITH REFRIGERANT**

If the system is overcharged with refrigerant, it causes problems such as insufficient cooling, poor fuel economy, engine overheating, etc.

## **DO NOT OPERATE ENGINE AND COMPRESSOR WITH NO REFRIGERANT**

### **CAUTION:**

Doing so may damage the inside of the compressor because the compressor parts always move regardless of whether the air conditioning system is turned on or off.

## **SUPPLEMENTAL RESTRAINT SYSTEM (SRS)**

This vehicle is equipped with a Supplemental Restraint System (SRS). Failure to carry out service operations in the correct sequence could cause the SRS to unexpectedly deploy during servicing, possibly leading to a serious accident. Before servicing (including removal or installation of parts, inspection or replacement), be sure to read the precautionary notices.

Click here 

## **GENERAL PRECAUTION**

While using the auxiliary battery during inspection, do not bring the positive (+) and negative (-) tester probes too close to each other as a short circuit may occur.



|   |                     |                                      |
|---|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000001FLBJ       |
| <b>Model Year Start:</b> 2019   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [12/2018 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: PROBLEM SYMPTOMS TABLE; 2019 MY Prius [12/2018 - ] |                     |                                      |

## PROBLEM SYMPTOMS TABLE

### HINT:

- Use the table below to help determine the cause of problem symptoms. If multiple suspected areas are listed, the potential causes of the symptoms are listed in order of probability in the "Suspected Area" column of the table. Check each symptom by checking the suspected areas in the order they are listed. Replace parts as necessary.
- Inspect the fuses and relays related to this system before inspecting the suspected areas below.

### Air Conditioning System

| SYMPTOM   | SUSPECTED AREA                           | LINK                 |
|---|--|----------------------|
| All functions of the air conditioning system do not operate | IG power source circuit                  | <a href="#">INFO</a> |
|   | Back-up power source circuit             | <a href="#">INFO</a> |
|   | LIN communication circuit*3              | <a href="#">INFO</a> |
|   | Air conditioning control panel circuit*4 | <a href="#">INFO</a> |
|   | Air conditioning amplifier assembly      | <a href="#">INFO</a> |
| Air flow Control: No blower operation                       | Blower motor circuit                     | <a href="#">INFO</a> |
|   | LIN communication circuit*3              | <a href="#">INFO</a> |
|   | Air conditioning control panel circuit*4 | <a href="#">INFO</a> |
|   | Air conditioning amplifier assembly      | <a href="#">INFO</a> |
| Air flow control: No blower control                         | Blower motor circuit                     | <a href="#">INFO</a> |
|   | LIN communication circuit*3              | <a href="#">INFO</a> |
|   | Air conditioning control panel circuit*4 | <a href="#">INFO</a> |
|   | Air conditioning amplifier assembly      | <a href="#">INFO</a> |

|  |   |      |
|--|---|------|
| Air flow control: Insufficient air flow            | Blower motor circuit                            | INFO |
|  | Air conditioning amplifier assembly             | INFO |
| Temperature control: Cooling effectiveness is poor | Refrigerant shortage check using the Techstream | INFO |
|  | Refrigerant volume                              | -    |
|  | Refrigerant pressure                            | INFO |
|  | Cooler expansion valve                          | INFO |
|  | Compressor with motor assembly                  | INFO |
|  | Air conditioning amplifier assembly             | INFO |
| Temperature control: No cool air comes out         | Refrigerant shortage check using the Techstream | INFO |
|  | Refrigerant volume                              | -    |
|  | Refrigerant pressure                            | INFO |
|  | Air conditioner pressure sensor circuit         | INFO |
|  | LIN communication circuit*3                     | INFO |
|  | Air conditioning control panel circuit*4        | INFO |
|  | Air mix damper control servo motor circuit      | INFO |
|  | Evaporator temperature sensor circuit           | INFO |
|  | Room temperature sensor circuit                 | INFO |
|  | Ambient temperature sensor circuit              | INFO |
|  | Cooler expansion valve                          | INFO |

|  |   |      |
|--|---|------|
|  | Air conditioning wire                                     | INFO |
|  | No. 2 air conditioning radiator damper servo sub-assembly | INFO |
|  | Air conditioning harness assembly                         | INFO |
|  | Compressor with motor assembly                            | INFO |
|  | Air conditioning amplifier assembly                       | INFO |
|  | Hybrid vehicle control ECU                                | INFO |
|  | ECM   | INFO |
| Temperature control: No warm air comes out | LIN communication circuit*3                               | INFO |
|  | Air conditioning control panel circuit*4                  | INFO |
|  | Air mix damper control servo motor circuit                | INFO |
|  | Evaporator temperature sensor circuit                     | INFO |
|  | Room temperature sensor circuit                           | INFO |
|  | Ambient temperature sensor circuit                        | INFO |
|  | No. 2 air conditioning radiator damper servo sub-assembly | INFO |
|  | Air conditioning harness assembly                         | INFO |
|  | Air conditioning amplifier assembly                       | INFO |
|  | Hybrid vehicle control ECU                                | INFO |
|  | ECM   | INFO |



Temperature control: Output air is warmer or cooler than the set temperature or response is slow

|   |      |
|---|------|
| Refrigerant shortage check using the Techstream           | INFO |
| Refrigerant volume  | -    |
| Refrigerant pressure                                      | INFO |
| Solar sensor circuit*1, *5                                | INFO |
| Solar sensor circuit*1, *6                                | INFO |
| Solar sensor circuit*2                                    | INFO |
| Air conditioning wire                                     | INFO |
| Room temperature sensor circuit                           | INFO |
| Ambient temperature sensor circuit                        | INFO |
| LIN communication circuit*3                               | INFO |
| Air conditioning control panel circuit*4                  | INFO |
| Air mix damper control servo motor circuit                | INFO |
| Air inlet damper control servo motor circuit              | INFO |
| Heater radiator unit sub-assembly                         | INFO |
| Cooler expansion valve                                    | INFO |
| No. 2 air conditioning radiator damper servo sub-assembly | INFO |
| No. 1 blower damper servo sub-assembly                    | INFO |
| Air conditioning harness assembly                         | INFO |

|  |   |      |
|--|---|------|
|  | Air conditioning amplifier assembly                       | INFO |
|  | Hybrid vehicle control ECU                                | INFO |
|  | ECM   | INFO |
|  | CAN communication system*1                                | INFO |
| Temperature control: No temperature control (only MAX COLD or MAX HOT) | LIN communication circuit*3                               | INFO |
|  | Air conditioning control panel circuit*4                  | INFO |
|  | Air mix damper control servo motor circuit                | INFO |
|  | Room temperature sensor circuit                           | INFO |
|  | Ambient temperature sensor circuit                        | INFO |
|  | Evaporator temperature sensor circuit                     | INFO |
|  | Solar sensor circuit*1, *5                                | INFO |
|  | Solar sensor circuit*1, *6                                | INFO |
|  | Solar sensor circuit*2                                    | INFO |
|  | No. 2 air conditioning radiator damper servo sub-assembly | INFO |
|  | Air conditioning harness assembly                         | INFO |
|  | Air conditioning amplifier assembly                       | INFO |
|  | CAN communication system*1                                | INFO |
|  | Refrigerant shortage check using the Techstream           | INFO |
| Refrigerant volume   | -   |      |

Temperature control: Output air temperature is different between left and right registers (the set temperature is the same for both)

|   |      |
|---|------|
| Refrigerant pressure                                      | INFO |
| Air mix damper control servo motor circuit                | INFO |
| Automatic light control sensor                            | INFO |
| No. 2 air conditioning radiator damper servo sub-assembly | INFO |
| Air conditioning harness assembly                         | INFO |
| Air conditioning amplifier assembly                       | INFO |

No air inlet control


|  |      |
|--|------|
| LIN communication circuit*3                  | INFO |
| Air conditioning control panel circuit*4     | INFO |
| Air inlet damper control servo motor circuit | INFO |
| No. 1 blower damper servo sub-assembly       | INFO |
| Air conditioning harness assembly            | INFO |
| Air conditioning amplifier assembly          | INFO |

No air flow mode control

|  |      |
|--|------|
| LIN communication circuit*3  | INFO |
| Air conditioning control panel circuit*4                                 | INFO |
| Air outlet damper control servo motor circuit (for driver side)          | INFO |
| Air outlet damper control servo motor circuit (for front passenger side) | INFO |
| No. 2 air conditioning radiator damper servo sub-assembly                | INFO |

|   |   |      |
|---|---|------|
|   | No. 1 air conditioning radiator damper servo sub-assembly | INFO |
|   | Air conditioning harness assembly                         | INFO |
|   | Air conditioning amplifier assembly                       | INFO |
| Diagnostic trouble codes (DTCs) are not recorded. Set mode is cleared when the power switch is turned off | Back-up power source circuit                              | INFO |
|   | Air conditioning amplifier assembly                       | INFO |

- \*1: w/ Automatic Light Control
- \*2: w/o Automatic Light Control
- \*3: except 11.6 Inch Display
- \*4: for 11.6 Inch Display
- \*5: w/ AFS
- \*6: w/o AFS



|  |                     |                                      |
|--|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM1000000018JLA       |
| <b>Model Year Start:</b> 2018  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2017 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: SYSTEM DESCRIPTION; 2018 - 2019 MY Prius [11/2017 - ] |                     |                                      |

## SYSTEM DESCRIPTION

### GENERAL

The air conditioning system has the following controls.

| CONTROL                              | OUTLINE   |
|--------------------------------------|---|
| Neural Network Control               | This control is capable of performing complex control by artificially simulating the information processing method of the nervous system of living organisms in order to establish a complex input/output relationship similar to that of a human brain.  |
| Outlet Air Temperature Control       | Based on the temperature set by the temperature control dial, neural network control calculates outlet air temperature based on input signals from various sensors.   |
| Blower Control                       | Controls the blower motor in accordance with the airflow volume that has been calculated by neural network control based on input signals from various sensors.   |
| Air Outlet Control                   | Automatically switches the air outlets in accordance with the outlet mode that has been calculated by neural network control.   |
|                                      | In accordance with the engine coolant temperature, ambient air temperature, amount of sunlight, required blower, outlet temperature and vehicle speed conditions, this control automatically switches the blower outlet to foot/defroster mode to prevent the windows from becoming fogged up when the ambient air temperature is low.  |
| Air Inlet Control                    | Automatically controls the air inlet control damper to help achieve the calculated outlet air temperature that is required.   |
|                                      | Drives the air inlet control servo motor according to the operation of the air inlet control switch and moves the dampers to the fresh or recirculation position.   |
| Electric Inverter Compressor Control | Based on the target evaporator temperature (which is calculated through signals from the cooler (room temp. sensor) thermistor, thermistor assembly and automatic light control sensor) and the actual evaporator temperature that is detected by the No. 1 cooler thermistor the air conditioning amplifier assembly calculates the target compressor speed and controls the compressor speed. |
|                                      | The air conditioning amplifier assembly calculates the target evaporator temperature (based on signals from the cooler (room temp. sensor) thermistor, thermistor assembly, automatic light control sensor and No. 1 cooler thermistor) and controls the compressor speed to an extent that will not inhibit proper cooling performance and defogging performance.                              |
|                                      | Turns the A/C on automatically when the AUTO button is pressed when the blower is on and the A/C is off.  |
|                                      | Decreases the compressor speed in order to ensure quietness when the vehicle is stopped or the engine is off.   |
| Defroster Control                    | Defroster control logic is used to improve defroster performance.   |
| S-FLOW Control                       | When the S-FLOW switch is turned on, the air outlets operate in a front seat control mode.  |
| Rear                                 | Refer to Rear Defogger System.  |


|                  |   |
|------------------|---|
| Defogger Control | Click here <a href="#">INFO</a>   |
| ECO Mode Control | When the pattern select switch assembly (DRIVE MODE switch) or air conditioning control assembly (ECO HEAT/COOL switch) is turned on, the air conditioning amplifier assembly limits the air conditioning system performance. |
| Diagnosis        | A Diagnostic Trouble Code (DTC) is stored in memory when the air conditioning amplifier assembly detects a problem with the air conditioning system.  |

## NEURAL NETWORK CONTROL

- In previous automatic air conditioning systems, the air conditioning amplifier assembly determined the required outlet air temperature and blower air volume in accordance with the calculation formula that has been obtained based on information received from the sensors.


However, because the senses of a person are rather complex, a given temperature is sensed differently, depending on the environment in which the person is situated. For example, a given amount of solar radiation can feel comfortably warm in a cold climate, or extremely uncomfortable in a hot climate. Therefore, as a technique for effecting a higher level of control, a neural network has been adopted in the automatic air conditioning system. With this technique, the data that has been collected under varying environmental conditions is stored in the air conditioning amplifier assembly. The air conditioning amplifier assembly can then effect control to provide enhanced air conditioning comfort.

- The neural network control consists of neurons in the input layer, intermediate layer and output layer. The input layer neurons process the input data of the outside temperature, the amount of sunlight and the room temperature based on the outputs of the switches and sensors, and output them to the intermediate layer neurons. Based on this data, the intermediate layer neurons adjust the strength of the links among the neurons. The sum of these is then calculated by the output layer neurons in the form of the required outlet temperature, solar correction, target airflow volume and outlet mode control volume. Accordingly, the air conditioning amplifier assembly controls the servo motors and blower motor in accordance with the control volumes that have been calculated by the neural network control.



## MODE POSITION AND DAMPER OPERATION

(a) Mode Position and Damper Operation








|      |   |      |  |
|------|---|------|--|
| * 1  | Air Mix Control Damper                      | * 2  | Driver Side Side Defroster             |
| * 3  | Front Defroster                             | * 4  | Front Passenger Side Side Defroster    |
| * 5  | Air Inlet Control Damper (Lower Side)       | * 6  | Air Inlet Control Damper (Upper Side)  |
| * 7  | Clean Air Filter                            | * 8  | Blower with Fan Motor Sub-assembly     |
| * 9  | No. 1 Cooler Evaporator Sub-assembly        | * 10 | Air Mix Control Damper                 |
| * 11 | Heater Radiator Unit Sub-assembly           | * 12 | Mode Switching Damper                  |
| * 13 | Driver Side Footwell Register               | * 14 | Front Passenger Side Footwell Register |
| * 15 | Driver Side Side Register                   | * 16 | Center Register                        |
| * 17 | Front Passenger Side Side Register          | * 18 | Driver Side Rear Footwell Register     |
| * 19 | Front Passenger Side Rear Footwell Register | -    | -                                      |
| * a  | Recirculated Air                            | * b  | Fresh Air                              |

### Functions of Main Dampers

| CONTROL DAMPER           | OPERATION POSITION                          | DAMPER POSITION | OPERATION   |
|--------------------------|---|-----------------|---|
| Air Inlet Control Damper | FRESH                                       | A1, B1          | Allows fresh air to enter.  |
|                          | RECIRCULATION                               | A2, B2          | Causes internal air to recirculate.   |
| Air Mix Control          | Temperature Setting:<br>16°C (61°F) to 30°C | C1 - C2         | Varies the front passenger side mixture ratio of the fresh air and the recirculation air in order to regulate the temperature continuously from HI to LO. |




|                           |   |                    |  |
|---------------------------|---|--------------------|--|
| Damper                    | (86°F)  | D2 - D1            | Varies the driver side mixture ratio of the fresh air and the recirculation air in order to regulate the temperature continuously from HI to LO.                       |
| Air Outlet Control Damper | DEF<br>      | F, H, K            | Defrosts the windshield through the center defroster, side defrosters and side registers.  |
|                           | FOOT/DEF<br> | F, H, J to K       | Defrosts the windshield through the center defroster, side defrosters and side registers, while air is also blown out from the front and rear footwell register ducts. |
|                           | FOOT<br>     | E, (E to F)*, H, J | Air blows out of the front and rear footwell register ducts and side registers. In addition, air blows out slightly from the center defroster and side defrosters.     |
|                           | B/L<br>      | E, G to I, J to K  | Air blows out of the center registers, side registers and front and rear footwell register ducts.  |
|                           | FACE<br>    | E, G, K            | Air blows out of the center registers and side registers.  |


### AIR OUTLETS AND AIRFLOW VOLUME

The size of each circle  $\circ$  indicates the ratio of airflow volume.

(a) Air Outlets and Airflow Volume (for All Seat Control Modes).



|    |                    |   |   |
|----|--------------------|---|---|
| *a | for 7 Inch Display | - | - |
|----|--------------------|---|---|




|    |                       |   |   |
|----|-----------------------|---|---|
| *a | for 11.6 Inch Display | - | - |
|----|-----------------------|---|---|


| MODE | FACE   |      | FOOT  |      | DEF    |      |
|------|--------|------|-------|------|--------|------|
|      | CENTER | SIDE | FRONT | REAR | CENTER | SIDE |
|      | A      | B    | C     | D    | E      | F    |
| FACE |        |      |       |      |        |      |

|              |   |   |   |   |   |   |
|--------------|---|---|---|---|---|---|
|              | ○ | ○ | — | — | — | — |
| B/L<br>      | ○ | ○ | ○ | ○ | — | ● |
| FOOT<br>     | — | ● | ○ | ○ | ● | ● |
| FOOT/DEF<br> | — | ● | ○ | ○ | ○ | ● |
| DEF<br>      | — | ○ | — | — | ○ | ○ |

(b) Air Outlet and Airflow Volume (for Front Seat Control Modes).




|    |                    |   |   |
|----|--------------------|---|---|
| *a | for 7 Inch Display | - | - |
|----|--------------------|---|---|



|    |                       |   |   |
|----|-----------------------|---|---|
| *a | for 11.6 Inch Display | - | - |
|----|-----------------------|---|---|

\*: Airflow is stopped when the front passenger seat is not occupied.


| MODE         | FACE   |      | FOOT  |      | DEF    |      |
|--------------|--------|------|-------|------|--------|------|
|              | CENTER | SIDE | FRONT | REAR | CENTER | SIDE |
|              | A      | B    | C     | D    | E      | F    |
| FACE<br>     | ○      | ○    | —     | —    | —      | —    |
| B/L<br>      | ○      | ○    | ○     | —    | —      | ●    |
| FOOT<br>     | —      | ●    | ○     | —    | ●      | ●    |
| FOOT/DEF<br> | —      | ●    | ○     | —    | ○      | ●    |
| DEF          |        |      |       |      |        |      |



## PARKING FRESH CONTROL

When 60 seconds have elapsed since the power switch has been turned off, the air conditioning amplifier assembly uses control logic which automatically changes the air inlet to FRESH mode to purge undesired odors from the air conditioning unit.

This logic will therefore reduce undesired odors upon starting the air conditioning system.



## COMPRESSOR WITH MOTOR ASSEMBLY

(a) General

### HINT:

In order to ensure the proper insulation of the internal high-voltage portion of the compressor and the compressor housing, this vehicle has adopted a compressor oil (ND-OIL 11) with a high level of insulation performance. Therefore, never use a compressor oil other than ND-OIL 11 type compressor oil or equivalent.

- (1) Along with the use of the hybrid system on this vehicle, an electric inverter compressor that is driven by a motor is used. The basic construction and operation of this compressor are the same as an ordinary scroll compressor, except that it is driven by an electric motor.
- (2) The Air Conditioning (A/C) inverter is integrated into the compressor with motor assembly.
- (3) The electric motor is actuated by 3-phase alternating current (244.8 V) supplied by the A/C inverter. As a result, the air conditioning control system on this vehicle is actuated without depending on the operation of the engine, thus realizing a comfortable air conditioning system and low fuel consumption.
- (4) Due to the use of an electric inverter compressor, the compressor speed can be controlled at the required speed calculated by the air conditioning amplifier assembly. Thus, the cooling and dehumidification performance and power consumption have been optimized.
- (5) Low-moisture permeation hoses are used for the suction and discharge hoses at the compressor in order to

minimize the entry of moisture into the refrigeration cycle.

(6) The compressor uses high-voltage alternating current. If a short or open circuit occurs in the compressor, the hybrid vehicle control ECU will cut off the A/C inverter circuit in order to stop the power supply to the compressor motor.

(b) Compressor Speed Control

(1) The air conditioning amplifier assembly calculates the target compressor speed based on the target evaporator temperature (calculated from the temperature control switch, cooler (room temp. sensor) thermistor, thermistor assembly, and automatic light control sensor) and the actual evaporator temperature detected by the No. 1 cooler thermistor. Then, the air conditioning amplifier assembly transmits the target speed to the hybrid vehicle control ECU. The hybrid vehicle control ECU controls the A/C inverter based on the target speed data in order to control the compressor to a speed that suits the operating condition of the air conditioning system.

(2) The air conditioning amplifier assembly calculates the target evaporator temperature (based on signals from the cooler (room temp. sensor) thermistor, thermistor assembly, automatic light control sensor and No. 1 cooler thermistor) and controls the compressor speed to an extent that will not inhibit proper cooling performance and defogging performance. As a result, comfort and low fuel consumption can be realized.

**NO. 1 COOLER THERMISTOR**


The No. 1 cooler thermistor detects the temperature of the cool air immediately after the evaporator in the form of resistance changes, and outputs it to the air conditioning amplifier assembly.

**BLOWER MOTOR WITH FAN SUB-ASSEMBLY**

The blower motor has a built-in blower controller, and is controlled using duty control performed by the air conditioning amplifier assembly.

**BUS CONNECTOR (AIR CONDITIONING HARNESS ASSEMBLY)**


(a) Bus connectors are used in the wire harness that connects the servo motors to the air conditioning amplifier assembly.



|    |   |    |   |
|----|---|----|---|
| *a | Example   | *b | Bus Connector<br>(to No. 1 Air Conditioning Radiator Damper Servo Sub-assembly) |
| *c | Bus Connector<br>(to No. 2 Air Conditioning Radiator Damper Servo Sub-assembly) | *d | Bus Connector<br>(to No. 3 Air Conditioning Radiator Damper Servo Sub-assembly) |
| *e | Bus Connector<br>(to No. 1 Blower Damper Servo Sub-                             | *f | to Air Conditioning Amplifier Assembly  |


|    |                            |   |   |
|----|----------------------------|---|---|
|    | assembly)                  |   |   |
| *g | to No. 1 Cooler Thermistor | - | - |

(b) Each bus connector has a built-in communication/driver IC which communicates with the air conditioning amplifier assembly, actuates the servo motor, and has a position detection function. This enables bus communication for the servo motor wire harness, for a more lightweight construction and a reduced number of wires.



## SERVO MOTOR

A pulse pattern type servo motor consists of a printed circuit board and a servo motor. The printed circuit board has three contact points, and can transmit two ON-OFF signals to the air conditioning amplifier assembly based on the difference of the pulse phases. The bus connector can detect the damper position and movement direction with these signals.



### AIR CONDITIONING THERMISTOR ASSEMBLY (w/ Humidity Sensor)

The air conditioning thermistor assembly detects the amount of raindrops on the windshield glass, the temperature of the windshield glass, and the temperature and humidity around the windshield glass and sends signals to the air conditioning amplifier assembly.

### COOLER (ROOM TEMP. SENSOR) THERMISTOR

The cooler (room temp. sensor) thermistor detects the cabin temperature based on changes in the resistance of its built-in thermistor and sends a signal to the air conditioning amplifier assembly.

### THERMISTOR ASSEMBLY

The thermistor assembly detects the outside temperature based on changes in the resistance of its built-in thermistor and sends a signal to the air conditioning amplifier assembly.

### AUTOMATIC LIGHT CONTROL SENSOR

The automatic light control sensor detects (in the form of changes in the current that flows through the built-in photo diode) the changes in the amount of sunlight and outputs these sunlight strength signals to the air conditioning amplifier assembly.

### AIR CONDITIONER PRESSURE SENSOR


The air conditioner pressure sensor detects the refrigerant pressure and outputs it to the air conditioning amplifier assembly in the form of voltage changes.






|   |                     |                                      |
|---|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000001FLBG       |
| <b>Model Year Start:</b> 2019   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [12/2018 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: SYSTEM DIAGRAM; 2019 MY Prius [12/2018 - ] |                     |                                      |



## [SYSTEM DIAGRAM](#)





\*1: for Lithium-ion Battery  
 \*2: for AWD

— : LIN Communication Line      ≡ : CAN Communication Line




Air Conditioning Amplifier Assembly



\*1: w/ Pre-collision System

\*2: w/ Navigation System

\*3: w/ Audio and Visual System


≡ : CAN Communication Line





Air Conditioning Amplifier Assembly

\*: w/o Automatic Light Control



Communication Table

| SENDER | RECEIVER | SIGNAL                                       | COMMUNICATION LINE |
|--------|----------|--|--------------------|
|        |          | Electricity load at low voltage state signal |                    |

|   |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
|---|----------------------------|--|--|---|--|---|-------------------------------|--|------------------------------------|----------------------------------|---|--|------------------------------------|--|---|------------------------|----------------------------------|-------------------------------------|-------------------------------------|--|--------------------------|-----|
| Air conditioning amplifier assembly                               | Hybrid vehicle control ECU | <table border="1"> <tr><td>Air conditioner pressure sensor signal</td></tr> <tr><td>Electro motion compressor command acceleration signal</td></tr> <tr><td>In-vehicle temperature signal</td></tr> <tr><td>Transmission system heating performance assistance request signal</td></tr> <tr><td>Blower level indicator signal</td></tr> <tr><td>Heater idle up request signal</td></tr> <tr><td>Engine ON request signal</td></tr> <tr><td>Charging control inhibit signal</td></tr> <tr><td>Electro motion compressor target revolutions signal</td></tr> <tr><td>Ambient temperature before correction signal</td></tr> <tr><td>Ambient temperature display signal</td></tr> <tr><td>Electro motion compressor start signal</td></tr> <tr><td>Humidity control for electro motion compressor start signal</td></tr> <tr><td>A/C cycle state signal</td></tr> <tr><td>Prior A/C control request signal</td></tr> <tr><td>A/C mode signal (EV drive distance)</td></tr> <tr><td>Standby for inverter request signal</td></tr> <tr><td>Inlet state signal (for cooling battery)</td></tr> <tr><td>A/C control state signal</td></tr> </table> | Air conditioner pressure sensor signal | Electro motion compressor command acceleration signal             | In-vehicle temperature signal          | Transmission system heating performance assistance request signal | Blower level indicator signal | Heater idle up request signal                | Engine ON request signal           | Charging control inhibit signal  | Electro motion compressor target revolutions signal | Ambient temperature before correction signal | Ambient temperature display signal | Electro motion compressor start signal | Humidity control for electro motion compressor start signal | A/C cycle state signal | Prior A/C control request signal | A/C mode signal (EV drive distance) | Standby for inverter request signal | Inlet state signal (for cooling battery) | A/C control state signal | CAN |
| Air conditioner pressure sensor signal                            |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Electro motion compressor command acceleration signal             |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| In-vehicle temperature signal                                     |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Transmission system heating performance assistance request signal |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Blower level indicator signal                                     |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Heater idle up request signal                                     |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Engine ON request signal  |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Charging control inhibit signal                                   |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Electro motion compressor target revolutions signal               |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Ambient temperature before correction signal                      |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Ambient temperature display signal                                |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Electro motion compressor start signal                            |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Humidity control for electro motion compressor start signal       |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| A/C cycle state signal  |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Prior A/C control request signal                                  |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| A/C mode signal (EV drive distance)                               |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Standby for inverter request signal                               |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Inlet state signal (for cooling battery)                          |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| A/C control state signal  |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Air conditioning amplifier assembly                               | ECM                        | <table border="1"> <tr><td>Air conditioner pressure sensor signal</td></tr> <tr><td>Transmission system heating performance assistance request signal</td></tr> <tr><td>Motor cooling fan drive request signal</td></tr> <tr><td>Water stop valve open request signal</td></tr> <tr><td>Heater idle up request signal</td></tr> <tr><td>Ambient temperature before correction signal</td></tr> <tr><td>Ambient temperature display signal</td></tr> <tr><td>Prior A/C control request signal</td></tr> </table>  | Air conditioner pressure sensor signal | Transmission system heating performance assistance request signal | Motor cooling fan drive request signal | Water stop valve open request signal                              | Heater idle up request signal | Ambient temperature before correction signal | Ambient temperature display signal | Prior A/C control request signal | CAN   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Air conditioner pressure sensor signal                            |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Transmission system heating performance assistance request signal |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Motor cooling fan drive request signal                            |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Water stop valve open request signal                              |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Heater idle up request signal                                     |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Ambient temperature before correction signal                      |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Ambient temperature display signal                                |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Prior A/C control request signal                                  |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
|   |                            | <table border="1"> <tr><td>A/C mode signal (EV drive distance)</td></tr> <tr><td>Recirculation indicator signal</td></tr> <tr><td>Fresh indicator signal</td></tr> <tr><td>A/C indicator signal</td></tr> <tr><td>Blower level indicator signal</td></tr> <tr><td></td></tr> </table>  | A/C mode signal (EV drive distance)    | Recirculation indicator signal                                    | Fresh indicator signal                 | A/C indicator signal  | Blower level indicator signal |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| A/C mode signal (EV drive distance)                               |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Recirculation indicator signal                                    |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Fresh indicator signal  |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| A/C indicator signal  |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
| Blower level indicator signal                                     |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |
|   |                            |  |  |   |  |   |                               |  |                                    |                                  |   |  |                                    |  |   |                        |                                  |                                     |                                     |  |                          |     |



|                                     |   |  |     |
|-------------------------------------|---|--|-----|
| Air conditioning amplifier assembly | Combination meter assembly  | Blower manual status signal<br>S-FLOW switch indicator signal<br>A/C on-screen request signal<br>S-FLOW state signal<br>Temperature display signal<br>A/C eco state indicator signal<br>A/C eco judge signal<br>Seat priority indicator request signal<br>Control information signal<br>Switch select information signal<br>In-vehicle temperature signal<br>Ambient temperature display signal<br>Ambient temperature display whole number/decimal (0/0.5°C) signal<br>A/C control state signal   | CAN |
| Air conditioning amplifier assembly | Navigation receiver assembly*1<br>Radio and display receiver assembly*2 | A/C mode signal (EV drive distance)<br>A/C display request signal<br>A/C warning on-screen request signal<br>Switch state control request signal<br>Buzzer on request signal<br>AUTO indicator signal<br>Front defroster indicator signal<br>Rear defogger indicator signal<br>Recirculation indicator signal<br>Fresh indicator signal<br>A/C indicator signal<br>Blower level indicator signal<br>Outlet indicator signal<br>Blower manual status signal<br>S-FLOW switch indicator signal<br>A/C on-screen request signal<br>S-FLOW state signal<br>A/C eco display request signal<br>Temperature display signal<br>A/C energy level signal<br>A/C eco state indicator signal<br>Seat priority indicator request signal<br>A/C screen select information signal | CAN |

|                                     |  |   |     |
|-------------------------------------|--|---|-----|
|                                     |  | Temperature unit select information signal                              |     |
|                                     |  | Blower step select information signal                                   |     |
|                                     |  | Speech recognition level information signal                             |     |
|                                     |  | Switch select information signal  |     |
|                                     |  | Destination select information signal                                   |     |
|                                     |  | Control information signal  |     |
|                                     |  | A/C recirculation/fresh collaborated with navigation information signal |     |
|                                     |  | Rear defogger drive request signal                                      |     |
|                                     |  | In-vehicle temperature signal   |     |
|                                     |  | Ambient temperature display signal                                      |     |
|                                     |  | Ambient temperature display whole number/decimal (0/0.5°C) signal       |     |
|                                     |  | A/C control state signal  |     |
| Air conditioning amplifier assembly | Skid control ECU (brake booster with master cylinder assembly) | Ambient temperature before correction signal                            | CAN |
| Air conditioning amplifier assembly | Driving support ECU assembly*3                                 | Ambient temperature display signal                                      | CAN |
| Air conditioning amplifier assembly | Forward recognition camera*3                                   | Ambient temperature display signal                                      | CAN |
| Air conditioning amplifier assembly | Clearance warning ECU assembly                                 | Ambient temperature display signal                                      | CAN |
| Air conditioning amplifier assembly | Swing grill actuator assembly                                  | Ambient temperature sensor data signal                                  | CAN |
|                                     |  | Air conditioner pressure sensor data signal                             |     |
| Air conditioning amplifier assembly | Battery ECU assembly*5   | In-vehicle temperature signal   | CAN |
|                                     |  | Front blower level indicator signal                                     |     |
|                                     |  | Ambient temperature display signal                                      |     |
|                                     |  | Prior A/C control request signal  |     |
|                                     |  | Inlet state signal (for cooling battery)                                |     |
| Air conditioning amplifier assembly | Rear hybrid motor control inverter assembly*6                  | Ambient temperature before correction signal                            | CAN |
|                                     |  | Ambient temperature display signal                                      |     |
|                                     |  | A/C control state signal  |     |
|                                     |  | A/C ventilation request signal  |     |
|                                     |  | Shift position P signal   |     |
|                                     |  | Shift position R signal   |     |
|                                     |  | Shift position N signal   |     |
|                                     |  | Eco mode indicator signal   |     |
|                                     |  | Auxiliary battery maximum temperature signal                            |     |


|  |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
|--|-------------------------------------|---|-------------------------------|-------------------------------|--|--|--|-----------------|----------------------------------|----------------------------|-----------------------------------|--------------------------------|---|-----------------------|---|-------------------|--|---|-----------------------------|------------------------|---------------------------------|-----------------------------|------------------------------------|---|------------------------------------|--|--|----------------------------------|-----|
| Hybrid vehicle control ECU   | Air conditioning amplifier assembly | <table border="1"> <tr><td>IGBDON request signal from HV</td></tr> <tr><td>State of STB (standby) signal</td></tr> <tr><td>Compulsion recycle request signal</td></tr> <tr><td>Compulsion recycle request signal A/C inverter and HV ECU communication signal</td></tr> <tr><td>A/C permission electric power signal</td></tr> <tr><td>READY on signal</td></tr> <tr><td>A/C inverter main voltage signal</td></tr> <tr><td>A/C inverter output signal</td></tr> <tr><td>Motor overload information signal</td></tr> <tr><td>Motor start information signal</td></tr> <tr><td>A/C inverter internal power source malfunction signal</td></tr> <tr><td>STB wire short signal</td></tr> <tr><td>A/C inverter temperature information signal</td></tr> <tr><td>Self-check signal</td></tr> <tr><td>Thermistor cold temperature malfunction signal</td></tr> <tr><td>Inlet air temperature reduction request flag signal</td></tr> <tr><td>A/C motor revolution signal</td></tr> <tr><td>A/C input power signal</td></tr> <tr><td>A/C inverter temperature signal</td></tr> <tr><td>A/C inverter voltage signal</td></tr> <tr><td>A/C Inverter CPU error flag signal</td></tr> <tr><td>A/C Inverter CPU initialization flag signal</td></tr> <tr><td>A/C inverter identification signal</td></tr> <tr><td>HV battery cooling before charging flag signal</td></tr> <tr><td>A/C compressor motor load ratio signal</td></tr> <tr><td>Emergency generating flag signal</td></tr> </table> | IGBDON request signal from HV | State of STB (standby) signal | Compulsion recycle request signal              | Compulsion recycle request signal A/C inverter and HV ECU communication signal | A/C permission electric power signal             | READY on signal | A/C inverter main voltage signal | A/C inverter output signal | Motor overload information signal | Motor start information signal | A/C inverter internal power source malfunction signal | STB wire short signal | A/C inverter temperature information signal | Self-check signal | Thermistor cold temperature malfunction signal | Inlet air temperature reduction request flag signal | A/C motor revolution signal | A/C input power signal | A/C inverter temperature signal | A/C inverter voltage signal | A/C Inverter CPU error flag signal | A/C Inverter CPU initialization flag signal | A/C inverter identification signal | HV battery cooling before charging flag signal | A/C compressor motor load ratio signal | Emergency generating flag signal | CAN |
| IGBDON request signal from HV  |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| State of STB (standby) signal  |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| Compulsion recycle request signal  |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| Compulsion recycle request signal A/C inverter and HV ECU communication signal |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| A/C permission electric power signal   |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| READY on signal  |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| A/C inverter main voltage signal   |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| A/C inverter output signal   |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| Motor overload information signal  |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| Motor start information signal   |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| A/C inverter internal power source malfunction signal                          |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| STB wire short signal  |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| A/C inverter temperature information signal                                    |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| Self-check signal  |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| Thermistor cold temperature malfunction signal                                 |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| Inlet air temperature reduction request flag signal                            |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| A/C motor revolution signal  |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| A/C input power signal   |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| A/C inverter temperature signal  |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| A/C inverter voltage signal  |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| A/C Inverter CPU error flag signal   |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| A/C Inverter CPU initialization flag signal                                    |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| A/C inverter identification signal   |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| HV battery cooling before charging flag signal                                 |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| A/C compressor motor load ratio signal   |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| Emergency generating flag signal   |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
|  | Air conditioning amplifier          | <table border="1"> <tr><td>Engine speed data signal</td></tr> <tr><td>Intake air temperature signal</td></tr> <tr><td>Intake air temperature sensor fail flag signal</td></tr> <tr><td>Estimated flux of electric water pump signal</td></tr> <tr><td>Flag for water stop valve close condition signal</td></tr> </table>   | Engine speed data signal      | Intake air temperature signal | Intake air temperature sensor fail flag signal | Estimated flux of electric water pump signal                                   | Flag for water stop valve close condition signal |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| Engine speed data signal   |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| Intake air temperature signal  |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| Intake air temperature sensor fail flag signal                                 |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| Estimated flux of electric water pump signal                                   |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |
| Flag for water stop valve close condition signal                               |                                     |   |                               |                               |  |  |  |                 |                                  |                            |                                   |                                |   |                       |   |                   |  |   |                             |                        |                                 |                             |                                    |   |                                    |  |  |                                  |     |

|  |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
|--|-------------------------------------|---|----------------------------------|--|---------------------------------|--------------------------|-------------------------------------|-----------------------------------|--|-----------------------------------|-------------------------|--------------------------|-------------------------------|---------------------------------|--------------------------------|-----------------------------|-------------------------------|---|--|-------------------------------------|-----|
| ECM  | assembly                            | <table border="1"> <tr><td> </td></tr> <tr><td>Compulsory internal air circulation at high coolant temperature command signal</td></tr> <tr><td>Soak timer test failed signal</td></tr> <tr><td>Soak time signal</td></tr> <tr><td>Engine coolant temperature signal</td></tr> <tr><td>Heater water temperature signal</td></tr> <tr><td>ETHW calculated in engine control signal</td></tr> </table>  |                                  | Compulsory internal air circulation at high coolant temperature command signal | Soak timer test failed signal   | Soak time signal         | Engine coolant temperature signal   | Heater water temperature signal   | ETHW calculated in engine control signal | CAN                               |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
|  |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| Compulsory internal air circulation at high coolant temperature command signal |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| Soak timer test failed signal  |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| Soak time signal   |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| Engine coolant temperature signal  |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| Heater water temperature signal  |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| ETHW calculated in engine control signal                                       |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| Combination meter assembly   | Air conditioning amplifier assembly | <table border="1"> <tr><td>Vehicle speed signal</td></tr> <tr><td>Front passenger side seat occupant status signal</td></tr> <tr><td>S-FLOW on/off signal</td></tr> <tr><td>Blower customize signal</td></tr> <tr><td>Eco air conditioning switch signal</td></tr> <tr><td>Blower up switch signal</td></tr> <tr><td>Blower down switch signal</td></tr> <tr><td>Recirculation/fresh switch signal</td></tr> <tr><td>TEMP up switch signal</td></tr> <tr><td>TEMP down switch signal</td></tr> </table>   | Vehicle speed signal             | Front passenger side seat occupant status signal                               | S-FLOW on/off signal            | Blower customize signal  | Eco air conditioning switch signal  | Blower up switch signal           | Blower down switch signal                | Recirculation/fresh switch signal | TEMP up switch signal   | TEMP down switch signal  | CAN                           |                                 |                                |                             |                               |   |  |                                     |     |
| Vehicle speed signal   |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| Front passenger side seat occupant status signal                               |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| S-FLOW on/off signal   |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| Blower customize signal  |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| Eco air conditioning switch signal   |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| Blower up switch signal  |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| Blower down switch signal  |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| Recirculation/fresh switch signal  |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| TEMP up switch signal  |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| TEMP down switch signal  |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| Navigation receiver assembly*1<br>Radio and display receiver assembly*2        | Air conditioning amplifier assembly | <table border="1"> <tr><td>AVN1S04 valid information signal</td></tr> <tr><td>A/C ECO switch status signal</td></tr> <tr><td>Panel design information signal</td></tr> <tr><td>AUTO switch state signal</td></tr> <tr><td>Front defroster switch state signal</td></tr> <tr><td>Rear defogger switch state signal</td></tr> <tr><td>Air inlet switch state signal</td></tr> <tr><td>OFF switch state signal</td></tr> <tr><td>A/C switch state signal</td></tr> <tr><td>Mode switch state signal</td></tr> <tr><td>Blower up switch state signal</td></tr> <tr><td>Blower down switch state signal</td></tr> <tr><td>Air outlet switch state signal</td></tr> <tr><td>TEMP up switch state signal</td></tr> <tr><td>TEMP down switch state signal</td></tr> <tr><td>Seat speech recognition mode information signal</td></tr> <tr><td>Seat speech recognition date addition subtraction information signal</td></tr> <tr><td>Seat speech recognition temperature</td></tr> </table> | AVN1S04 valid information signal | A/C ECO switch status signal   | Panel design information signal | AUTO switch state signal | Front defroster switch state signal | Rear defogger switch state signal | Air inlet switch state signal            | OFF switch state signal           | A/C switch state signal | Mode switch state signal | Blower up switch state signal | Blower down switch state signal | Air outlet switch state signal | TEMP up switch state signal | TEMP down switch state signal | Seat speech recognition mode information signal | Seat speech recognition date addition subtraction information signal | Seat speech recognition temperature | CAN |
| AVN1S04 valid information signal   |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| A/C ECO switch status signal   |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| Panel design information signal  |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| AUTO switch state signal   |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| Front defroster switch state signal  |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| Rear defogger switch state signal  |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| Air inlet switch state signal  |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| OFF switch state signal  |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| A/C switch state signal  |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| Mode switch state signal   |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| Blower up switch state signal  |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| Blower down switch state signal  |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| Air outlet switch state signal   |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| TEMP up switch state signal  |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| TEMP down switch state signal  |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| Seat speech recognition mode information signal                                |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| Seat speech recognition date addition subtraction information signal           |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |
| Seat speech recognition temperature  |                                     |   |                                  |  |                                 |                          |                                     |                                   |  |                                   |                         |                          |                               |                                 |                                |                             |                               |   |  |                                     |     |

|  |  |  |     |
|--|--|--|-----|
|  |  | directions data signal                                   |     |
| Main body ECU<br>(multiplex network<br>body ECU) | Air conditioning amplifier<br>assembly | Security control signal                                  | CAN |
|  |  | Hood courtesy switch signal                              |     |
|  |  | Wireless key switch on time signal                       |     |
|  |  | Wireless smart communication data signal                 |     |
|  |  | Auto dimmer signal                                       |     |
|  |  | ACC switch signal  |     |
|  |  | Driver side seat courtesy switch signal                  |     |
|  |  | Front passenger side seat courtesy switch<br>signal      |     |
|  |  | Rear right side courtesy switch signal                   |     |
|  |  | Rear left side courtesy switch signal                    |     |
|  |  | Back door courtesy switch signal                         |     |
|  |  | Driver side door lock position switch signal             |     |
|  |  | Front passenger side door lock position<br>switch signal |     |
|  |  | Rear right side door lock position switch<br>signal      |     |
|  |  | Rear left side door lock position switch<br>signal       |     |
|  |  | Back door lock position switch signal                    |     |
|  |  | Destination symbol signal                                |     |
|  |  | Destination package signal                               |     |
|  |  | Steering wheel signal                                    |     |
|  |  | Solar data (R) signal                                    |     |
| Solar data (L) signal                            |  |  |     |
| A/C function information signal                  |  |  |     |
| Power steering ECU<br>assembly                   | Air conditioning amplifier<br>assembly | Loading control level signal                             | CAN |
| Airbag sensor assembly                           | Air conditioning amplifier<br>assembly | Front passenger side seat occupant status<br>signal      | CAN |
| Certification ECU<br>(smart key ECU<br>assembly) | Air conditioning amplifier<br>assembly | Push start switch signal                                 | CAN |
|  |  | Key signal for push start system use                     |     |
|  |  | Power mode signal  |     |
| Battery ECU<br>assembly*5                        | Air conditioning amplifier<br>assembly | A/C ventilation request signal                           | CAN |
|  |  | S-FLOW display instruction signal                        |     |
|  |  | ECO display instruction signal                           |     |
|  |  | Entire front panel display instruction signal            |     |
|  |  | AUTO display instruction signal                          |     |

|                                      |                                      |  |     |
|--------------------------------------|--------------------------------------|--|-----|
| Air conditioning amplifier assembly  | Air conditioning control assembly* 4 | Blower level display instruction signal<br>Recirculation/fresh display instruction signal<br>Air outlet display instruction signal<br>Rear defogger display instruction signal<br>Set temperature display instruction signal<br>Dimmer signal<br>A/C display instruction signal  | LIN |
| Air conditioning control assembly* 4 | Air conditioning amplifier assembly  | Independent control A/C information signal<br>AUTO switch operation signal<br>OFF switch operation signal<br>A/C switch operation signal<br>ECO switch operation signal<br>Blower switch operation signal (up, down)<br>S-FLOW switch operation signal<br>Air outlet switch operation signal<br>Front defroster switch operation signal<br>Rear defogger switch operation signal<br>Set temperature switch operation signal<br>Recirculation/fresh switch operation signal | LIN |


- \*1: w/ Navigation System
- \*2: w/ Audio and Visual System
- \*3: w/ Pre-collision System
- \*4: except 11.6 Inch Display
- \*5: for Lithium-ion Battery
- \*6: for AWD



|  |              |                               |
|--|--------------|-------------------------------|
| Last Modified: 01-14-2019  | 6.8:8.0.48   | Doc ID: RM100000001FYIO       |
| Model Year Start: 2019   | Model: Prius | Prod Date Range: [12/2018 - ] |
| Title: HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: TERMINALS OF ECU; 2019 MY Prius [12/2018 - ] |              |                               |

## TERMINALS OF ECU

### AIR CONDITIONING AMPLIFIER ASSEMBLY



#### HINT:

Check from the rear of the connector while it is connected to the air conditioning amplifier assembly.

| TERMINAL NO. (SYMBOL)        | WIRING COLOR     | TERMINAL DESCRIPTION  | CONDITION   | SPECIFIED CONDITION |
|------------------------------|------------------|---|---|---------------------|
| F57-1 (SG-1) - Body ground   | LG - Body ground | Ground for cooler (room temp. sensor) thermistor                | Always  | Below 1 V           |
| F57-2 (SG-2) - Body ground   | P - Body ground  | Ground for thermistor assembly, air conditioner pressure sensor | Always  | Below 1 V           |
| F57-4 (S5-1) - F58-4 (GND)*1 | L - W-B          | Power supply for cooler (solar sensor) thermistor               | Power switch on (IG)  | 4.5 to 5.5 V        |
|                              |                  |   | Power switch off  | Below 1 V           |
| F57-6 (S5-3) - F57-2 (SG-2)  | GR - P           | Power supply for air conditioner pressure sensor                | Power switch on (IG)  | 4.75 to 5.25 V      |
|                              |                  |   | Power switch off  | Below 1 V           |
| F57-13 (TAM) - F57-2 (SG-2)  | BE - P           | Thermistor assembly signal                                      | <ul style="list-style-type: none"> <li>Power switch on (IG)</li> <li>Ambient temperature: 25°C (77°F)</li> </ul>  | 1.35 to 1.75 V      |
|                              |                  |   | <ul style="list-style-type: none"> <li>Power switch on (IG)</li> <li>Ambient temperature: 40°C (104°F)</li> </ul> | 0.9 to 1.2 V        |

|                                     |            |  |  |                  |
|-------------------------------------|------------|--|--|------------------|
| F57-14<br>(TR) - F57-1<br>(SG-1)    | B - LG     | Cooler (room temp. sensor) thermistor signal | <ul style="list-style-type: none"> <li>Power switch on (IG)</li> <li>Cabin temperature: 25°C (77°F)</li> </ul>   | 1.8 to 2.2 V     |
|                                     |            |  | <ul style="list-style-type: none"> <li>Power switch on (IG)</li> <li>Cabin temperature: 40°C (104°F)</li> </ul>  | 1.2 to 1.6 V     |
| F57-22<br>(TS) - F58-4<br>(GND)*1   | BE - W-B   | Cooler (solar sensor) thermistor signal      | <ul style="list-style-type: none"> <li>Power switch on (IG)</li> <li>Cooler (solar sensor) thermistor subjected to electric light</li> </ul>   | 0.8 to 4.3 V     |
|                                     |            |  | <ul style="list-style-type: none"> <li>Power switch on (IG)</li> <li>Cooler (solar sensor) thermistor covered with cloth</li> </ul>  | Below 0.8 V      |
| F57-24<br>(PRE) - F57-2<br>(SG-2)   | SB - P     | Air conditioner pressure sensor signal       | <ul style="list-style-type: none"> <li>Power switch on (READY)</li> <li>Air conditioning system operating</li> <li>Refrigerant pressure: Abnormal pressure (more than 3025 kPa (30.8 kgf/cm<sup>2</sup>, 439 psi))</li> </ul>  | 4.61 V or higher |
|                                     |            |  | <ul style="list-style-type: none"> <li>Power switch on (READY)</li> <li>Air conditioning system operating</li> <li>Refrigerant pressure: Abnormal pressure (less than 176 kPa (1.8 kgf/cm<sup>2</sup>, 26 psi))</li> </ul>   | Below 0.74 V     |
|                                     |            |  | <ul style="list-style-type: none"> <li>Power switch on (READY)</li> <li>Air conditioning system operating</li> <li>Refrigerant pressure: Normal pressure (less than 3025 kPa (30.8 kgf/cm<sup>2</sup>, 439 psi) and more than 176 kPa (1.8 kgf/cm<sup>2</sup>, 26 psi))</li> </ul> | 0.74 to 4.61 V   |
| F57-26<br>(SHIN) - F58-4<br>(GND)*2 | R - W-B    | Seat heater switch signal                    | <ul style="list-style-type: none"> <li>Power switch on (IG)</li> <li>Seat heater switch (for driver side) off</li> </ul>   | 11 to 14 V       |
|                                     |            |  | <ul style="list-style-type: none"> <li>Power switch on (IG)</li> <li>Seat heater switch (for driver side) on</li> </ul>  | Below 1 V        |
| F58-1 (B) - F58-4 (GND)             | V - W-B    | Power source (Back-up)                       | Power switch off   | 11 to 14 V       |
| F58-2 (IG+) - F58-4 (GND)           | B - W-B    | Power source (IG)                            | Power switch on (IG)   | 11 to 14 V       |
|                                     |            |  | Power switch off   | Below 1 V        |
| F58-4 (GND) -                       | W-B - Body | Ground for main power supply                 | Always   | Below 1 V        |



|                               |          |  |   |                                   |
|-------------------------------|----------|--|---|-----------------------------------|
| Body ground                   | ground   |  |   |                                   |
| F58-6 (BLW) - F58-4 (GND)     | SB - W-B | Blower motor speed control signal  | <ul style="list-style-type: none"> <li>• Power switch on (IG)</li> <li>• Blower switch: LO</li> </ul>                   | Pulse generation (See waveform 1) |
| F58-11 (CANH) - F58-12 (CANL) | BE - W   | CAN communication signal   | CAN communication is performed  | Pulse generation                  |
| F58-14 (LIN1) - F58-4 (GND)*5 | SB - W-B | LIN communication signal (Air conditioning control assembly)   | Power switch on (IG)  | Pulse generation (See waveform 2) |
| F58-15 (SCLI) - F58-4 (GND)*3 | G - W-B  | LIN communication signal (Air conditioning thermistor assembly*3, windshield wiper relay assembly*4) | Power switch on (IG)  | Pulse generation                  |
| z23-2 (BUSG) - Body ground    | -        | Ground for BUS IC  | Always  | Below 1 V                         |
| z23-3 (BUS) - z23-2 (BUSG)    | -        | BUS IC control signal  | Power switch on (IG)  | Pulse generation (See waveform 3) |
| z23-4 (BBUS) - z23-2 (BUSG)   | -        | Power supply for BUS IC  | Power switch off  | 11 to 14 V                        |
| z23-5 (SGA) - Body ground     | -        | Ground for No. 1 cooler thermistor   | Always  | Below 1 V                         |
| z23-6 (TEA) - z23-5 (SGA)     | GR - GR  | No. 1 cooler thermistor signal   | <ul style="list-style-type: none"> <li>• Power switch on (IG)</li> <li>• Evaporator temperature: 0°C (32°F)</li> </ul>  | 1.7 to 2.1 V                      |
|                               |          |  | <ul style="list-style-type: none"> <li>• Power switch on (IG)</li> <li>• Evaporator temperature: 15°C (59°F)</li> </ul> | 0.9 to 1.3 V                      |

\*1: w/o Automatic Light Control


\*2: w/ Seat Heater System

\*3: w/ Humidity Sensor

\*4: w/ Auto Wiper System


\*5: except 11.6 Inch Display

(a) Waveform 1:




| ITEM              | CONTENT  |
|-------------------|--|
| Terminal No.      | F58-6 (BLW) - F58-4 (GND)  |
| Tool Setting      | 2 V/DIV., 1 ms./DIV.   |
| Vehicle Condition | <ul style="list-style-type: none"><li>• Power switch on (IG)</li><li>• Blower switch: LO</li></ul> |

(b) Waveform 2:




| ITEM              | CONTENT                     |
|-------------------|-----------------------------|
| Terminal No.      | F58-14 (LIN1) - F58-4 (GND) |
| Tool Setting      | 2 V/DIV., 20 ms./DIV.       |
| Vehicle Condition | Power switch on (IG)        |

(c) Waveform 3:



| ITEM              | CONTENT                    |
|-------------------|----------------------------|
| Terminal No.      | z23-3 (BUS) - z23-2 (BUSG) |
| Tool Setting      | 2 V/DIV., 2 ms./DIV.       |
| Vehicle Condition | Power switch on (IG)       |

### AIR CONDITIONING CONTROL ASSEMBLY (except 11.6 Inch Display)



#### HINT:

Check from the rear of the connector while it is connected to the air conditioning control assembly.

| TERMINAL NO.<br>(SYMBOL)   | WIRING<br>COLOR   | TERMINAL DESCRIPTION                         | CONDITION                                     | SPECIFIED<br>CONDITION |
|----------------------------|-------------------|--|---|------------------------|
| F52-1 (GND) - Body ground  | W-B - Body ground | Ground for air conditioning control assembly | Always  | Below 1 V              |
| F52-4 (ILL+) - Body ground | W - Body ground   | Illumination signal                          | Light control switch off                      | Below 1 V              |
|                            |                   |  | Light control switch in tail or head position | 11 to 14 V             |
| F52-5 (ILL-) - Body ground | V - Body ground   | Illumination signal                          | Always  | Below 1 V              |
| F52-6 (LIN1) - Body ground | SB - Body ground  | LIN communication signal                     | Power switch on (IG)                          | Pulse generation       |
| F52-8 (IG+) - F52-1 (GND)  | LG - W-B          | Power source (IG)                            | Power switch off                              | Below 1 V              |
|                            |                   |  | Power switch on (IG)                          | 11 to 14 V             |


### CHECK NAVIGATION RECEIVER ASSEMBLY (for 11.6 Inch Display)

Click here [INFO](#)

## HYBRID VEHICLE CONTROL ECU

for Nickel Metal Hydride Battery: Click here [INFO](#)

for Lithium-ion Battery: Click here [INFO](#)



|  |                     |                                      |
|--|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM1000000018JM1       |
| <b>Model Year Start:</b> 2018  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2017 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AIR CONDITIONING SYSTEM: U0131,U0142,U0151,U0155,U0163,U0293; Lost Communication with Electric Power Steering ECU; 2018 - 2019 MY Prius [11/2017 - ] |                     |                                      |

|            |              |  |
|------------|--------------|--|
| <b>DTC</b> | <b>U0131</b> | <b>Lost Communication with Electric Power Steering ECU</b> |
|------------|--------------|--|

|            |              |  |
|------------|--------------|--|
| <b>DTC</b> | <b>U0142</b> | <b>Lost Communication with Main Body ECU</b> |
|------------|--------------|--|

|            |              |  |
|------------|--------------|--|
| <b>DTC</b> | <b>U0151</b> | <b>Lost Communication with Restraints Control Module</b> |
|------------|--------------|--|

|            |              |  |
|------------|--------------|--|
| <b>DTC</b> | <b>U0155</b> | <b>Lost Communication with Combination Meter</b> |
|------------|--------------|--|

|            |              |  |
|------------|--------------|--|
| <b>DTC</b> | <b>U0163</b> | <b>Lost Communication with Navigation Control Module</b> |
|------------|--------------|--|

|            |              |                                       |
|------------|--------------|---------------------------------------|
| <b>DTC</b> | <b>U0293</b> | <b>Lost Communication with HV ECU</b> |
|------------|--------------|---------------------------------------|

## **DESCRIPTION**

| DTC NO. | DETECTION ITEM                                      | DTC DETECTION CONDITION  | TROUBLE AREA   | MEMORY    |
|---------|---|--|--|-----------|
| U0131   | Lost Communication with Electric Power Steering ECU | No communication with power steering ECU assembly                | <ul style="list-style-type: none"> <li>• CAN communication system</li> <li>• Power steering ECU assembly</li> </ul>                | Memorized |
| U0142   | Lost Communication with Main Body ECU               | No communication with main body ECU (multiplex network body ECU) | <ul style="list-style-type: none"> <li>• CAN communication system</li> <li>• Main body ECU (multiplex network body ECU)</li> </ul> | Memorized |
| U0151   | Lost Communication with Restraints Control Module   | No communication with airbag sensor assembly                     | <ul style="list-style-type: none"> <li>• CAN communication system</li> <li>• Airbag sensor assembly</li> </ul>                     | Memorized |
| U0155   | Lost Communication with Combination Meter           | No communication with combination meter assembly                 | <ul style="list-style-type: none"> <li>• CAN communication system</li> <li>• Combination meter</li> </ul>                          | Memorized |

|       |   |   |   |           |
|-------|---|---|---|-----------|
|       |   |   | assembly  |           |
| U0163 | Lost Communication with Navigation Control Module | No communication with navigation receiver assembly* | <ul style="list-style-type: none"> <li>• CAN communication system</li> <li>• Navigation receiver assembly*</li> </ul> | Memorized |
| U0293 | Lost Communication with HV ECU                    | No communication with hybrid vehicle control ECU    | <ul style="list-style-type: none"> <li>• CAN communication system</li> <li>• Hybrid vehicle control ECU</li> </ul>    | Memorized |

\*: for 11.6 Inch Display

## **PROCEDURE**


|           |                                       |
|-----------|---------------------------------------|
| <b>1.</b> | <b>GO TO CAN COMMUNICATION SYSTEM</b> |
|-----------|---------------------------------------|

### **HINT:**

Refer to CAN Communication System.

Click here [INFO](#) [INFO](#)

**NEXT**  **END**



|   |                     |                                      |
|---|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000T88B       |
| <b>Model Year Start:</b> 2016   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: AMBIENT TEMPERATURE SENSOR: INSTALLATION; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

## [INSTALLATION](#)


### [PROCEDURE](#)

#### **1. INSTALL THERMISTOR ASSEMBLY**

- (a) Connect the connector.
- (b) Engage the clamp to install the thermistor assembly.

#### **2. INSTALL FRONT BUMPER ASSEMBLY**

Click here [INFO](#) [INFO](#)



|  |                     |                                      |
|--|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000TBWT       |
| <b>Model Year Start:</b> 2016  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: BLOWER UNIT: INSTALLATION; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

## [INSTALLATION](#)

### [PROCEDURE](#)

#### **1. INSTALL BLOWER ASSEMBLY**


- (a) Engage the 3 guides and 2 claws.
- (b) Install the blower assembly to the air conditioning radiator assembly with the 2 screws.
- (c) Engage 4 guides.
- (d) Connect the connector.

#### **2. INSTALL NO. 2 AIR DUCT**

Click here [INFO](#)

#### **3. INSTALL AIR CONDITIONER UNIT ASSEMBLY**

Click here [INFO](#) [INFO](#) [INFO](#)





|  |                     |   |
|--|---------------------|---|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000SJU1              |
| <b>Model Year Start:</b> 2016  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 -        ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: CONDENSER: ON-VEHICLE INSPECTION; 2016 - 2019 MY Prius [11/2015 -        ] |                     |   |

## **ON-VEHICLE INSPECTION**

### **PROCEDURE**

#### **1. INSPECT COOLER CONDENSER ASSEMBLY**

- (a) If the cooler condenser assembly fins are dirty, clean them with water and dry them with compressed air.


**NOTICE:**

Do not damage the cooler condenser assembly fins.

- (b) If any cooler condenser assembly fins are bent, straighten them using a screwdriver or pliers.

#### **2. INSPECT FOR REFRIGERANT LEAK**

- (a) Using a halogen leak detector, check the pipe joints for refrigerant leaks.
- (b) If a refrigerant leak is detected in a joint, check the torque of the bolt of the joint.



|   |                     |                                      |
|---|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000T87X       |
| <b>Model Year Start:</b> 2016   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: FRONT BLOWER MOTOR: INSTALLATION; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

## [INSTALLATION](#)

### [PROCEDURE](#)

#### **1. INSTALL BLOWER MOTOR WITH FAN SUB-ASSEMBLY**

- (a) Install the blower motor with fan sub-assembly with the 3 screws.


**NOTICE:**

Replace the blower motor with fan sub-assembly if it has been dropped or subjected to a severe impact.

- (b) Connect the connector.  
(c) Engage the clamp.

#### **2. INSTALL NO. 2 INSTRUMENT PANEL UNDER COVER SUB-ASSEMBLY**

Click here [INFO](#) [INFO](#)





|  |                     |                                      |
|--|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019   | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000T885       |
| <b>Model Year Start:</b> 2016  | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: ROOM TEMPERATURE SENSOR: INSTALLATION; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

## INSTALLATION

### PROCEDURE

#### 1. INSTALL COOLER (ROOM TEMP. SENSOR) THERMISTOR

- (a) Connect the connector and aspirator.
- (b) Engage the 2 claws to install the cooler (room temp. sensor) thermistor as shown in the illustration.



#### 2. INSTALL NO. 2 LOWER INSTRUMENT PANEL FINISH PANEL

Click here [INFO](#) [INFO](#)

#### 3. INSTALL SHIFT LEVER HOLE COVER

Click here [INFO](#) [INFO](#)

#### 4. INSTALL LOWER CENTER INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY

Click here [INFO](#) [INFO](#)

#### 5. INSTALL GLOVE COMPARTMENT DOOR ASSEMBLY

Click here [INFO](#) [INFO](#)

#### 6. INSTALL LOWER NO. 1 INSTRUMENT PANEL AIRBAG ASSEMBLY

Click here [INFO](#)

#### 7. INSTALL REAR CONSOLE BOX ASSEMBLY

Click here [INFO](#) [INFO](#)



|   |                     |                                      |
|---|---------------------|--------------------------------------|
| <b>Last Modified:</b> 01-14-2019  | 6.8:8.0.48          | <b>Doc ID:</b> RM100000000T88H       |
| <b>Model Year Start:</b> 2016   | <b>Model:</b> Prius | <b>Prod Date Range:</b> [11/2015 - ] |
| <b>Title:</b> HEATING / AIR CONDITIONING: SOLAR SENSOR: INSTALLATION; 2016 - 2019 MY Prius [11/2015 - ] |                     |                                      |

## [INSTALLATION](#)

### [PROCEDURE](#)

#### **1. INSTALL AUTOMATIC LIGHT CONTROL SENSOR**

- (a) Engage the 2 claws to install the automatic light control sensor.
- (b) Connect the connector.

#### **2. INSTALL DEFROSTER NOZZLE ASSEMBLY**

Click here [INFO](#)

#### **3. INSTALL NO. 1 INSTRUMENT PANEL PIN**

Click here [INFO](#)

#### **4. INSTALL UPPER INSTRUMENT PANEL ASSEMBLY**

Click here [INFO](#)

