	<u> </u>
50,000 miles or 60 months	55,000 miles or 66 months
<ul> <li>□ Check installation of driver's floor mat</li> <li>□ Clean cabin air filter (vehicles with solar power ventilation system)</li> <li>□ Inspect and adjust all fluid levels</li> <li>□ Inspect wiper blades</li> <li>□ Replace engine oil and oil filter <sup>1</sup></li> <li>□ Rotate tires</li> <li>□ Visually inspect brake linings/drums and</li> </ul>	☐ Check installation of driver's floor mat ☐ Inspect and adjust all fluid levels ☐ Inspect wiper blades ☐ Rotate tires ☐ Visually inspect brake linings/drums and brake pads/discs  Note: If OW-20 oil WAS NOT used at
brake pads/discs  Note: Driving in heavy traffic, on dirt roads or in urban, dusty or desert	the last oil change, replace engine oil and oil filter. <sup>1</sup>
areas may shorten the life of the cabin air filter. Replacement may be needed	Additional Maintenance Items for Special Operating Conditions <sup>2</sup>
if you notice reduced air flow from the air conditioner and heater or if the windows fog easily when you use the "Fresh" mode. Consult your dealer if any of these conditions occur.  Additional Maintenance Items for	Driving on dirt roads or dusty roads:  ☐ Inspect ball joints and dust covers ☐ Inspect drive shaft boots ☐ Inspect engine air filter ☐ Inspect steering linkage and boots ☐ Replace engine oil and oil filter ☐ Tighten nuts and bolts on chassis and
Special Operating Conditions <sup>2</sup>	body
Driving on dirt roads or dusty roads:  ☐ Inspect ball joints and dust covers ☐ Inspect drive shaft boots ☐ Inspect engine air filter ☐ Inspect steering linkage and boots ☐ Tighten nuts and bolts on chassis and body  Driving while towing, using a car-top carrier, or heavy vehicle loading <sup>5</sup> : ☐ Tighten nuts and bolts on chassis and	Driving while towing, using a car-top carrier, or heavy vehicle loading <sup>5</sup> :  ☐ Replace engine oil and oil filter <sup>1</sup> ☐ Tighten nuts and bolts on chassis and body  Repeated trips of less than five miles in temperatures below 32°F / 0°C: ☐ Replace engine oil and oil filter <sup>1</sup> Extensive idling and/or low speed driving
body	for a long distance such as police, taxi or door-to-door delivery use:  ☐ Replace engine oil and oil filter <sup>1</sup>
Dealer Service Verification:	Dealer Service Verification:
Date: Mileage:	Date: Mileage: