



L37(A), L38(B), L39(C), L40(D), L41(E), L42(F), L45(G)
 Navigation Receiver Assembly
 L40(D), L41(E), L45(G)
 Radio Receiver Assembly




U3(A), U13(B)
 Map Light Assembly

L37(A), L38(B), L39(C), L40(D), L41(E), L42(F), L45(G)
 Navigation Receiver Assembly
 L40(D), L41(E), L45(G)
 Radio Receiver Assembly




L37(A), L38(B), L39(C), L40(D), L41(E), L42(F), L45(G)
 Navigation Receiver Assembly
 L40(D), L41(E), L45(G)
 Radio Receiver Assembly



* 7 : w/ Rear View Monitor
 * 8 : w/ Safety Connect System




L37(A), L38(B), L39(C), L40(D), L41(E), L42(F), L45(G)
 Navigation Receiver Assembly
 L40(D), L41(E), L45(G)
 Radio Receiver Assembly





* 8 : w/ Safety Connect System
 * 9 : w/o Safety Connect System

L37(A), L38(B), L39(C), L40(D), L41(E), L42(F), L45(G)
 Navigation Receiver Assembly
 L40(D), L41(E), L45(G)
 Radio Receiver Assembly




When wiring colors are indicated with (**), either the colored wiring (general wiring) or the painted wiring is used.



L37(A), L38(B), L39(C), L40(D), L41(E), L42(F), L45(G)
 Navigation Receiver Assembly
 L40(D), L41(E), L45(G)
 Radio Receiver Assembly




L37(A), L38(B), L39(C), L40(D), L41(E), L42(F), L45(G)
 Navigation Receiver Assembly
 L40(D), L41(E), L45(G)
 Radio Receiver Assembly




L37(A), L38(B), L39(C), L40(D), L41(E), L42(F), L45(G)
 Navigation Receiver Assembly
 L40(D), L41(E), L45(G)
 Radio Receiver Assembly




L37(A), L38(B), L39(C), L40(D), L41(E), L42(F), L45(G)
 Navigation Receiver Assembly
 L40(D), L41(E), L45(G)
 Radio Receiver Assembly




L37(A), L38(B), L39(C), L40(D), L41(E), L42(F), L45(G)
 Navigation Receiver Assembly
 L40(D), L41(E), L45(G)
 Radio Receiver Assembly







- * 3 : w/ Navigation System
- * 7 : w/ Rear View Monitor
- * 8 : w/ Safety Connect System




A58
Skid Control ECU with Actuator Assembly






A 21
Gray




A 25
White




A 58
Gray




I 4
White




I 5
White




L 5
Gray




L 6
Gray




L 14
Blue




L 15
White




L 19
White




L 27
White




L 30
White



L 31
White




L 32
Blue




L 36
White




L 37
White




L 38
Black




L 39
Blue




L 40
White




L 41
White




L 42
Gray




L 45
White




L 52
Black




L 85
White




L 87
Black




L 89
Black




L 92
White

















L 93
White




L 94
White







3A
White




3B
White




4A
White




4B
White




AL1
Blue




AL2
Gray




AL3
White




AL4
Black




L11
Black




L12
White




LR1
White




LR2
Black




LS2
Black




Lz1
White




Lz2
White




NL2
White




OL2
White




PS1
White




QR1
White



UL1
Gray



UL2
White



VR1
White

