

■ Power windows and moon roof* (→P. 198, 202)

Function	Default setting	Customized setting	①	②	③
Mechanical key linked operation (open)	Off	On	-	-	0
Mechanical key linked operation (close)	Off	On	-	-	0
Wireless remote control linked operation (open only)	Off	On	-	-	0
Mechanical key, wireless remote control linked operation signal (buzzer)	On	Off	-	-	0

*: If equipped

■ Reverse warning buzzer (→P. 236)

Function	Default setting	Customized setting	①	②	③
Signal (buzzer) when the shift position is in R	Intermittent	Single	-	-	0

■ Turn signal lever (→P. 240)

Function	Default setting	Customized setting	①	②	③
Times of flashing of the lane change signal flashers	3	Off	-	-	0
		5			
		7			