

WIRELESS DOOR LOCK CONTROL SYSTEM > CUSTOMIZE PARAMETERS

for Preparation [Click here](#)

CUSTOMIZING FUNCTION WITH INTELLIGENT TESTER

HINT:

The following items can be customized.

NOTICE:

- When the customer requests a change in a function, first make sure that the function can be customized.
- Be sure to make a note of the current settings before customizing.
- When troubleshooting a function, first make sure that the function is set to the default setting.

CUSTOMIZE

- Connect the intelligent tester to the DLC3.
- Turn the power switch on (IG).
- Turn the intelligent tester on.
- Enter the following menus: Body / Main Body or Illuminated Entry / Utility / Customize.
- Select the setting by referring to the table below.

Wireless Door Lock Control System

Display (item)	Default	Function	Setting
Wireless Control	ON	Function that turns wireless door lock function on or off	ON or OFF
Hazard Answer Back	ON	When the doors are locked by wireless operation, the hazard warning lights flash once. When the doors are unlocked by wireless operation, the hazard warning lights flash twice.	ON or OFF
Open Door Warning	ON	The buzzer sounds when lock is pressed when any of the doors are ajar.	ON or OFF
Auto Lock Time	30 s	Function that regulates the interval between unlocking and automatic relocking of doors	30 s, 60 s or 120 s

Illuminated Entry

Display	Default	Content	Setting
Lighting Time	15 s	Changes the lighting time after closing all doors. (It will quickly fade out in case of turning the power switch from off to on (ACC or IG).)	7.5 s, 15 s or 30 s

