



H

*1	Front Wheel Opening Extension LH	*2	Front Floor Cover LH
*3	Rear Floor Side Member Cover LH	*4	No. 2 Floor Under Cover
*5	Front Fender Sprashshield FR LH	*6	No. 2 Engine Under Cover
*7	Front Fender Sprashshield FR RH	*8	Front Wheel Opening Extension RH
*9	No. 1 Engine Under Cover Assembly	*10	Front Floor Cover RH
*11	Rear Floor Side Member Cover RH	*12	No. 1 Floor Under Cover
*13	Rear Body Floor Cover RR		
*a	Aero Stabilizing Fin	-	-