













Position of Parts in Instrument Panel



Position of Parts in Instrument Panel


K1	Airbag ECU Assembly
K4	Instrument Panel Passenger Airbag without Door Assembly
K5	Instrument Panel Passenger Airbag without Door Assembly
K6	Spiral Cable Sub-Assembly
K7	No. 1 Instrument Panel Lower Airbag Assembly
K8	DLC3
K9	Telematics Transceiver
K11	Hybrid Vehicle Control ECU
K13	Certification ECU
K14	No. 4 Junction Connector
K15	Main Body ECU
K16	Main Body ECU
K17	Main Body ECU
K18	Combination Meter Assembly
K19	Combination Meter Assembly
K20	Power Distribution Box Assembly
K21	Power Distribution Box Assembly
K22	Electric Parking Brake Switch Assembly
K23	Certification ECU
K24	No. 5 Junction Connector
K25	No. 6 Junction Connector
K26	Integration Control Supply
K27	Foot Light RH (No. 1 Interior Illumination Light Assembly)
K28	Foot Light LH (No. 1 Interior Illumination Light Assembly)
K29	Rear Seat Heater Switch RH

Position of Parts in Instrument Panel




Position of Parts in Instrument Panel

K16
White




90980-12C63

K17
Black




90980-12C62

K18
White




90980-12E01

K19
Black




90980-12E02

K20
Gray




90980-12E73

K21
White




90980-12E69

K22
Black



90980-12370


K23
White



90980-12E93


Position of Parts in Instrument Panel

K24
Black




90980-12B54

K25
Black



90980-12B54

K26
White



90980-12976

K27
White




90980-11918

K28
White



90980-11918

K29
Black



90980-12C73