



*A	for Bolt with Adhesive	*B	except Bolt with Adhesive
*1	CYLINDER HEAD COVER GASKET	*2	CAMSHAFT POSITION SENSOR
*3	CYLINDER HEAD COVER SUB-ASSEMBLY	*4	GASKET
*5	SPARK PLUG TUBE GASKET	-	-
	N*m (kgf*cm, ft.*lbf): Specified torque	•	Non-reusable part