Autel



Vehicle information

Toyota Prius

Diagnostics time: 2025/04/26 20:13

Path: Automatic selection > Europe > w/ Smart Key > Diagnosis > Auto scan >

Status report

System name	DTC counts	Status
Engine and ect	3	Fault
Transmission control	2	Fault
ABS/VSC/TRC	0	Pass
SRS airbag	0	Pass
Hybrid control	0	Pass
Hv battery	0	Pass
Cruise control	0	Pass
EMPS	0	Pass
Air conditioner	1	Fault
Immobiliser	0	Pass
Body	0	Pass
Gateway	0	Pass
Entry&start	0	Pass
Power source control	0	Pass

1. Engine and ect — (3)

1.1. P0420	Catalyst system efficiency below threshold (bank 1)
	Current
1.2. P0420	Catalyst system efficiency below threshold (bank 1)
	Pending
1.3. P0420	Catalyst system efficiency below threshold (bank 1)



History

2. Transmission control —— (2)

2.1. C2300	Actuator system malfunction
	Current
2.2. C2318	Low voltage error (power supply malfunction)
	Current

3. Air conditioner — (1)

3.1. B1421	Solar sensor circuit (passenger side)
	Current