



Last Modified: 01-14-2019	6.8:8.0.48	Doc ID: RM100000000THEX
Model Year Start: 2016	Model: Prius	Prod Date Range: [11/2015 -]
Title: 2ZR-FXE (EMISSION CONTROL): VACUUM SENSOR: COMPONENTS; 2016 - 2019 MY Prius [11/2015 -]		

COMPONENTS

ILLUSTRATION



*1	E.F.I. VACUUM SENSOR ASSEMBLY (MANIFOLD ABSOLUTE PRESSURE SENSOR)	*2	VACUUM HOSE
	N*m (kgf*cm, ft.*lbf): Specified torque	-	-



Last Modified: 01-14-2019	6.8:8.0.48	Doc ID: RM100000000THEW
Model Year Start: 2016	Model: Prius	Prod Date Range: [11/2015 -]
Title: 2ZR-FXE (EMISSION CONTROL): VACUUM SENSOR: INSTALLATION; 2016 - 2019 MY Prius [11/2015 -]		

INSTALLATION

PROCEDURE

1. INSTALL E.F.I. VACUUM SENSOR ASSEMBLY (MANIFOLD ABSOLUTE PRESSURE SENSOR)


(a) Install the E.F.I. vacuum sensor assembly (manifold absolute pressure sensor) to the intake manifold with the bolt.

Torque:

7.0 N·m { 71 kgf·cm, 62 in·lbf }

(b) Connect the vacuum hose to the E.F.I. vacuum sensor assembly (manifold absolute pressure sensor).

(c) Connect the E.F.I. vacuum sensor assembly (manifold absolute pressure sensor) connector.




Last Modified: 01-14-2019	6.8:8.0.48	Doc ID: RM100000000THEY
Model Year Start: 2016	Model: Prius	Prod Date Range: [11/2015 -]
Title: 2ZR-FXE (EMISSION CONTROL): VACUUM SENSOR: REMOVAL; 2016 - 2019 MY Prius [11/2015 -]		

REMOVAL

PROCEDURE

1. REMOVE E.F.I. VACUUM SENSOR ASSEMBLY (MANIFOLD ABSOLUTE PRESSURE SENSOR)

- (a) Disconnect the E.F.I. vacuum sensor assembly (manifold absolute pressure sensor) connector.



- (b) Disconnect the vacuum hose from the E.F.I. vacuum sensor assembly (manifold absolute pressure sensor).

- (c) Remove the bolt and E.F.I. vacuum sensor assembly (manifold absolute pressure sensor) from the intake manifold.

