

thousands of miles:	5	10	15	20	25	30	35	40	45	50	55	60	65	70	75	80	85	90	95	100	105	110	115	120
months:	6	12	18	24	30	36	42	48	54	60	66	72	78	84	90	96	102	108	114	120	126	132	138	144
Check driver's floor mat	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
Inspect and adjust all fluid levels	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
Rotate tires	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
Visual inspect brake pads/discs	x	x	x	x	x		x	x	x	x	x		x	x	x	x	x		x	x	x	x	x	
Inspect brake pads/discs [3]						x						x						x						x
Replace engine oil and oil filter		x		x		x		x		x		x		x		x		x		x		x		x
Replace engine air filter [4]						x						x						x						x
Clean cabin air filter (solar)		x		x		x				x		x		x				x		x		x		
Replace cabin air filter (solar)								x								x								x
Clean cabin air filter (non-solar)			x					x						x						x				
Replace cabin air filter (non-solar)						x						x						x						x
Inspect transaxle fluid						x						x						x						x
Inspect engine/Inverter coolant			x			x			x			x			x			x			x			x
Replace engine/Inverter coolant [5]																				x				
Inspect ball joints & dust covers			x			x			x			x			x			x			x			x
Inspect drive shaft boots			x			x			x			x			x			x			x			x
Inspect exhaust system			x			x			x			x			x			x			x			x
Inspect radiator & condenser			x			x			x			x			x			x			x			x
Inspect steering gear box			x			x			x			x			x			x			x			x
Inspect steering linkage & boots			x			x			x			x			x			x			x			x
Inspect fuel lines, tank & vent						x						x						x						x
Inspect fuel tank cap gasket						x						x						x						x
Replace spark plugs																								x

[3]Complete brake inspection, including check of disc thickness and runout.

[4]Inspect every 5000 miles

[5] inverter coolant change at 150,000 miles or 180 months (per footnote 3 on page 51 of US maintenance guide)