

**2010 Prius Maintenance Schedule (Canadian, based on Owner's Manual Supplement)**

* kilometers:	8K	16K	24K	32K	40K	48K	56K	64K	72K	80K	88K	96K	104K	112K	120K	128K
maintenance items:	6 mo	12 mo	18 mo	24 mo	30 mo	36 mo	42 mo	48 mo	54 mo	60 mo	66 mo	72 mo	78 mo	84 mo	90 mo	96 mo
replace engine oil & filter	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
inspect engine air filter (1)	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
lube locks, hinges & latches	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
inspect lights, horns & wipers	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
check coolant, brake & washer fluid levels	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
inspect tire condition & pressure (2)	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
replace cabin air filter		X		X		X		X		X		X		X		X
check transaxle fluid level				X				X								X
change transaxle fluid **												X				
inspect steer. gear box, linkage, suspension (3)		X		X		X		X		X		X		X		X
inspect ball joints & dust covers		X		X		X		X		X		X		X		X
inspect drive shaft and steering rack boots		X		X		X		X		X		X		X		X
inspect chassis nuts, for looseness or damage		X		X		X		X		X		X		X		X
inspect brake linings, drums pads & discs		X		X		X		X		X		X		X		X
inspect brake lines & hoses		X		X		X		X		X		X		X		X
perform complete brake service				X				X				X				X
inspect exhaust system for leaks or damage		X		X		X		X		X		X		X		X
Road test		X		X		X		X		X		X		X		X
replace super long life coolant (4)																
inspect fuel lines, vapour vent system				X				X				X				X
inspect gas tank bands and cap gasket				X				X				X				X
replace iridium spark plugs (5)																

(1) inspect as scheduled, visually check & clean with compressed air as needed. Replace at least every 48000km

(2) including spare, rotate as needed

(3) check for looseness, damage or leakage

(4) replace at 120 mo / 160000 km, thereafter every 60 months / 80000 km

(5) every 192000 km

\* months or kilometers, whichever comes first

\*\* not clear if this is required