

Ρ

ILLUSTRATION



Lithium soap base glycol grease

Р

REMOVAL

1. REMOVE UPPER INSTRUMENT PANEL ASSEMBLY

HINT:

Refer to the instructions for Removal of the upper instrument panel assembly

- 2. REMOVE NO. 1 INSTRUMENT PANEL UNDER COVER SUB-ASSEMBLY
- 3. REMOVE STOP LIGHT SWITCH ASSEMBLY_
- 4. REMOVE STOP LIGHT SWITCH MOUNTING ADJUSTER
- 5. REMOVE BRAKE PEDAL RETURN SPRING



(a) Remove the brake pedal return spring from the brake pedal support sub-assembly and push rod pin.

6. REMOVE PUSH ROD PIN



(a) Remove the clip and push rod pin to separate the brake pedal subassembly from the push rod clevis.

7. SEPARATE DRIVER SIDE JUNCTION BLOCK ASSEMBLY

(a) Remove the bolt and nut, and separate the driver side junction block assembly.



8. REMOVE BRAKE PEDAL SUPPORT ASSEMBLY



(a) Remove the bolt and separate the brake pedal support assembly from the instrument panel reinforcement.



(b) Disengage the clamp and disconnect the connector from the brake pedal stroke sensor assembly.



(c) Remove the 4 nuts and brake pedal support assembly.

(d) Remove the nut from the brake pedal support assembly.



С

DISASSEMBLY

1. REMOVE BRAKE PEDAL STROKE SENSOR ASSEMBLY

2. REMOVE BRAKE PEDAL SUB-ASSEMBLY



(a) Remove the brake pedal shaft and nut to remove the brake pedal subassembly from the brake pedal support sub-assembly.

С

3. REMOVE BRAKE PEDAL SHAFT COLLAR

(a) Remove the brake pedal shaft collar from the brake pedal sub-assembly.

4. REMOVE BRAKE PEDAL BUSHING

(a) Remove the 2 brake pedal bushings from the brake pedal sub-assembly.

5. REMOVE BRAKE PEDAL PAD

ADJUSTMENT

1. INSPECT AND ADJUST BRAKE PEDAL HEIGHT

- (a) Check the brake pedal height.
- (1) Turn back the carpet.
- (2) Turn back the dash silencer from the slit provided on the dash silencer.



(3) Measure the shortest distance between the brake pedal surface and floor panel.

Text in Illustration

*1	Stop Light Switch Assembly
*2	Clevis Lock Nut
*3	Floor Panel
*4	Brake Pedal Height

Brake pedal height from floor panel:

127.7 to 137.7 mm (5.03 to 5.42 in.)

- С
- (b) Adjust the brake pedal height.

(1) Remove the stop light switch assembly .

- (2) Loosen the clevis lock nut.
- (3) Adjust the brake pedal height by turning the push rod.
- (4) Tighten the clevis lock nut.

Torque: 26 N·m (260 kgf·cm, 19ft·lbf)

(5) Install and adjust the stop light switch assembly

2. INSPECT AND ADJUST BRAKE PEDAL STROKE SENSOR ASSEMBLY

3. INSPECT BRAKE PEDAL FREE PLAY

(a) Depress the pedal until a slight resistance is felt. Measure the brake



pedal free play as shown in the illustration.

Text in Illustration

*1 Brake Pedal Free Play

Pedal free play:

1.0 to 6.0 mm (0.0394 to 0.236 in.)

If the pedal free play is not as specified, check the stop light switch clearance **RFO**. If the pedal free play is as specified, proceed to the Inspect Brake Pedal Reserve Distance procedure.

4. INSPECT BRAKE PEDAL RESERVE DISTANCE

HINT:

т

Measure the distance at the same point used for the brake pedal height inspection.

(a) Release the parking brake pedal.

(b) With the power switch on (READY), depress the brake pedal and measure the pedal reserve distance.

Pedal reserve distance from the floor panel at 196 N (20 kgf, 44.1 lbf):

More than 78.0 mm (3.07 in.)

If the distance is not as specified, troubleshoot the brake system

REASSEMBLY

1. INSTALL BRAKE PEDAL PAD

2. INSTALL BRAKE PEDAL BUSHING

- (a) Apply lithium soap base glycol grease to 2 new brake pedal bushings.
- (b) Install the 2 brake pedal bushings to the brake pedal sub-assembly.

3. INSTALL BRAKE PEDAL SHAFT COLLAR

(a) Install the brake pedal shaft collar to the brake pedal sub-assembly.

4. INSTALL BRAKE PEDAL SUB-ASSEMBLY



С

(a) Install the brake pedal sub-assembly to the brake pedal support subassembly with the brake pedal shaft and nut.

Torque: 17 N·m (176 kgf·cm, 13ft·lbf)

5. INSTALL BRAKE PEDAL STROKE SENSOR ASSEMBLY_

INSTALLATION

С

1. INSTALL BRAKE PEDAL SUPPORT ASSEMBLY



(a) Install the nut to the brake pedal support assembly.



(b) Install the brake pedal support assembly with the 4 nuts.

Torque: 13 N·m (130 kgf·cm, 9ft·lbf)



(c) Engage the clamp and connect the connector to the brake pedal stroke sensor assembly.

(d) Install the brake pedal support assembly to the instrument panel reinforcement with the bolt.

Text in Illustration

*1 Bolt Width		
Bolt Variation	Bolt Width	
Bolt A	14 mm (0.551 in.)	
Bolt B	12 mm (0.472 in.)	

for Bolt A - Torque: 14 N·m (140 kgf·cm, 10ft·lbf)



for Bolt B - Torque: 24 N·m (241 kgf·cm, 17ft·lbf)

HINT:

Two types of bolts each with a different torque specification are used.

2. INSTALL DRIVER SIDE JUNCTION BLOCK ASSEMBLY



(a) Install the driver side junction block assembly with the bolt and nut.

Torque: 14 N·m (138 kgf·cm, 10ft·lbf)

3. INSTALL PUSH ROD PIN

(a) Apply lithium soap base glycol grease to the push rod pin and installation hole of the brake pedal subassembly.



(b) Install the push rod pin and a new clip to connect the push rod clevis to the brake pedal sub-assembly.

4. INSTALL BRAKE PEDAL RETURN SPRING

2010 Toyota Prius



(a) Install the brake pedal return spring to the brake pedal support subassembly and push rod pin.

5. INSTALL STOP LIGHT SWITCH MOUNTING ADJUSTER

6. INSTALL STOP LIGHT SWITCH ASSEMBLY_

7. INSTALL UPPER INSTRUMENT PANEL ASSEMBLY

HINT:

Refer to the instructions for Installation of the upper instrument panel assembly

8. INSPECT AND ADJUST BRAKE PEDAL

HINT: INFO

9. INSTALL NO. 1 INSTRUMENT PANEL UNDER COVER SUB-ASSEMBLY

10. PERFORM INITIALIZATION AND CALIBRATION OF LINEAR SOLENOID VALVE

HINT: INFO