


# REMOVAL

## 1. REMOVE UPPER INSTRUMENT PANEL ASSEMBLY

(a) Remove the upper instrument panel assembly .

## 2. REMOVE NO. 1 HEATER TO REGISTER DUCT .

## 3. REMOVE COMBINATION METER ASSEMBLY



(a) Disconnect the connector.

(b) Disengage the clamp.

(c) Remove the 3 screws.


(d) Disengage the clip and remove the combination meter assembly.

# DISASSEMBLY

## NOTICE:


When disassembling the combination meter assembly, eliminate static electricity by touching the vehicle body to prevent components from being damaged.

### 1. REMOVE INSTRUMENT PANEL FINISH PANEL SUB-ASSEMBLY




(a) Remove the 6 screws and instrument panel finish panel sub-assembly.

### 2. REMOVE NO. 3 COMBINATION METER COVER




(a) Remove the 3 screws.



(b) Disengage the 7 claws and 2 guides to remove the No. 3 combination meter cover.


### 3. REMOVE METER CIRCUIT PLATE

(a) Disconnect the connector as shown in the illustration.




P

(b) Disengage the 2 guides to remove the meter circuit plate.



P

#### 4. REMOVE NO. 2 COMBINATION METER COVER




P


(a) Disengage the 2 guides to remove the No. 2 combination meter cover.

#### 5. REMOVE NO. 1 COMBINATION METER COVER


(a) Disengage the 2 guides to remove the No. 1 combination meter cover.



## 6. REMOVE NO. 4 COMBINATION METER COVER




(a) Remove the 7 screws.



(b) Disengage the 6 claws to remove the No. 4 combination meter cover.


## 7. REMOVE NO. 2 METER CIRCUIT PLATE

(a) Disconnect the connector as shown in the illustration.




P

(b) Disengage the 2 guides to remove the No. 2 meter circuit plate.



P


(c) Disconnect the connector to remove the No. 5 meter circuit plate from the No. 2 meter circuit plate as shown in the illustration.




P

## 8. REMOVE NO. 2 COMBINATION METER CASE

(a) Disengage the 2 guides to remove the No. 2 combination meter case.




### 9. REMOVE NO. 1 METER LENS



(a) Disengage the 2 guides to remove the No. 1 meter lens.


### 10. REMOVE NO. 4 METER CIRCUIT PLATE




(a) Disconnect the connector to remove the No. 4 meter circuit plate as shown in the illustration.

### 11. REMOVE NO. 3 METER CIRCUIT PLATE

(a) Disengage the 2 guides to remove the No. 3 meter circuit plate.




## 12. REMOVE COMBINATION METER CASE




(a) Disengage the 2 guides to remove the combination meter case.

## 13. REMOVE NO. 2 METER LENS




(a) Disengage the 2 guides to remove the No. 2 meter lens.

## 14. REMOVE NO. 3 METER LENS



(a) Disengage the 2 guides to remove the No. 3 meter lens.

## 15. REMOVE NO. 1 COMBINATION METER REFLECTOR



(a) Disengage the clip and 9 guides, and remove the No. 1 combination meter reflector as shown in the illustration.


## 16. REMOVE NO. 3 COMBINATION METER CASE



# REASSEMBLY


1. INSTALL NO. 3 COMBINATION METER CASE

2. INSTALL NO. 1 COMBINATION METER REFLECTOR




(a) Engage the clip and 9 guides to install the No. 1 combination meter reflector as shown in the illustration.

3. INSTALL NO. 3 METER LENS



(a) Engage the 2 guides to install the No. 3 meter lens.


4. INSTALL NO. 2 METER LENS




(a) Engage the 2 guides to install the No. 2 meter lens.

5. INSTALL COMBINATION METER CASE

(a) Engage the 2 guides to install the combination meter case.




#### 6. INSTALL NO. 3 METER CIRCUIT PLATE



(a) Engage the 2 guides to install the No. 3 meter circuit plate.


#### 7. INSTALL NO. 4 METER CIRCUIT PLATE




(a) Connect the connector to install the No. 4 meter circuit plate to the No. 3 meter circuit plate.

#### 8. INSTALL NO. 1 METER LENS

(a) Engage the 2 guides to install the No. 1 meter lens.




### 9. INSTALL NO. 2 COMBINATION METER CASE




(a) Engage the 2 guides to install the No. 2 combination meter case.

### 10. INSTALL NO. 2 METER CIRCUIT PLATE




(a) Connect the connector to install the No. 5 meter circuit plate to the No. 2 meter circuit plate.

(b) Engage the 2 guides to install the No. 2 meter circuit plate.




P



(c) Connect the connector as shown in the illustration.


P

## 11. INSTALL NO. 4 COMBINATION METER COVER



(a) Engage the 6 claws.


P



(b) Install the No. 4 combination meter cover with the 7 screws.


P

## 12. INSTALL NO. 1 COMBINATION METER COVER




(a) Engage the 2 guides to install the No. 1 combination meter cover.

### 13. INSTALL NO. 2 COMBINATION METER COVER




(a) Engage the 2 guides to install the No. 2 combination meter cover.

### 14. INSTALL METER CIRCUIT PLATE




(a) Engage the 2 guides to install the meter circuit plate.

(b) Connect the connector as shown in the illustration.




P

### 15. INSTALL NO. 3 COMBINATION METER COVER



P

(a) Engage the 7 claws and 2 guides.




P

(b) Install the No. 3 combination meter cover with the 3 screws.


### 16. INSTALL INSTRUMENT PANEL FINISH PANEL SUB-ASSEMBLY

(a) Install the instrument panel finish panel sub-assembly with the 6 screws.



# INSTALLATION

## 1. INSTALL COMBINATION METER ASSEMBLY



(a) Engage the clip.

(b) Install the combination meter assembly with the 3 screws.

(c) Engage the clamp.


(d) Connect the connector.

## 2. INSTALL NO. 1 HEATER TO REGISTER DUCT INFO

## 3. INSTALL UPPER INSTRUMENT PANEL ASSEMBLY

(a) Install the upper instrument panel assembly INFO.





P


### 32. REMOVE FRONT NO. 2 SPEAKER ASSEMBLY

HINT:

Use the same procedure for the RH side and LH side INFO.

### 33. REMOVE CENTER INSTRUMENT CLUSTER FINISH PANEL GARNISH

- (a) Remove the 2 screws <C>.
- (b) Disengage the 7 claws.
- (c) Disconnect the connector and remove the center instrument cluster finish panel garnish.




P

### 34. DISCONNECT NO. 3 INSTRUMENT PANEL WIRE INFO

### 35. REMOVE UPPER INSTRUMENT PANEL ASSEMBLY

- (a) Disconnect each connector.


(b) Disengage the 2 clamps.



P

(c) Remove the 2 bolts <B>.

(d) Remove the 2 passenger airbag bolts <A>.




P

**Text in Illustration**

*1	Passenger Airbag Bolt <A>	*2	Bolt <B>
----	---------------------------	----	----------

(e) Pull the upper instrument panel assembly in the direction indicated by the arrow to disengage the 2 claws and 4 clips.


(f) Pull the upper instrument panel assembly in the direction indicated by the arrow to disengage the 5 claws and remove the upper instrument panel assembly.



P

# DISASSEMBLY


## 1. REMOVE NO. 3 HEATER TO REGISTER DUCT



(a) Remove the 3 screws <C> and No. 3 heater to register duct.

P

## 2. REMOVE NO. 2 HEATER TO REGISTER DUCT



(a) Remove the 3 screws <C> and No. 2 heater to register duct.

P

3. REMOVE PLASMACLUSTER WITH BRACKET (w/ Plasmacluster) INFO


4. REMOVE NAVIGATION ANTENNA ASSEMBLY (w/ Navigation System) INFO

5. REMOVE AUTOMATIC LIGHT CONTROL SENSOR INFO


6. REMOVE NO. 2 INSTRUMENT PANEL WIRE

(a) Disconnect the connector.

(b) Disengage the 2 claws and each clamp, and remove the No. 2 instrument panel wire.




7. REMOVE NO. 5 INSTRUMENT PANEL WIRE



(a) Disengage the 2 clamps and remove the No. 5 instrument panel wire.


8. REMOVE INSTRUMENT CLUSTER FINISH PANEL ASSEMBLY



(a) Remove the 5 screws <C> and instrument cluster finish panel assembly.


9. REMOVE CENTER INSTRUMENT PANEL REGISTER ASSEMBLY

(a) Remove the 3 screws <C> and center instrument panel register



assembly.


#### 10. REMOVE METER HOOD SPACER



(a) Remove the 2 screws <C> and meter hood spacer.

#### 11. REMOVE FRONT PASSENGER SIDE AIRBAG ASSEMBLY [INFO](#)


#### 12. REMOVE NO. 1 INSTRUMENT PANEL CUSHION




(a) Remove the No. 1 instrument panel cushion.

#### 13. REMOVE INSTRUMENT PANEL CUSHION

(a) Remove the instrument panel cushion.




14. REMOVE NO. 2 INSTRUMENT PANEL CUSHION




(a) Remove the No. 2 instrument panel cushion.

15. REMOVE NO. 4 INSTRUMENT PANEL CUSHION



(a) Remove the No. 4 instrument panel cushion.

16. REMOVE NO. 5 INSTRUMENT PANEL CUSHION




(a) Remove the No. 5 instrument panel cushion.




# REASSEMBLY

## 1. INSTALL NO. 5 INSTRUMENT PANEL CUSHION




(a) Using hot-melt glue and install a new No. 5 instrument panel cushion as shown in the illustration.

## 2. INSTALL NO. 4 INSTRUMENT PANEL CUSHION



(a) Using hot-melt glue and install a new No. 4 instrument panel cushion as shown in the illustration.

## 3. INSTALL NO. 2 INSTRUMENT PANEL CUSHION




(a) Using hot-melt glue and install a new No. 2 instrument panel cushion as shown in the illustration.

## 4. INSTALL INSTRUMENT PANEL CUSHION

(a) Align the marking lines on the upper instrument panel with the ends of the instrument panel cushion and install a new instrument panel cushion


as shown in the illustration.



## Text in Illustration

*1	Marking Line
----	--------------

### 5. INSTALL NO. 1 INSTRUMENT PANEL CUSHION




(a) Align the marking lines on the upper instrument panel with the ends of the No. 1 instrument panel cushion and install a new No. 1 instrument panel cushion as shown in the illustration.

## Text in Illustration

*1	Marking Line
----	--------------


### 6. INSTALL FRONT PASSENGER SIDE AIRBAG ASSEMBLY\_ INFO

### 7. INSTALL METER HOOD SPACER




(a) Install the meter hood spacer with the 2 screws <C>.

### 8. INSTALL CENTER INSTRUMENT PANEL REGISTER ASSEMBLY




(a) Install the center instrument panel register assembly with the 3 screws <C>.

## 9. INSTALL INSTRUMENT CLUSTER FINISH PANEL ASSEMBLY



(a) Install the instrument cluster finish panel assembly with the 5 screws <C>.

## 10. INSTALL NO. 5 INSTRUMENT PANEL WIRE




(a) Engage the 2 clamps to install the No. 5 instrument panel wire.

## 11. INSTALL NO. 2 INSTRUMENT PANEL WIRE

(a) Engage each clamp and 2 claws.

(b) Connect the connector to install the No. 2 instrument panel wire.




P

12. INSTALL AUTOMATIC LIGHT CONTROL SENSOR\_ [INFO](#)

13. INSTALL NAVIGATION ANTENNA ASSEMBLY (w/ Navigation System)\_ [INFO](#)

14. INSTALL PLASMACLUSTER WITH BRACKET (w/ Plasmacluster)\_ [INFO](#)

15. INSTALL NO. 2 HEATER TO REGISTER DUCT



P

(a) Install the No. 2 heater to register duct with the 3 screws <C>.

16. INSTALL NO. 3 HEATER TO REGISTER DUCT

(a) Install the No. 3 heater to register duct with the 3 screws <C>.




P

# INSTALLATION

## 1. INSTALL UPPER INSTRUMENT PANEL ASSEMBLY

(a) When using a new upper instrument panel sub-assembly:


(1) Immediately before installing the upper instrument panel assembly, twist and cut off the portions shown in the illustration.



P

(b) Engage the 5 claws as shown in the illustration.

(c) Engage the 2 claws and 4 clips, and install the upper instrument panel assembly as shown in the illustration.




P

(d) Install the 2 bolts <B>.

(e) Install the 2 passenger airbag bolts <A>.

Torque: **20 N·m (204 kgf·cm, 15ft·lbf)**



P


*Text in Illustration*

*1	Passenger Airbag Bolt <A>	*2	Bolt <B>
----	---------------------------	----	----------

(f) Engage the 2 clamps.

(g) Connect each connector.





P


2. CONNECT NO. 3 INSTRUMENT PANEL WIRE INFO

3. INSTALL CENTER INSTRUMENT CLUSTER FINISH PANEL GARNISH

(a) Connect the connector.

(b) Engage the 7 claws.

(c) Install the center instrument cluster finish panel garnish with the 2 screws <C>.




P

#### 4. INSTALL FRONT NO. 2 SPEAKER ASSEMBLY

HINT:

Use the same procedure for the RH side and LH side INFO.

#### 5. INSTALL NO. 2 INSTRUMENT PANEL SPEAKER PANEL SUB-ASSEMBLY




P

(a) Engage the 2 guides and 6 claws to install the No. 2 instrument panel speaker panel sub-assembly as shown in the illustration.

#### 6. INSTALL FRONT PILLAR GARNISH CORNER PIECE RH

(a) Engage the 3 claws to install the front pillar garnish corner piece RH.



P


## 7. INSTALL FRONT PILLAR GARNISH RH

HINT:

Use the same procedure for the RH side and LH side INFO.

## 8. INSTALL FRONT NO. 2 SPEAKER ASSEMBLY INFO


## 9. INSTALL NO. 1 INSTRUMENT PANEL SPEAKER PANEL SUB-ASSEMBLY



P

(a) Engage the 2 guides and 6 claws to install the No. 1 instrument panel speaker panel sub-assembly as shown in the illustration.

## 10. INSTALL FRONT PILLAR GARNISH CORNER PIECE LH



P

(a) Engage the 3 claws to install the front pillar garnish corner piece LH.

## 11. INSTALL FRONT PILLAR GARNISH LH INFO

## 12. INSTALL INSTRUMENT PANEL FINISH PANEL END RH



(a) Engage the guide as shown in the illustration.



P



(b) Engage the guide as shown in the illustration.

P



(c) Engage the 4 claws to install the instrument panel finish panel end RH.


P

## 13. CONNECT FRONT DOOR OPENING TRIM WEATHERSTRIP RH\_ INFO

## 14. INSTALL GLOVE COMPARTMENT DOOR

(a) Open the glove compartment door assembly.

(b) Insert the glove compartment door as shown in the illustration.




(c) Engage the 7 claws to install the glove compartment door.

#### 15. INSTALL NO. 2 INSTRUMENT PANEL REGISTER



(a) Engage the 3 claws and clip to install the No. 2 instrument panel register.

#### 16. INSTALL NO. 1 SIDE DEFROSTER NOZZLE



(a) Engage the 3 claws to install the No. 1 side defroster nozzle.

#### 17. INSTALL INSTRUMENT PANEL FINISH PANEL END LH



(a) Engage the guide as shown in the illustration.



P



(b) Engage the guide as shown in the illustration.



P



(c) Engage the 4 claws to install the instrument panel finish panel end LH.

P


18. CONNECT FRONT DOOR OPENING TRIM WEATHERSTRIP LH\_ INFO

19. INSTALL NO. 1 CENTER INSTRUMENT CLUSTER FINISH PANEL

(a) Engage the 4 claws to install the No. 1 center instrument cluster finish panel.



20. INSTALL NO. 1 INSTRUMENT PANEL REGISTER




(a) Engage the 4 claws to install the No. 1 instrument panel register.

21. INSTALL LOWER INSTRUMENT PANEL FINISH PANEL ASSEMBLY


(a) Connect each connector.

(b) Engage the clamp.




(c) Engage the 2 guides and claw to connect the hood lock control cable.

(d) Engage the 6 claws and clip.



P



P

(e) Install the lower instrument panel finish panel assembly with the screw <C>.


22. INSTALL COWL SIDE TRIM SUB-ASSEMBLY LH INFO

23. INSTALL FRONT DOOR SCUFF PLATE LH INFO

24. INSTALL NAVIGATION RECEIVER WITH BRACKET (w/ Navigation System) INFO

25. INSTALL RADIO RECEIVER WITH BRACKET (w/o Navigation System) INFO

26. INSTALL UPPER INSTRUMENT PANEL FINISH PANEL SUB-ASSEMBLY



P

(a) Connect the connector.


(b) Engage the 3 claws to install the upper instrument panel finish panel sub-assembly.

27. INSTALL INSTRUMENT CLUSTER FINISH PANEL GARNISH




(a) Connect the connector.

(b) Engage the 14 claws to install the instrument cluster finish panel garnish.




## 28. INSTALL INSTRUMENT PANEL CUP HOLDER ASSEMBLY



(a) Install the instrument panel cup holder with the 4 screws <C> to the lower center instrument cluster finish panel sub-assembly.

## 29. INSTALL LOWER CENTER INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY

(a) Engage the 7 claws and 2 clips to install the lower center instrument cluster finish panel sub-assembly.



### 30. INSTALL INTEGRATION CONTROL AND PANEL ASSEMBLY



(a) Connect each connector.

(b) Engage the 6 claws to install the integration control and panel assembly.

### 31. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL

NOTICE:

When disconnecting the cable, some systems need to be initialized after the cable is reconnected INFO.

### 32. INSTALL REAR NO. 3 FLOOR BOARD INFO

### 33. INSTALL REAR DECK FLOOR BOX INFO

### 34. INSTALL REAR NO. 2 FLOOR BOARD (for Separate Type) INFO

### 35. INSPECT SRS WARNING LIGHT

(a) Inspect the SRS warning light INFO.