

Vehicle Diagnostic Report

2009 Prius 1NZ-FXE

Production Date - 12/2008
JTDKB20U197878719

3/12/2021 8:20:04 PM

Diagnostic Trouble Code Report ABS/VSC/TRAC(1 of 1)

Code	Description	Current	Pending	History	Summary	Freeze Frame
C0210	Rear Speed Sensor RH Circuit	X			Icon C	Y
C1253	Hydro-Booster Pump Motor Relay	X			Icon C	N
C1300	ABS ECU Malfunction	X			Icon C	Y
C1311	Open Circuit in Main Relay 1	X			Icon C	N
C1313	Open Circuit in Main Relay 2	X			Icon C	N
U0123	Lost Communication with Yaw Rate Sensor Module	X			Icon C	N
U0124	Lost Communication with Lateral Acceleration Sensor Module	X			Icon C	N
U0126	Lost Communication with Steering Angle Sensor Module	X			Icon C	N

Freeze Frame Data Report C1300(Current)(1 of 2)

Parameter	Value	Unit
Detailed Freeze DTC	65535	
Stop Light SW	OFF	
VSC/TRAC OFF SW	OFF	
Shift Lever Position	Fail	
Operated System	no Sys	
Number of IG ON	31	
Vehicle Speed	0	MPH
Steering Angle Sensor	1143	deg
Yaw Rate Sensor	-128	deg/s
Master Cylinder Sensor1	0.45	V
Pedal Stroke Sensor1	1.16	V
Throttle Sensor	0	deg
Master Cylinder Grade	0	MPa/s
Right And Left G	-1.49	G
Back And Forth G	0.00	G
Buzzer	OFF	
Reservoir Warning SW	OFF	
Parking Brake SW	OFF	
FR Wheel Cylinder	0.47	V
FL Wheel Cylinder	0.49	V
RR Wheel Cylinder	0.47	V
RL Wheel Cylinder	0.47	V
Accumulator Sensor	3.27	V
Master Cylinder Sensor2	0.47	V
Pedal Stroke Sensor2	3.80	V
MTT	0.00	V
IG1 Voltage	0.00	V
IG2 Voltage	0.00	V
BS1	11.46	V
BS2	11.46	V
VM1	10.84	V
VM2	10.84	V
+B1	12.15	V
+B2	12.23	V
FR Target Oil Pressure	0.0	MPa
FL Target Oil Pressure	0.0	MPa
RR Target Oil Pressure	0.0	MPa
RL Target Oil Pressure	0.0	MPa
SLAFR Solenoid Current	0.00	A
SLAFL Solenoid Current	0.00	A
SLARR Solenoid Current	0.00	A
SLARL Solenoid Current	0.00	A
SLRFR Solenoid Current	0.00	A
SLRFL Solenoid Current	0.00	A
SLRRR Solenoid Current	0.00	A

Freeze Frame Data Report
C1300(Current)(2 of 2)

Parameter	Value	Unit
SLRRL Solenoid Current	0.00	A
FR Wheel Speed	0	MPH
FL Wheel Speed	0	MPH
RR Wheel Speed	0	MPH
RL Wheel Speed	0	MPH
Capacitor Mode	OFF	
ECB Solenoid (SCSS)	OFF	
ECB Solenoid (SMC1)	OFF	
ECB Solenoid (SMC2)	OFF	
Motor Relay1	OFF	
Motor Relay2	OFF	
ECB Main Relay1	ON	
ECB Main Relay2	ON	