

Vehicle Diagnostic Report

2009 Prius 1NZ-FXE

Production Date - 12/2008
JTDKB20U197878719

3/12/2021 8:21:21 PM

Diagnostic Trouble Code Report ABS/VSC/TRAC(1 of 1)

Code	Description	Current	Pending	History	Summary	Freeze Frame
C0210	Rear Speed Sensor RH Circuit	X			Icon C	Y
C1253	Hydro-Booster Pump Motor Relay	X			Icon C	N
C1300	ABS ECU Malfunction	X			Icon C	Y
C1311	Open Circuit in Main Relay 1	X			Icon C	N
C1313	Open Circuit in Main Relay 2	X			Icon C	N
U0123	Lost Communication with Yaw Rate Sensor Module	X			Icon C	N
U0124	Lost Communication with Lateral Acceleration Sensor Module	X			Icon C	N
U0126	Lost Communication with Steering Angle Sensor Module	X			Icon C	N

Freeze Frame Data Report C0210(Current)(1 of 2)

Parameter	Value	Unit
Detailed Freeze DTC	280	
Stop Light SW	OFF	
VSC/TRAC OFF SW	OFF	
Shift Lever Position	D(M)	
Operated System	no Sys	
Number of IG ON	31	
Vehicle Speed	70	MPH
Steering Angle Sensor	0	deg
Yaw Rate Sensor	0	deg/s
Master Cylinder Sensor1	0.45	V
Pedal Stroke Sensor1	1.16	V
Throttle Sensor	124	deg
Master Cylinder Grade	0	MPa/s
Right And Left G	0.00	G
Back And Forth G	0.00	G
Buzzer	OFF	
Reservoir Warning SW	OFF	
Parking Brake SW	OFF	
FR Wheel Cylinder	0.47	V
FL Wheel Cylinder	0.47	V
RR Wheel Cylinder	0.47	V
RL Wheel Cylinder	0.49	V
Accumulator Sensor	3.58	V
Master Cylinder Sensor2	0.47	V
Pedal Stroke Sensor2	3.78	V
MTT	0.00	V
IG1 Voltage	13.80	V
IG2 Voltage	13.72	V
BS1	13.41	V
BS2	13.49	V
VM1	13.26	V
VM2	13.10	V
+B1	13.95	V
+B2	13.95	V
FR Target Oil Pressure	0.0	MPa
FL Target Oil Pressure	0.0	MPa
RR Target Oil Pressure	0.0	MPa
RL Target Oil Pressure	0.0	MPa
SLAFR Solenoid Current	0.00	A
SLAFL Solenoid Current	0.00	A
SLARR Solenoid Current	0.00	A
SLARL Solenoid Current	0.00	A
SLRFR Solenoid Current	0.00	A
SLRFL Solenoid Current	0.00	A
SLRRR Solenoid Current	0.00	A

Freeze Frame Data Report
C0210(Current)(2 of 2)

Parameter	Value	Unit
SLRRL Solenoid Current	0.00	A
FR Wheel Speed	70	MPH
FL Wheel Speed	70	MPH
RR Wheel Speed	0	MPH
RL Wheel Speed	70	MPH
Capacitor Mode	OFF	
ECB Solenoid (SCSS)	OFF	
ECB Solenoid (SMC1)	OFF	
ECB Solenoid (SMC2)	OFF	
Motor Relay1	OFF	
Motor Relay2	OFF	
ECB Main Relay1	ON	
ECB Main Relay2	ON	