

Fig. 7: Removing/Installing Brake Master Cylinder Reservoir Filler Cap Assembly
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

2. Add brake fluid into the reservoir between MAX and MIN level on the brake fluid reservoir.

Brake fluid

SAE J1703 or FMVSS No. 116 DOT3

3. Connect the Techstream to the DLC3 and turn the power switch on (IG).
4. Turn the Techstream on and enter the following menus: Chassis / ABS/VSC/TRAC / Air Bleeding.
5. Select the "Usual air bleeding" on the Techstream display, and replace the brake fluid following the instructions on the Techstream.
6. After replacing brake fluid, tighten each bleeder plug.

front bleeder plug

Torque: 8.3 N*m (85 kgf*cm, 73 in.*lbf)

rear bleeder plug

Torque: 11 N*m (112 kgf*cm, 8 ft.*lbf)

- c. Clear the DTCs. Refer to **DTC CHECK / CLEAR** .
- d. Turn the Techstream off and turn the power switch off.
- e. Inspect for brake fluid leaks.
- f. Install the brake master cylinder reservoir filler cap.
- g. Install the center cowl top ventilator cover.
 1. Engage the 2 claws and 3 guides to install the center cowl top ventilator cover.