

## Vehicle information

2007 Toyota Prius

VIN: JTDKB20U377559867

Mileage:

Diagnostic time: 2024-02-19 16:29:57

Diagnostic path: Automatic selection\USA\2007\w/ Smart Key\Diagnosis\Control unit\Hv battery\Trouble codes\

## Freeze frame data

Calculate load	0.0	
Engine coolant temp	9	°C
Engine revolution	0	rpm
Vehicle spd	0	Km/h
Throttle position	14.5	%
Engine run time	0	S
Dtc clear warm up	0	
+B	14.410	V
Battery state of charge	59.5	%
Batt pack current val	8.93	A
Battery block vol -v01	15.96	V
Battery block vol -v02	15.94	V
Battery block vol -v03	15.93	V
Battery block vol -v04	15.87	V
Battery block vol -v05	15.90	V
Battery block vol -v06	15.91	V
Battery block vol -v07	15.90	V
Battery block vol -v08	15.91	V
Battery block vol -v09	15.96	V

Battery block vol -v10	-8.96	V
Battery block vol -v11	15.90	V
Battery block vol -v12	15.93	V
Battery block vol -v13	15.90	V
Battery block vol -v14	15.91	V
Inhaling air temp	10.1	°C
Vmf fan motor voltage	0.0	V
Auxiliary battery vol	14.4	V
Charge control val	-15.0	KW
Discharge control val	14.0	KW
Delta soc	0.0	%
Charge control signal	On	
Equal charg out rly sig	OFF	
Eqtr charge perm sig	OFF	
Standby blower request	OFF	
Cooling fan mode	0	Mode
Ecu control mode	0	
Temp of batt tb1	9.3	°C
Temp of batt tb2	8.3	°C
Temp of batt tb3	9.4	°C